

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GAOMON](#) /

› [GAOMON Kitchen Island and Baker's Rack Instruction Manual](#)

GAOMON 43.7*27.9*72

GAOMON Kitchen Island and Baker's Rack

Model: 43.7*27.9*72 | Brand: GAOMON

INTRODUCTION

Thank you for choosing the GAOMON Kitchen Island and Baker's Rack. This versatile furniture piece is designed to enhance your kitchen, dining room, or living room with additional storage and workspace. This manual provides essential information for safe assembly, proper use, and maintenance of your new product. Please read these instructions carefully before assembly and retain them for future reference.



Figure 1: Fully assembled GAOMON Kitchen Island and Baker's Rack.

SAFETY INFORMATION

- Do not expose the product to liquids.
- Assemble carefully to avoid injury. Ensure all parts are correctly aligned and securely fastened.
- Do not exceed the maximum weight capacity of 400 pounds for the tabletop and shelves.
- Keep small parts and packaging materials away from children during assembly.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop (1x)
- Lower Storage Shelves (2x)

- Metal Frame Components (various)
- Overhead Rack with Hooks (1x)
- S-Hooks (5x)
- Assembly Hardware (screws, bolts, Allen wrench, etc.)
- Casters (optional, if included)

SETUP AND ASSEMBLY

Assembly typically takes approximately 45-60 minutes. No additional tools are required as all necessary assembly tools are included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the Main Frame:** Connect the vertical and horizontal metal frame components using the provided hardware. Ensure all connections are finger-tight before fully tightening.
3. **Install Lower Shelves:** Slide and secure the two lower storage shelves into their designated positions within the main frame. Ensure they are level and stable.
4. **Attach Tabletop:** Place the wooden tabletop onto the top of the main frame and secure it with the appropriate screws.
5. **Install Overhead Rack:** Attach the vertical supports for the overhead rack to the tabletop frame, then secure the top rack piece.
6. **Attach S-Hooks:** Hang the 5 S-hooks onto the overhead rack.
7. **Final Tightening:** Once all components are in place, carefully tighten all screws and bolts using the provided Allen wrench. Do not overtighten.
8. **Check Stability:** Gently shake the assembled unit to ensure it is stable and all connections are secure.




Figure 2: Product dimensions for assembly planning.

OPERATING INSTRUCTIONS

The GAOMON Kitchen Island and Baker's Rack is designed for versatile use in various home settings.

- **Tabletop Usage:** The 30mm thickened wooden tabletop provides a stable and durable surface for food preparation, dining, or as a coffee bar. It can support up to 400 pounds.

30mm Thickened Table Top

Stable and Durable



Figure 3: Detail of the thickened tabletop.

- **Storage Shelves:** Utilize the three spacious open shelves to store kitchen appliances such as microwaves, toasters, pots, pans, and other kitchen utensils. The shelves are designed for easy access and organization.



Figure 4: Storage shelves in use.

- **S-Hooks:** The five included S-hooks on the overhead rack are perfect for hanging cooking tools, spoons, pans, or kitchen towels, keeping them within easy reach and freeing up counter space.



Figure 5: Overhead rack with S-hooks.

To ensure the longevity and appearance of your GAOMON Kitchen Island and Baker's Rack, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** In case of spills, wipe them immediately with a dry cloth to prevent moisture damage to the wood.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.

TROUBLESHOOTING

If you encounter any issues with your kitchen island, refer to the following common troubleshooting tips:

- **Wobbling/Instability:** Ensure all screws and bolts are fully tightened. Check that the unit is placed on a flat, even surface. Adjust any leveling feet if present.
- **Missing Parts:** If any parts were missing upon arrival, review the package contents list. Contact customer support with details of the missing components.
- **Damaged Parts:** If any components arrived damaged, do not proceed with assembly. Contact customer support immediately for assistance.

SPECIFICATIONS

Feature	Detail
Brand	GAOMON
Model Number	43.7*27.9*72
Material	Wood (Engineered Wood shelves) and Metal
Color	Pear Wood and White
Product Dimensions (D x W x H)	42"D x 27"W x 72"H (approx. 43.7"D x 27.9"W x 72"H)
Item Weight	66 Pounds
Number of Shelves	3
Weight Capacity (Maximum)	400 Pounds
Assembly Required	Yes
Installation Type	Freestanding
Care Instructions	Wipe with Dry Cloth

WARRANTY AND SUPPORT

GAOMON is committed to providing quality products and customer satisfaction.

- **Return Policy:** This product is eligible for a 30-day easy return policy from the date of purchase. Please refer to your retailer's specific return guidelines.

- **Protection Plans:** Optional 2-Year and 3-Year protection plans may be available for purchase separately. Please check with your retailer for details.
- **Customer Support:** For any questions, concerns, or assistance with assembly or parts, please contact Gaomon Direct customer support. Contact information can typically be found on your purchase receipt or the retailer's website.