Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

oneisall DTJ 002

oneisall 2 in 1 Dog Clippers Grooming and Paw Trimmer User Manual

Model: DTJ 002 | Brand: oneisall

1. Introduction

Thank you for choosing the oneisall 2 in 1 Dog Clippers Grooming and Paw Trimmer. This versatile grooming kit is designed to provide a stress-free and efficient grooming experience for your beloved pets. Featuring two specialized blades, a quiet motor, and a long-lasting battery, it's perfect for maintaining your pet's coat and sensitive areas with ease.



Image: The oneisall 2 in 1 Dog Clippers Grooming and Paw Trimmer with accessories and three dogs.

2. Package Contents

Upon unboxing your oneisall grooming kit, you should find the following items:

- Dog Clippers (1)
- Colorful Guards (6): 3 mm, 6 mm, 10 mm, 13 mm, 16 mm, 19 mm
- Cleaning Brush (1)
- Grooming Oil (1)
- Charging Cable (1)

- Instructions (1)



Image: A visual representation of all items included in the oneisall grooming kit.

3. Safety Information

Caution:

- Keep blades away from eyes and face.
- Do not use on infants.
- Keep away from water.

- Always unplug and allow to cool before cleaning.
- Always follow recommended cleaning and maintenance procedures.
- Always supervise children when using this product.

4. Product Overview

The oneisall 2 in 1 Dog Clippers feature a thoughtful design for optimal performance and user convenience.



Image: Detailed view of the clipper highlighting washable blades, USB-C charging, one-click blade replacement, battery level indicator, lightweight design, and dual-switch for power control.

Key Features:

- **2-in-1 Design:** Includes a wide blade for thick coats and a narrow blade for sensitive areas like paws, face, and ears.
- **Sharp Stainless Steel Blades:** Durable and effective for thick and matted fur, reducing pulling.
- **Low Noise Motor:** Operates below 50 dB for a stress-free grooming experience.
- **2 Adjustable Speed Settings:** Adapts to different fur types.
- **Long-Lasting Battery:** 2500mAh battery provides up to 240 minutes of continuous use.
- **LCD Display:** Shows remaining battery level.
- **Easy Detachable Blade:** One-click "PUSH" button for quick blade replacement.

5. Setup

5.1 Charging the Clippers

Before first use, fully charge the clippers. Connect the provided USB-C charging cable to the clipper's charging port and plug the other end into a compatible USB power adapter (not included). The LCD display will indicate the charging progress.



Image: The clipper connected to a laptop via USB-C for charging, showing battery level indicators.

5.2 Installing and Removing Blades

The clippers come with a standard wide blade installed. To switch to the narrow paw trimmer blade or for cleaning:

1. Ensure the clippers are turned off.
2. Locate the "PUSH" button on the back of the clipper, just below the blade.
3. Press the "PUSH" button firmly to release the current blade head. It will pop up slightly.
4. Gently pull the blade head away from the clipper body.
5. To install a new blade, align the new blade head with the slots on the clipper body.

6. Press the blade head firmly inward until it clicks securely into place.

Your browser does not support the video tag.

Video: Demonstrates how to install and remove the blade head on the oneisall dog clippers using the "PUSH" button for easy replacement.

5.3 Attaching Guide Combs

Select the desired colorful guide comb (3mm to 19mm) based on the desired hair length. Slide the comb onto the clipper blade until it snaps securely into place. Ensure it is fully seated before grooming.



Image: Various colorful guide combs (3mm, 6mm, 10mm, 13mm, 16mm, 19mm) for achieving different hair lengths.

6. Operating Instructions

6.1 Powering On/Off and Speed Settings

Press the power button to turn the clippers on. The LCD display will light up, indicating the battery level. Press the power button again to cycle through the two speed settings: a quieter mode for thin/fine hair and a turbo mode for thick/curly hair. Press and hold the power button to turn the clippers off.



Image: The clipper showing its dual power modes: Quiet Mode for thin & fine hair, and Turbo Mode for thick & curly hair.

6.2 General Grooming (Wide Blade)

For overall body grooming, use the standard wide blade with the appropriate guide comb. Ensure your pet's coat is clean, dry, and tangle-free before grooming. Move the clippers smoothly and evenly against the direction of hair growth for best results.



Image: A person grooming a dog with the oneisall clippers, demonstrating its use for general coat trimming.

6.3 Paw and Sensitive Area Trimming (Narrow Blade)

Switch to the narrow blade for precise trimming around sensitive areas such as paws, face, and ears. This smaller blade allows for greater control and reduces the risk of accidental nicks. Gently hold the paw or area taut and carefully trim the hair.



Image: Close-up of a dog's paw being trimmed with the narrow blade of the oneisall clippers, showing its effectiveness for delicate areas.

Your browser does not support the video tag.

Video: An overview of the oneisall 2 in 1 Dog Clippers and Paw Trimmer (Model DTJ 002), showcasing its features and use on various pet areas.

7. Maintenance

7.1 Cleaning the Blades

Regular cleaning ensures optimal performance and longevity of your clippers:

1. Turn off the clippers and remove the blade head as described in Section 5.2.
2. Use the provided cleaning brush to remove any trapped hair from the blades and the clipper body.
3. The blades are washable. You may rinse them under running water. Ensure they are completely dry before reattaching.

7.2 Lubrication

Apply a few drops of the included grooming oil to the blades after each cleaning or every few uses to keep them running smoothly and prevent rust. Turn the clippers on for a few seconds to distribute the oil evenly.

7.3 Storage

Store the clippers and all accessories in a cool, dry place, away from direct sunlight and moisture. Keep them out of reach of children and pets.

8. Troubleshooting

Problem	Possible Cause	Solution
Clippers not turning on	Low battery; Power button not pressed correctly.	Charge the clippers fully; Press and hold the power button firmly.
Hair pulling or uneven cutting	Blades are dull, dirty, or not lubricated; Hair is tangled or matted.	Clean and lubricate blades; Ensure hair is clean and tangle-free before grooming.
Clippers getting warm quickly	Extended use; Blades need lubrication.	Allow clippers to cool down; Apply grooming oil to blades.
Blade not detaching/attaching easily	Improper alignment; Debris blocking mechanism.	Ensure proper alignment with slots; Clear any debris from the mechanism.

9. Specifications

Feature	Detail
Model Name	DTJ 002
Item Weight	1.12 pounds (0.51 Kilograms)
Item Dimensions (LxWxH)	8 x 2 x 7.6 inches
Battery Capacity	2500mAh Lithium Ion
Run Time (Full Charge)	Up to 240 minutes (4 hours)
Noise Level	Below 50 dB

Feature	Detail
Blade Material	Stainless Steel
Charging Method	USB-C
Included Components	Clippers, 2 Blades (Standard & Small), 6 Guide Combs, Cleaning Brush, Grooming Oil, Charging Cable

10. Warranty and Support

oneisall offers a **2-Year Warranty** on this product. For any questions, concerns, or technical support, please contact oneisall customer service. They provide **24-hour Customer Service** to assist you.
For further assistance, please refer to the contact information provided in your product packaging or visit the official oneisall website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CSYH27TM

More documents and user manuals: **https://manuals.plus/**