

Dexnor DK005

Dexnor Keyboard Case User Manual

Model: DK005 | Brand: Dexnor

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Dexnor Keyboard Case. Designed for enhanced productivity and protection, this keyboard case transforms your Samsung Galaxy tablet into a versatile laptop-like device.



Image: Dexnor Keyboard Case with a Samsung Galaxy Tab, showcasing the keyboard and tablet in an open, laptop-like configuration.

PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Premium Bluetooth Keyboard Case
- 1 x USB-C Charging Cable
- 1 x User Manual (this document)
- 1 x Quick-start Guide

COMPATIBILITY

The Dexnor Keyboard Case is specifically designed for the following Samsung Galaxy Tab models:

- 2025 Samsung Galaxy Tab S10 FE 10.9-inch (Models: SM-X520, SM-X526, SM-X526B)
- 2023 Samsung Galaxy Tab S9 11-inch (Models: Wi-Fi SM-X710, 5G SM-X716B, SM-X718U)
- 2023 Samsung Galaxy Tab S9 FE 5G 10.9-inch (Models: Wi-Fi SM-X510, 5G SM-X516B, SM-X518U)

Note: This case is NOT compatible with the Tab S10 FE+, S9+, or S9 FE+ 12.4-inch models. Please confirm your tablet model before use.



ATTENTION

Check Tablet models as follows

① Settings → ② About Tablet

Only compatible with Samsung Galaxy Tab S9/S9 FE



ONLY FOR
Samsung Galaxy Tab
S9/S9 FE



NOT FOR
Samsung Galaxy Tab
S9+/S9 FE+



KEY FEATURES

Magnetic Floating Cantilever Stand

The sturdy aluminum alloy hinge with embedded magnets allows for instant transformation of your tablet into a laptop. It provides seamless adjustments for optimal viewing angles, ideal for various environments like travel, business, or work.

SECURE MAGNETIC ATTACHMENT

Turn your tablet into a laptop anytime anywhere




Image: The keyboard case with a tablet attached, demonstrating the magnetic floating cantilever stand at a 125-degree angle, suitable for lap or table use.

High-Precision Multi-Touch Trackpad

Navigate your tablet with ease using the integrated smart trackpad, which supports multi-finger gestures. This feature provides mouse-like controls for efficient document editing, web browsing, and presentation building.

MULTI-TOUCH TRACKPAD

DEXNOR

Navigate your tablet with unparalleled precision



Type-C charging



Anti-scratch PU leather



Automatic sleep/wake up

Image: Close-up of the keyboard's multi-touch trackpad, highlighting its responsive surface and illuminated logo.

S Pen Holders

The case includes two convenient S Pen holders: a built-in magnetic holder within the keyboard for secure storage, and a cut-out slot on the back cover for both charging and storage. This design ensures quick access and prevents loss of your S Pen. The case also folds into a slim folio for comprehensive front and back protection.

2 PLACES FOR STYLUS STORAGE

Enjoy the convenience of quick access while preventing loss



Image: A side view of the keyboard case showing the tablet attached, with an S Pen stored in the integrated holder on the keyboard base, and another view showing the S Pen charging slot on the back of the tablet case.

Backlit & Rechargeable Keyboard

Enhance your typing experience with 7 solid color backlights and 3 adjustable brightness levels. The keyboard is powered by a long-lasting 650mAh battery, providing up to 200 hours of working time and 1200 hours of standby time on a single charge. It fully recharges in approximately 3.5 hours via the included USB-C cable. The auto wake/sleep function helps conserve battery power.

7 BACKLIGHT MODES

Easy and comfortable to type, whether it's day or night



Image: The keyboard illuminated with a blue backlight, demonstrating the 7 available color options and adjustable brightness levels.

SETUP GUIDE

1. Charging the Keyboard

Before first use, fully charge the keyboard. Connect the included USB-C charging cable to the keyboard's charging port and plug the other end into a USB power adapter (not included).

- A full charge takes approximately 3.5 hours.
- The charging indicator light will change to indicate a full charge.

2. Attaching Your Tablet

The keyboard case features a strong magnetic attachment system. Simply align your compatible Samsung Galaxy Tab with the magnetic area on the cantilever stand. The magnets will securely hold the tablet in place.

- Ensure the tablet is correctly oriented for optimal magnetic connection.

- The cantilever design allows for various viewing angles once attached.

3. Bluetooth Pairing

To connect the keyboard to your tablet via Bluetooth:

1. Turn on the keyboard by sliding the power switch to the "ON" position.
2. Press the **Fn + C** keys simultaneously on the keyboard to enter Bluetooth pairing mode. The Bluetooth indicator light will flash.
3. On your Samsung Galaxy Tab, go to **Settings > Connected devices > Bluetooth**.
4. Turn on Bluetooth and search for available devices.
5. Select "Dexnor Keyboard" (or similar name) from the list of available devices.
6. Follow any on-screen prompts to complete the pairing process. The Bluetooth indicator light on the keyboard will turn solid when successfully paired.

Your browser does not support the video tag.

Video: A demonstration of the Dexnor Keyboard Case, showing its features and how it functions with the Samsung Galaxy Tab. This video highlights the ease of setup and use.

OPERATING INSTRUCTIONS

1. Using the Keyboard

The keyboard provides a full QWERTY layout with additional function keys for tablet control.

- **Typing:** Use the keys as you would a standard laptop keyboard.
- **Function Keys:** The top row of keys (F1-F12 equivalents) often have dual functions. Press **Fn** key along with the desired function key to activate its secondary function (e.g., volume control, media playback).
- **Shortcut Keys:** The keyboard supports practical shortcut keys combined with DeX mode for enhanced productivity.

2. Adjusting Backlight

To customize the keyboard backlight:

- Press the **Light Bulb** key (usually near the top right) to cycle through 7 different backlight colors.
- Press **Fn + Light Bulb** key to adjust the brightness level (3 levels available).

3. Using the Multi-Touch Trackpad

The trackpad allows for precise navigation and supports various multi-finger gestures:

- **Single Finger Tap:** Left-click.
- **Two Finger Tap:** Right-click.
- **Two Finger Scroll:** Scroll up/down or left/right.
- **Pinch to Zoom:** Zoom in/out on content.
- Refer to your tablet's settings for additional trackpad gesture customization.

Your browser does not support the video tag.

Video: A detailed overview of the Dexnor Keyboard Case, demonstrating its features including the keyboard and trackpad functionality with a Samsung Galaxy Tab.

MAINTENANCE

Proper care will extend the life of your Dexnor Keyboard Case:

- **Cleaning:** Use a soft, damp cloth to wipe down the exterior of the case and keyboard. Avoid harsh chemicals or abrasive materials.
- **Storage:** When not in use, keep the case closed to protect the tablet screen and keyboard. Store in a cool, dry place.
- **Battery Care:** To maintain battery health, avoid fully discharging the keyboard frequently. Recharge when the battery is low. If storing for an extended period, charge the battery to about 50% every few months.

TROUBLESHOOTING

If you encounter issues with your Dexnor Keyboard Case, please refer to the following common solutions:

- **Keyboard Not Connecting via Bluetooth:**

- Ensure the keyboard is charged and powered on.
- Verify Bluetooth is enabled on your tablet.
- Try unpairing and re-pairing the keyboard in your tablet's Bluetooth settings.
- Restart both the tablet and the keyboard.

- **Trackpad Lag or Unresponsiveness:**

- Ensure your tablet's operating system is up to date.
- Check tablet settings for trackpad sensitivity and pointer speed adjustments.
- Clean the trackpad surface to remove any debris.
- If issues persist, try restarting the keyboard and tablet.

- **Backlight Not Working or Dim:**

- Ensure the keyboard battery is sufficiently charged.
- Press the backlight adjustment keys (**Light Bulb** key or **Fn + Light Bulb**) to cycle through colors and brightness levels.

- **Tablet Not Attaching Securely:**

- Ensure the tablet model is compatible with the case (refer to Compatibility section).
- Check for any obstructions or debris on the magnetic surfaces of both the tablet and the case.

SPECIFICATIONS

Model Number	DK005
Product Dimensions	10.2 x 8.07 x 0.75 inches
Item Weight	1.53 pounds
Connectivity Technology	Bluetooth
Keyboard Description	Multi Functional
Number of Keys	64
Keyboard Backlighting Color Support	RGB (7 solid colors)
Battery Capacity	650mAh
Working Time	Up to 200 hours (without backlight)

Standby Time	Up to 1200 hours
Charging Time	Approx. 3.5 hours

WARRANTY & SUPPORT

Dexnor stands behind the quality of its products.

- **Manufacturer's Warranty:** Your Dexnor Keyboard Case comes with a 1-year manufacturer's warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
- **Technical Support:** Enjoy lifetime technical support for your product. If you have any questions or require assistance, please contact Dexnor customer service.

For warranty claims or technical assistance, please refer to the contact information provided in your quick-start guide or visit the official Dexnor website.

© 2024 Dexnor. All rights reserved.

Documents - Dexnor – DK005

Report No.: CTA2402220701

FCC TEST REPORT

[\[pdf\] Test Report](#)

EMC DSS AC Test Report Shenzhen Houlci Network Technology CO Ltd DK004DK005 2BA3T 2BA3TDK004DK005 dk004dk005

Report No.: CTA2402220701 FCC TEST REPORT Test report On Behalf of Shenzhen Houlci Network Technology CO., Ltd For Bluetooth Keyboard Model No: DK004, DK005 FCC ID: 2BA3T-DK004DK005 Prepared for : Shenzhen Houlci Network Technology CO., Ltd 2606, West Tower, Galaxy Twin Towers, Yaxing Road 8, ...

lang:en score:18 filesize: 913.62 K page_count: 36 document date: 2024-02-26

Page 1 of 36