

[Manuals.plus](#) /

› [Outsunny](#) /

› Outsunny 4-Piece Garden Furniture Set User Manual

## Outsunny DE84G-207V00BK0431

# Outsunny 4-Piece Garden Furniture Set User Manual

Model: DE84G-207V00BK0431

## INTRODUCTION

Thank you for choosing the Outsunny 4-Piece Garden Furniture Set. This manual provides important information regarding the assembly, operation, maintenance, and specifications of your new furniture set. Please read this manual thoroughly before assembly and use to ensure safe and proper handling of the product. Keep this manual for future reference.

## PRODUCT OVERVIEW

The Outsunny 4-Piece Garden Furniture Set is designed to enhance your outdoor living space, offering comfort and style. It includes a two-seater sofa, two single chairs, and a functional coffee table, making it ideal for terraces, gardens, pool areas, verandas, and yards.

### Key Features:

- **Four-Piece Set:** Comprises one two-seater sofa, two chairs, and one coffee table, accommodating four people simultaneously. Offers versatile combination possibilities to suit your decor or occasion.
- **Outdoor Suitable:** Constructed with a lacquered steel frame that is easy to clean and resistant to UV radiation and light moisture.
- **Breathable and Air-Permeable:** Seating surfaces made of breathable mesh ensure pleasant coolness and good ventilation, preventing discomfort on hot summer days.
- **Stylish Side Table:** The coffee table features a 5 mm thick tempered glass top, which is both stylish and easy to clean, eliminating worries about spilled drinks.



Image: The complete Outsunny 4-piece garden furniture set, including a two-seater sofa, two single chairs, and a coffee table.



Image: The furniture set placed on a patio rug in a garden setting, demonstrating its aesthetic appeal in an outdoor environment.

## WHAT'S IN THE BOX

Upon unpacking, please ensure all components listed below are present and undamaged:

- 1 x Two-seater Sofa
- 2 x Single Chairs
- 1 x Coffee Table
- Assembly Hardware (screws, bolts, tools if provided)
- Instruction Manual (this document)

## SETUP AND ASSEMBLY

Assembly of the Outsunny Garden Furniture Set requires careful attention to detail. All parts are neatly packed and numbered to minimize errors.

### Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches. Verify all parts are present according to the packing list.
2. Follow the numbered instructions provided in the assembly guide. Note that there are many screws, so take your time.
3. **Important Assembly Tip:** A common point of confusion in assembly is the installation of the support bar for the seat. It is strongly recommended to install this bar into the bench and chairs **before** fully assembling the main frame, as it may be difficult to fit afterwards.
4. Securely tighten all screws and bolts once the components are aligned. Do not overtighten to avoid damaging the frame.
5. Once assembled, gently test the stability of each piece before full use.




Image: A diagram illustrating the dimensions of the two-seater sofa (111L x 70W x 75H cm), single chair (59W x 70D x 75H cm), and coffee table (75L x 43W x 38.5H cm).



# STABILE STAHLKONSTRUKTION

Für den langfristigen Einsatz im Freien konzipiert



Image: A close-up view of the stable steel frame construction of the furniture, highlighting its durability.

## OPERATING INSTRUCTIONS

Your Outsunny Garden Furniture Set is designed for comfortable outdoor use. Simply arrange the two-seater sofa, two chairs, and coffee table to suit your space and needs. The lightweight design allows for easy rearrangement.

### Usage Tips:

- Place the furniture on a flat, stable surface to ensure stability and prevent tipping.
- Utilize the coffee table for drinks, snacks, or decorative items. Its tempered glass top is robust and easy to clean.
- Enjoy the breathable mesh seating, which provides comfort and ventilation, especially in warmer weather.



# ATMUNGSAKTIVES NETZ

Sich trotz heißem Sommer kühl fühlen



Wasserdicht



Belüftung




Image: A close-up of the breathable mesh fabric used for the seating, emphasizing its air-permeable and waterproof qualities.



# TISCH AUS GEHÄRTETEM GLAS

Eine moderne Ergänzung für Ihren Garten



Leicht zu reinigen



Image: A close-up of the coffee table's tempered glass top, showing a cup of coffee and highlighting its easy-to-clean surface.

## MAINTENANCE

Proper care and maintenance will extend the lifespan of your Outsunny Garden Furniture Set.

### Cleaning:

- Wipe down the steel frame and mesh seating with a damp cloth.
- For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water.
- Clean the tempered glass tabletop with a glass cleaner or a damp cloth.
- Avoid using abrasive cleaners, harsh chemicals, or stiff brushes, as these can damage the surfaces.

### Storage and Protection:

- To extend the product's lifespan, it is highly recommended to use a furniture cover when the set is not in use,

especially during adverse weather conditions (heavy rain, snow, strong sun).

- During winter months or prolonged periods of non-use, store the furniture in a dry, sheltered area to protect it from extreme temperatures and moisture.

## TROUBLESHOOTING

This section addresses common issues you might encounter during assembly or use.

### Assembly Difficulties:

- **Difficulty fitting the seat support bar:** As noted in the assembly section, ensure the seat support bar is installed into the bench and chairs early in the assembly process, before the main frame is fully tightened. This is a common point where users find the instructions misleading.
- **Missing or damaged parts:** If you find any parts are missing or damaged upon unpacking, please contact customer support immediately.

### Stability Issues:

- **Wobbling furniture:** Ensure all screws and bolts are securely tightened. Check that the furniture is placed on a level surface.

## SPECIFICATIONS

Feature	Detail
Model Number	DE84G-207V00BK0431
Material	Mesh, Steel, Tempered Glass
Color	Black
Two-seater Sofa Dimensions (L x W x H)	111 cm x 70 cm x 75 cm
Single Chair Dimensions (W x D x H)	59 cm x 70 cm x 75 cm
Coffee Table Dimensions (L x W x H)	75 cm x 43 cm x 38.5 cm
Item Weight	25 Kilograms
Special Features	4-piece set, Waterproof, Breathable and cool, Stable steel frame, Tempered glass tabletop
Care Instructions	Wipe with a damp cloth

## **WARRANTY AND SUPPORT**

Outsunny products are designed for quality and durability. For any questions regarding your product, assembly, or if you encounter any issues, please contact your retailer or the manufacturer's customer service. Please retain your proof of purchase for any warranty claims.