

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [qimedo](#) /
- > [Qimedo Electric Spin Scrubber Q2 Pro User Manual](#)

qimedo YD-QJS1802

Qimedo Electric Spin Scrubber Q2 Pro User Manual

Model: YD-QJS1802

Brand: qimedo

1. PRODUCT OVERVIEW

The Qimedo Electric Spin Scrubber Q2 Pro is a high-power cordless cleaning brush designed for efficient cleaning of various surfaces such as bathtubs, tiles, floors, and showers. It features a powerful 1500 RPM motor, an effortless handle design, and a smart display for enhanced user experience.



Image: The Qimedo Electric Spin Scrubber Q2 Pro, showcasing its main unit, extension handle, two batteries, and a variety of included brush heads. The display shows power modes and battery level, and the brush head is depicted in action with water splashing.

Key Features:

- **High Power Motor:** Up to 1500 RPM with three modes (800 RPM/1000 RPM/1500 RPM) for effective cleaning.
- **Effortless Handle:** Reduces the perceived weight of the scrubber by 30% during use.
- **Smart Display:** Shows remaining power percentage and current power mode. Alerts when battery is below 25%.
- **Adjustable Handle:** Telescopic pole extends up to 50 inches, and the brush head can be adjusted 45° for

ergonomic cleaning.

- **8-in-1 Brush Heads:** Includes various brush types for different cleaning needs.
- **IPX7 Waterproof Design:** The brush head is fully sealed, allowing it to be submerged in water.
- **Dual Battery System:** Equipped with two removable 21V, 2000 mAh batteries for extended use.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Electric Floor Scrubber x 1
- 21V Battery x 2
- Charger x 1
- Replacement Brush Heads (4 soft bristle, 4 cloth) x 8
- Hook x 1
- User Manual x 1
- Brush Head Bag x 1



Image: An overhead view of the Qimedo Electric Spin Scrubber Q2 Pro, disassembled into its main components, alongside all the included brush heads and two batteries, illustrating the complete package contents.

3. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Qimedo Electric Spin Scrubber:

1. **Install the Brush Head:** Align and firmly attach the desired cleaning brush head to the main unit. Replace brush heads by pulling them off, not unscrewing.
2. **Connect Extension Handle (Front):** Align the extension handle with the main unit and tighten it securely.

3. **Connect Extension Handle (Other Side):** Align the other end of the extension handle with the battery handlebar and tighten it securely. Ensure proper alignment with the slightly raised rails inside the plastic connecting tubes.
4. **Install Batteries:** Insert a charged 21V battery into the battery compartment on the handlebar.



Image: A visual guide demonstrating the six steps for assembling the electric spin scrubber, including attaching the brush, connecting the extension handle sections, installing the battery, and powering on the device. Key components like the IPX7 waterproof brush head, retractable extension pole, smart display, and switch button are labeled.

4. OPERATING INSTRUCTIONS

Powering On/Off and Mode Selection:

- **Power On:** Long press the power button on the scrubber for 3 seconds to turn it on.
- **Mode Selection:** Single press the power button to switch between the three different power modes: Low (800 RPM), Mid (1000 RPM), and Max (1500 RPM).
- **Power Off:** Long press the power button for 3 seconds to turn it off.

Smart Display:

The smart display on the handle provides important information:

- The left side shows the percentage of power remaining (100%, 75%, 50%, 25%).
- The right side indicates the current power mode (Max, Mid, Low).
- When the power drops below 25%, the display will prompt you to recharge the battery.

1500 RPM Power Scrubber with Display

Effortless Handle makes the scrubber **30%** lighter than before when in use.

★ ★ ★
Effortless Handle

Battery Display:
100%/75%/50%/25%

Mode Display:
Max/Mid/Low

Long press 3-5s
to Power On



Total 3.43 lbs

Image: A user holding the Qimedo Electric Spin Scrubber, highlighting the 'Effortless Handle' design. An inset shows a close-up of the smart display, indicating battery percentage (100% Max, 75% Mid, 50% Low, 25%) and the power button, with text explaining to long press for 3-5 seconds to power on.

Adjusting the Handle and Brush Head:

- The telescopic pole can be adjusted to a maximum length of 50 inches to reach high or low areas without bending or stretching.
- The brush head can be adjusted up to 45° to clean various angles and surfaces effectively.

Adjustable Extended Handle



Image: A user cleaning a tiled wall with the Qimedo Electric Spin Scrubber, demonstrating the adjustable extended handle. Insets show the handle at various lengths (69cm/42.7in, 108cm/42.9in, 126cm/49.6in) and the brush head articulating up to 90 degrees for flexible cleaning angles.

Brush Head Selection and Usage:

The scrubber comes with 8 interchangeable brush heads to suit different cleaning tasks:

- **Big Flat Brush:** Ideal for flat floors.
- **Small Flat Brush:** Suitable for smaller flat surfaces.

- **Pointed Brush:** Designed for corners and narrow spaces.
- **Dome Brush:** Effective for corners and crevices.
- **Sponge Brush:** For glass cleaning and waxing.
- **Wool-like Brush:** Recommended for car polishing.
- **Scouring Brush:** For oily areas.
- **Big Cloth Brush:** For general floor cleansing.



Big Flat Brush
for flat floors



Small Flat Brush
for small flat



Pointed Brush
for corners and narrow space



Dome Brush
for corners and crevices



Sponge Brush
for glass cleansing, waxing



Wool-like Brush
for car polishing




Scouring Brush
for oily areas



Big Cloth Brush
for floor cleansing

8-in-1 Cleaning Brush



Spin scrubber



High cleaning power



Easy to use



Works great



(e.g., Big Flat Brush for flat floors, Pointed Brush for corners). Below, a collage of images shows the scrubber being used in various scenarios, such as cleaning a car, bathtub, sink, stove, and window.

5. CHARGING AND BATTERY INFORMATION

The Qimedo Electric Spin Scrubber is powered by a removable 21V, 2000 mAh lithium-ion battery. Two batteries are included to ensure continuous operation.

- **Charging Time:** A fully depleted battery charges in approximately 100 minutes (about 2 hours).
- **Operating Time:** A fully charged battery can provide up to 120 minutes of continuous operation in Mid speed mode.
- **Dual Battery Advantage:** With two batteries, you can use one while the other charges, minimizing downtime.



Image: A close-up of the 21V battery connected to its charger, which is plugged into a wall outlet. A red indicator light on the charger signifies that charging is in progress. Text indicates '2000 mAh battery' and 'Charge 2 hours'.

6. MAINTENANCE AND CARE

Cleaning the Brush Head:

The scrubber brush head features an IPX7 waterproof design, meaning it is completely sealed and can be submerged in water for thorough cleaning. After use, remove the brush head and rinse it under running water to remove any debris or cleaning solution residue.

IPX7 Waterproof Brush Head

Features: Put the whole brush head into the water, Don't worry about damage.



Image: The Qimedo Electric Spin Scrubber's brush head is shown submerged in water, demonstrating its IPX7 waterproof capability. Additional images show the scrubber being used to clean a sink and a bathtub, emphasizing its suitability for wet environments.

Battery Care:

- Always remove the battery from the scrubber when not in use or when storing for extended periods to preserve battery life and for safety.
- Store batteries in a cool, dry place.

Storage:

The included hook can be mounted in a corner or on a wall for convenient storage of the scrubber. The brush head bag provides a tidy way to store the various brush attachments.



Image: A close-up view of the Qimedo Electric Spin Scrubber handle, showing a yellow wall-mounted hook designed for convenient storage. The hook is positioned to hold the scrubber upright against a wall.

7. TROUBLESHOOTING

- **Scrubber Not Working (after pressing too hard):** If the scrubber stops working after applying excessive pressure, separate the battery from the scrubber, then reinstall the battery. Press and hold the power button for 3 seconds to restart the device.
- **Stubborn Stains:** For optimal cleaning of stubborn stains, it is recommended to soak the area in detergent for 3-5 minutes before using the scrubber.

8. SPECIFICATIONS

Feature	Specification
Brand	qimedo
Model Number	YD-QJS1802
Color	White
Handle Material	Metal, Plastic
Product Dimensions	51.57"L x 8.07"W x 3.15"H
Item Weight	6.23 pounds (2.83 Kilograms)
Special Feature	1500 rpm high power electric spin scrubber, battery powered, cordless, smart display, 8 brushes, IPX7 waterproof
Battery Type	21V Lithium Ion (2 included)
Battery Capacity	2000 mAh
Charging Time	Approx. 100 minutes
Continuous Working Time	Up to 120 minutes (Mid speed mode)
Handle Length	Adjustable up to 50 inches
Brush Head Adjustment	Up to 45°

9. WARRANTY AND SUPPORT

The Qimedo Electric Spin Scrubber Q2 Pro comes with a **2-year warranty**. For any product, order, or logistics issues, please contact the qimedo team for assistance. They offer 24-hour full-time after-sales service.

For further support, you may visit the official qimedo store on Amazon: [qimedo Store](#)