



Manuals.plus /

› Casaria /

› Casaria Folding Garden Chairs Instruction Manual - Model B0CSYVQM7P

Casaria B0CSYVQM7P

Casaria Folding Garden Chairs Instruction Manual

Model: B0CSYVQM7P

1. INTRODUCTION

Thank you for choosing Casaria Folding Garden Chairs. These chairs are designed for comfort, durability, and convenience, suitable for various outdoor and indoor settings such as gardens, balconies, terraces, and even compact kitchens. They feature a robust powder-coated steel frame and a weather-resistant, breathable fabric seat. The chairs are lightweight, easy to fold, and come fully assembled, ready for immediate use.

This manual provides essential information for the safe and effective use, maintenance, and care of your Casaria Folding Garden Chairs.

2. SETUP

Your Casaria Folding Garden Chairs arrive fully assembled. Setup primarily involves unfolding the chairs for use.

- Unfolding the Chair:** Carefully remove the chair from its packaging. Hold the chair by the top of the backrest and the front edge of the seat. Gently pull the backrest and seat apart until the chair fully extends and locks into its open position. Ensure all four legs are firmly on the ground and the chair is stable before use.
- Folding the Chair for Storage:** To fold, lift the seat slightly and push the backrest towards the front legs. The chair will collapse into a compact, flat form. This allows for easy storage in small spaces.



Image: The chair in unfolded and folded states, highlighting its space-saving design and ease of handling. A person is shown carrying the folded chair.

3. OPERATING INSTRUCTIONS

The Casaria Folding Garden Chair is designed for straightforward use and comfort.

- **Seating:** Once unfolded and stable, the chair provides a comfortable and supportive seating surface. The high backrest is designed to promote correct posture.
- **Weight Capacity:** The chair is built to support a maximum load of 130 kg (approximately 286 lbs). Do not exceed this weight limit to ensure safety and product longevity.
- **Placement:** These chairs are suitable for both indoor and outdoor environments. When used outdoors, their weather-resistant materials ensure durability against various elements.




Image: Detailed view of the seating surface, illustrating features such as correct back posture support, breathable elastic fabric, and weather-resistant, easy-to-clean materials.

4. MAINTENANCE

Proper maintenance will extend the life and appearance of your Casaria Folding Garden Chairs.

- **Cleaning:** The chairs are easy to clean. Simply wipe down the frame and fabric with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with a clean damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the materials.
- **Drying:** After cleaning, allow the chairs to air dry completely before folding and storing them to prevent mildew or corrosion.
- **Storage:** When not in use for extended periods, especially during harsh weather conditions, it is recommended to fold the chairs and store them in a dry, protected area to preserve their condition.
- **Inspection:** Periodically check all frame connections and components to ensure they are secure.




SOLIDA SUPERFICIE DI SEDUTA



Postura corretta della schiena **grazie al sostegno rialzabile**



Tessuto traspirante elastico



Materiali facili da pulire resistenti alle intemperie

Image: Close-up details of the powder-coated steel frame and anti-scratch floor protectors, emphasizing durability and stability.

5. TROUBLESHOOTING

Most issues with these chairs are minor and easily resolved.

- **Chair feels unstable:** Ensure the chair is fully unfolded and locked into position. Check that all four legs are on a flat, even surface. Verify that the anti-scratch floor protectors are intact and properly seated on each leg.
- **Difficulty folding/unfolding:** Ensure there are no obstructions in the folding mechanism. Apply gentle, even pressure. If the mechanism feels stiff, ensure it is clean and free of debris. Do not force the chair to fold or unfold.
- **Fabric appears stained:** Refer to the cleaning instructions in the Maintenance section. Act quickly to clean spills to prevent permanent staining.

6. SPECIFICATIONS

Brand	Casaria
Model	B0CSYVQM7P
Color	Grey
Material (Frame)	Powder-coated Steel Alloy
Material (Seat)	Polyester
Dimensions (H x W x D)	80 x 46 x 50 cm (31.5 x 18.1 x 19.7 inches)
Seat Height	47 cm (18.5 inches)
Item Weight	2.7 kg (5.95 lbs) per chair
Maximum Recommended Weight	130 kg (286 lbs)
Assembly Required	No (Ships fully assembled)
Special Features	Lightweight, Foldable, Weather-resistant

SALVASPAZIO E MANEGGEVOLI



Le sedie si piegano in modo facile e veloce. In più, si trasportano senza fatica grazie ai 2,7 kg di peso della singola sedia.

-  **Disponibili in set da 2 o da 4 pz**
-  **Adatti a interni ed esterni**
-  **Per la terrazza, il campeggio, il balcone e la cucina**

Image: Detailed dimensions of the Casaria folding garden chair, including height, width, and seat measurements, along

with key features.

7. WARRANTY

Casaria products are manufactured to high-quality standards. For specific warranty information regarding your Casaria Folding Garden Chairs, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

8. SUPPORT

If you have any questions, require assistance, or encounter issues not covered in this manual, please contact Casaria customer support or your retailer. Please have your product model number (B0CSYVQM7P) and purchase details ready when contacting support.