Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Csasan V90

Csasan V90 Wireless Earbuds User Manual

Model: V90 | Brand: Csasan

1. Introduction

Thank you for choosing the Csasan V90 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features for active lifestyles. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

2. What's in the Box

Verify that all items are present in your package:

- 2x Sports earbuds
- 3x pairs of eartips (S/M/L)
- 1x Type C Charging box
- 1x USB-C Charging cable
- 1x Detailed user manual



Image showing the Csasan V90 Wireless Earbuds, charging case, USB-C cable, and three sizes of ear tips (S, M, L) included in the package.

3. Setup

3.1 Initial Charging

Before first use, fully charge the charging case and earbuds.

1. Connect the provided USB-C charging cable to the charging port on the case.
2. Plug the other end into a compatible USB power adapter (not included).
3. The LED display on the case will show the charging progress. A full charge typically takes about 1.5 hours for the case.
4. Place the earbuds into the charging case. The earbuds will automatically begin charging. Their individual charge levels will be displayed on the case.



The charging case for the Csasan V90 earbuds displaying battery levels for both the case and individual earbuds, indicating USB-C charging capability and 48 hours of total playtime.

3.2 Pairing with Your Device

The Csasan V90 earbuds feature one-step auto-pairing for convenience.

1. Ensure the earbuds are fully charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings.
4. Search for "V90" in the list of available devices and select it to connect.
5. Once connected, you will hear an audible confirmation, and the earbuds will be ready for use.
6. For subsequent uses, simply open the charging case, and the earbuds will automatically connect to the last paired device.



Illustration showing the automatic pairing process of the Csasan V90 earbuds with a smartphone upon opening the charging case, compatible with iOS, Android, and Windows devices.

Official video demonstrating the features and pairing process of the Csasan V90 Wireless Earbuds.

4. Operating Your Earbuds

4.1 Wearing the Earbuds

The ergonomic design with earhooks ensures a secure and comfortable fit, especially during sports activities.

1. Select the ear tips (S/M/L) that best fit your ear canal for optimal sound and comfort.
2. Insert the earbud into your ear.
3. Gently place the earhook over the back of your ear, adjusting it until it feels secure and comfortable.



A person wearing the Csasan V90 earbuds during a workout, highlighting the ergonomic design, flexible ear hooks, and three included ear tip sizes for a comfortable and secure fit.

4.2 Smart Touch Controls

The earbuds feature intuitive touch controls for easy management of music and calls.

Function	Left Earbud	Right Earbud
Play/Pause Music	Tap Twice	Tap Twice
Previous Track	Press and Hold 2s	-
Next Track	-	Press and Hold 2s
Volume Down	Tap Once	-
Volume Up	Tap Once	Tap Once
Answer/End Call	Tap Once	Tap Once

Function	Left Earbud	Right Earbud
Reject Call	Press and Hold 2s	Press and Hold 2s
Activate Voice Assistant	Tap 3 Times	Tap 3 Times



Diagram illustrating the various smart touch controls on the Csasan V90 earbuds, including play/pause, previous/next track, volume control, answer/hang up calls, and voice assistant activation.

4.3 Audio Features

- **3D Stereo Sound:** Equipped with 13mm diaphragm speaker drivers, these earbuds provide a powerful and wide sound range for crisp audio and deep bass.
- **Crystal Clear Calls:** CVC8.0 noise reduction technology monitors and suppresses environmental noise in real-time, ensuring uninterrupted listening and clear conversations.



An exploded view diagram of the Csasan V90 earbud highlighting its 13mm drivers, Bass+ technology, Bluetooth 5.3 chip, and support for HFP&A2DP for Hi-Fi stereo sound.

5. Maintenance

5.1 Cleaning

Regular cleaning helps maintain sound quality and extends the lifespan of your earbuds.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- Use a dry cotton swab to clean the charging contacts on both the earbuds and the case.

5.2 Waterproofing (IP7 Rating)

The Csasan V90 earbuds have an IP7 waterproof rating, making them resistant to sweat, rain, and minor water splashes.

They are suitable for exercise and running.

- Do not submerge the earbuds in water for extended periods.
- Ensure the charging port is dry before charging to prevent damage.
- After exposure to sweat or rain, wipe the earbuds dry before placing them back in the charging case.



The Csasan V90 Wireless Earbuds and their charging case, showcasing their sleek black design and digital battery display.

6. Troubleshooting

If you encounter issues with your Csasan V90 earbuds, try the following solutions:

6.1 Pairing Issues

- **Earbuds not pairing:** Ensure Bluetooth is enabled on your device and the earbuds are within range. Turn off and on your device's Bluetooth, then try re-pairing.
- **Only one earbud connecting:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. This often re-syncs them.

6.2 Sound Issues

- **No sound or low volume:** Check the volume levels on both your device and the earbuds. Ensure ear tips are properly seated in your ear canal.
- **Distorted sound:** Move closer to your device to reduce interference. Ensure earbuds are fully charged.

6.3 Charging Issues

- **Earbuds not charging:** Ensure the charging contacts on both the earbuds and the case are clean and dry. Check if the charging cable is securely connected.
- **Case not charging:** Try a different USB-C cable or power adapter. Ensure the charging port on the case is free of debris.

6.4 Call Quality Issues

- **Poor microphone quality:** Ensure the microphone is not obstructed. Move to a quieter environment if there is excessive background noise.

7. Specifications

Feature	Detail
Model Name	V90
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Battery Life (Earbuds)	8 Hours
Total Playtime (with Charging Case)	48 Hours
Charging Time (Case)	1.5 Hours
Water Resistance Level	IP7 Waterproof
Control Method	Touch
Audio Driver Size	13 Millimeters
Earpiece Shape	Over Ear
Compatible Devices	Most devices with Bluetooth

8. Warranty and Support

Csasan offers a 2-year warranty on this product. For any support inquiries, please refer to the contact information provided in the original packaging or visit the official Csasan store on Amazon.
Official User Guide (PDF): Download PDF

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CSYWR1R2

More documents and user manuals: **https://manuals.plus/**