

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Wielio](#) /

> [Wielio Native 1080P Full HD Projector \(Model B0CSYX5BYQ\) Instruction Manual](#)

Wielio B0CSYX5BYQ

Wielio Native 1080P Full HD Projector (Model B0CSYX5BYQ) Instruction Manual

Your guide to setting up, operating, and maintaining your projector.

INTRODUCTION

Thank you for choosing the Wielio Native 1080P Full HD Projector. This manual provides essential information to help you get the most out of your device. Please read it thoroughly before use and keep it for future reference.



Image: Overview of the Wielio Native 1080P Full HD Projector's key features, including its native 1080P resolution, 12000 lumens brightness, 5G WiFi, Bluetooth 5.1, support for up to 200-inch projection, and a lamp life of 50,000 hours.

IMPORTANT SAFETY INSTRUCTIONS

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation around the projector to prevent overheating.
- Keep the projector away from water or other liquids.
- Use only the power adapter provided with the projector.
- Do not attempt to repair the projector yourself. Contact qualified service personnel.

PACKAGE CONTENTS

Please check that all items are present in your package:

- Wielio Native 1080P Full HD Projector
- Power Cable
- Remote Control
- HDMI Cable
- User Manual
- (Optional: Projection Screen, Tripod - depending on package)

SETUP GUIDE

1. Powering On

1. Connect the power cable to the projector's power input port.
2. Plug the power cable into a wall outlet.
3. Press the power button on the projector or the remote control to turn on the device.

Your browser does not support the video tag.

Video: Demonstrates connecting the power cable and powering on the projector, followed by a projection of a snowboarder on a large screen. This video also shows the various input ports on the back of the projector.

2. Placement and Projection

The projector offers flexible placement options to suit your viewing environment.

- **Table Placement:** Place the projector on a stable, flat surface.
- **Tripod Installation:** Use the tripod mounting hole on the bottom of the projector to attach it to a compatible tripod.
- **Ceiling Mount:** The projector can also be mounted to the ceiling using a compatible ceiling mount (sold separately).




Image: Illustrates various ways to position the projector, including on a table, mounted on a tripod, or suspended from the ceiling, to achieve optimal projection.

Adjust the distance between the projector and the screen to achieve your desired screen size. The projector supports projection sizes up to 200 inches.



Image: Demonstrates the relationship between projection distance and screen size, showing how to achieve 40-inch, 100-inch, and 200-inch displays.

3. Focus Adjustment

To ensure a clear image, adjust the focus using the remote control.

1. Turn on the projector and display an image.
2. Use the "F-" and "F+" buttons on the remote control to sharpen the image until it is clear.

Your browser does not support the video tag.

Video: Shows the projector displaying its main menu and demonstrates how to adjust the focus using the F- and F+ buttons on the remote control.

OPERATING INSTRUCTIONS

1. Connectivity Options

The projector supports various input sources:

- **HDMI:** Connect devices like laptops, gaming consoles (PS5), or streaming sticks (Fire Stick) using an HDMI cable.
- **USB:** Play media directly from a USB drive.
- **AV:** Connect older devices using an AV cable.
- **Wi-Fi:** Mirror your smartphone or tablet screen wirelessly.
- **Bluetooth:** Connect external Bluetooth speakers for enhanced audio.

Your browser does not support the video tag.

Video: Illustrates the various input ports on the projector, including HDMI, USB, and AUX, highlighting its multi-device connectivity. It also shows the projector in use for home theater, gaming, and screen mirroring.

2. Wireless Screen Mirroring (Wi-Fi Projection)

Mirror your iOS or Android device screen to the projector wirelessly:

1. Ensure your projector and smartphone are connected to the same Wi-Fi network.
2. Select the "Screen Mirroring" or "Wi-Fi Projection" option on the projector's menu.
3. On your smartphone, enable screen mirroring (e.g., "Screen Cast" on Android, "Screen Mirroring" on iOS Control Center) and select the projector from the list of available devices.



Image: Depicts the 5G WiFi mirrored screen connection feature, showing a smartphone, tablet, and laptop wirelessly connected to the projector, displaying the same content.

3. Bluetooth Audio Connection

Connect external Bluetooth speakers for a more immersive audio experience:

1. Turn on your Bluetooth speaker and set it to pairing mode.
2. On the projector's menu, navigate to the Bluetooth settings.
3. Select your Bluetooth speaker from the list of available devices to pair.



Image: Illustrates the Bluetooth 5.1 connection, showing the projector wirelessly paired with an external speaker for enhanced sound.

4. Using the Remote Control

The remote control allows you to navigate the projector's interface, adjust settings, and control media playback. Key functions include:

- **Power Button:** Turns the projector on/off.
- **Navigation Buttons (Up/Down/Left/Right):** Move through menu options.
- **OK Button:** Confirms selections.
- **Source Button:** Selects input sources (HDMI, USB, AV, Wi-Fi).
- **Volume Buttons (+/-):** Adjusts audio volume.
- **F-/F+ Buttons:** Adjusts image focus.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your projector.

1. Cleaning the Lens

- Use a soft, lint-free cloth specifically designed for optical lenses.
- Gently wipe the lens in a circular motion to remove dust or smudges.
- Avoid using abrasive cleaners or excessive force.

2. Cleaning the Projector Body

- Wipe the exterior of the projector with a soft, dry cloth.
- Do not use liquid cleaners directly on the projector.

3. Ventilation

- Ensure that the projector's ventilation openings are not blocked.
- Allow sufficient space around the projector for air circulation to prevent overheating.

TROUBLESHOOTING

If you encounter issues with your projector, refer to the following common problems and solutions:

No Image on Screen

- **Check Power:** Ensure the projector is properly connected to a power source and turned on.
- **Input Source:** Verify that the correct input source (HDMI, USB, Wi-Fi) is selected on the projector.
- **Cable Connection:** If using HDMI or AV, ensure cables are securely connected to both the projector and the source device.

Blurry Image

- **Adjust Focus:** Use the "F-" and "F+" buttons on the remote control to adjust the focus until the image is clear.
- **Projection Distance:** Ensure the projector is within the recommended projection distance for the screen size.
- **Lens Cleanliness:** Clean the projector lens if it appears dirty.

No Sound

- **Volume Level:** Check the volume settings on both the projector and the source device.
- **Audio Output:** If using external speakers, ensure they are properly connected (via Bluetooth or AUX) and powered on.
- **Source Device Audio:** Verify that the audio output on your source device is not muted or set to an incorrect output.

Wi-Fi/Bluetooth Connectivity Issues

- **Restart Devices:** Try restarting the projector, your smartphone/tablet, and your Wi-Fi router/Bluetooth speaker.
- **Proximity:** Ensure the devices are within range for Wi-Fi or Bluetooth connection.
- **Network Check:** For Wi-Fi, ensure your network is working correctly and the password is entered correctly.

SPECIFICATIONS

Feature	Detail
Brand	Wielio
Model Number	B0CSYX5BYQ
Connectivity Technology	Bluetooth, USB, Wi-Fi
Display Resolution	1920 x 1080 (Native 1080P)
Display Type	DLP
Item Weight	2.92 pounds
Product Dimensions	7.5 x 9 x 7.5 inches
First Available	January 22, 2024

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Wielio customer service through their official website or the retailer where you purchased the product.