

[Manuals.plus](#) /

> [YONISEE](#) /

> YONISEE AMY-01 Lift Recliner Chair with Massage and Heat User Manual

YONISEE AMY-01

YONISEE AMY-01 Lift Recliner Chair User Manual

Model: AMY-01 | Brand: YONISEE

INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your YONISEE AMY-01 Lift Recliner Chair. Please read this manual thoroughly before using the product and retain it for future reference.



Image: The YONISEE Lift Recliner Chair in a relaxed position, demonstrating its comfort and design.

SAFETY INSTRUCTIONS

- Ensure all components are securely assembled before use.
- Keep hands and feet clear of the chair's moving parts during operation.
- Do not allow children or pets to play on or around the chair, especially during movement.
- Place the chair on a level, stable surface.
- Do not exceed the maximum weight capacity of 150 kg (330 lbs).
- Only use the provided power adapter and remote control.
- Disconnect power before cleaning or performing maintenance.
- USB ports are for low-power devices only (e.g., phones, headsets). Do not attempt to charge high-power devices.

PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. The chair typically arrives in multiple boxes.

- Chair Base

- Backrest
- Armrests (Left and Right)
- Power Adapter
- Remote Control
- Arm Pads (Included Components)
- Cushion (Included Components)

ASSEMBLY INSTRUCTIONS

Assembly typically requires two people due to the weight of some components. No tools are generally needed.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Armrests:** Slide the armrests onto the sides of the chair base until they click securely into place. Ensure they are fully seated but not pushed too far, which could impede movement.
3. **Install Backrest:** Align the backrest with the slots on the chair base and push down firmly until it locks into position.
4. **Connect Cables:** Connect the power cable from the chair to the power adapter, and then plug the adapter into a wall outlet. Connect the remote control cable to the designated port on the chair.
5. **Final Check:** Ensure all connections are secure and the chair is stable before initial use.



Sturdy Steel Frame

Help seniors sit and stand easily

Sturdy Frame

Ergonomic design

Lift Up

Recliner

Image: Illustration of the chair's sturdy steel frame and the adjustable recline mechanism, highlighting its robust construction.

OPERATING INSTRUCTIONS

Lift and Recline Functions

The chair features a heavy-duty motor for smooth lift and recline operations. Use the remote control to adjust the chair's position.

- **Lift Function:** Press the 'Lift' button on the remote to gently raise the chair, assisting users in standing up without strain on knees or back. The chair can tilt forward by approximately 30 degrees for easy exit.
- **Recline Function:** Press the 'Recline' button to move the chair into various reclining positions, up to 140 degrees. This allows for comfortable reading, watching TV, or napping.
- **Adjustable Positions:** The chair offers three main positions: upright (for easy entry/exit), working/reading (standard seated), and reclined (for relaxation).



Image: Visual representation of the chair's three primary positions: assisting with standing, standard seating, and full recline for rest.

Massage and Heat Functions

The integrated massage and heat functions are controlled via the remote.

- **Massage Points:** The chair features 8 vibration massage points targeting the neck, back, thighs, and lumbar regions.
- **Lumbar Heating:** A lumbar heating function provides warmth to the lower back area.
- **Remote Control:** Use the dedicated buttons on the remote to activate, adjust intensity, and select massage modes and heat settings.

Easy to use it with remote



Image: The remote control and a diagram illustrating the massage points and heat function within the chair.

Convenience Features

The chair includes several features for user convenience.

- **USB Port:** An integrated USB outlet allows for charging low-power devices such as smartphones or headsets.
- **Cup Holders:** Two cup holders are built into the armrests for beverages.
- **Side Pockets:** Two side pockets provide storage for remotes, magazines, or other small items.

Comfort and convenience



2 Cup Holders



USB Ports+Type C Ports



2 Side Pockets

Image: The chair's convenience features, including cup holders, USB ports, and side storage pockets.

MAINTENANCE

- **Cleaning:** For general cleaning, wipe the fabric surface with a damp cloth. For tougher stains, use a mild upholstery cleaner according to its instructions. Do not use harsh chemicals or abrasive cleaners.
- **Power Disconnection:** Always unplug the chair from the power outlet before cleaning or moving it.
- **Inspection:** Periodically check all connections and moving parts for wear or damage. If any issues are found, discontinue use and contact customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not move or power on.	Power cord disconnected; remote control not connected; power outlet not working.	Ensure power cord is securely plugged into chair and outlet. Check remote control connection. Test outlet with another device.

Problem	Possible Cause	Solution
Massage/Heat function not working.	Remote control issue; function not activated.	Ensure chair is powered on. Press the correct buttons on the remote to activate massage/heat.
Chair movement is jerky or noisy.	Loose connections; obstruction in mechanism.	Check all assembly connections. Ensure no objects are obstructing the lift or recline mechanism. Contact support if issue persists.
USB port not charging devices.	Device requires too much power; cable issue; chair not powered.	Ensure device is low-power. Try a different USB cable. Verify chair is powered on.

SPECIFICATIONS

Brand	YONISEE
Model Number	AMY-01-Brown
Color	Brown
Size	Large Recliner Armchair
Frame Material	Alloy Steel
Special Features	Side Pocket, Massage, Heat, USB Port, Cup Holders, Extended Footrest
Recommended Height	150CM-185CM
Maximum Weight Recommendation	150 Kilograms (330 LBS)
Item Dimensions (L x W x H)	30.2 x 35.43 x 38.46 inches
Seat Back Interior Height	66 Centimeters
Seat Depth	53.34 Centimeters
Required Assembly	Yes
UPC / GTIN	659467459830



Height

150-183cm



Weight

330LBS



Image: Comprehensive dimensions and specifications of the YONISEE Lift Recliner Chair.

WARRANTY INFORMATION

Specific warranty details are not provided in the available product information. Please refer to your purchase documentation or contact the retailer for warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your YONISEE Lift Recliner Chair, please contact the retailer or manufacturer directly. Contact information may be available on your purchase receipt or the product packaging.