



Manuals.plus /

› Whubefy /

› Whubefy 18x8.2FT Inflatable Obstacle Course Bounce House User Manual (Model: XD5162B)

Whubefy XD5162B

Whubefy 18x8.2FT Inflatable Obstacle Course Bounce House User Manual (Model: XD5162B)

Comprehensive guide for setup, operation, maintenance, and safety.

1. INTRODUCTION

This manual provides essential instructions for the safe and proper use of your Whubefy 18x8.2FT Inflatable Obstacle Course Bounce House, Model XD5162B. Please read all instructions carefully before setup and operation to ensure maximum enjoyment and safety for all users.



Image 1: The Whubefy 18x8.2FT Inflatable Obstacle Course Bounce House, showcasing its vibrant colors and various play elements including slides, tunnels, and climbing areas.

2. IMPORTANT SAFETY INFORMATION

Adherence to these safety guidelines is crucial to prevent injury and ensure a safe play environment.

- **Adult Supervision:** Guardianship is required for children under the age of three. Continuous adult supervision is mandatory for all children using the bounce house.
- **Clearance Area:** Ensure sufficient, flat, and sharp-object-free space around the bounce house for safety.
- **Blower Operation:** The blower must continuously run to keep the bounce house inflated. Small amounts of air leakage at the seams are intentional and necessary for continuous airflow, preventing overinflation. Do not turn off the blower during use.
- **Weight Limits:** The maximum weight recommendation for the unit is 400 pounds. A maximum user weight of 90 lbs per child is recommended, considering the force area and size. Suitable for 2-5 children simultaneously.
- **Material Safety:** Constructed with 0.4mm vinyl and 420D+840D puncture-resistant material. Features 3-sided mesh safety nets, heightened handrail slide, extended cushion landing, and flame-resistant material.
- **Securing the Unit:** Always use the provided ground stakes to secure the bounce house firmly to the ground, especially in windy conditions.

3. WHAT'S IN THE BOX

Your Whubefy Inflatable Obstacle Course Bounce House package includes:

- 1 x Inflatable Obstacle Bounce House
- 1 x 680W Blower
- 8 x Bouncer Stakes
- 4 x Blower Stakes
- 1 x Storage Bag
- 12 x Repair Patches
- 4 x Patchlines
- 1 x Instruction Manual



Image 2: A visual representation of the included components: the deflated bounce house, 680W blower, ground stakes, repair patches, and storage bag.

4. SETUP INSTRUCTIONS

Follow these steps for quick and easy setup:

1. **Unpack:** Remove the bounce house from its storage bag and unroll it on a flat, clear surface free of sharp objects.
2. **Position:** Lay the bounce house flat, ensuring the air intake tube is extended towards the blower's location.

3. **Connect Blower:** Attach the air intake tube securely to the 680W air blower. Ensure all other air outlets are closed or tied off as instructed.
4. **Inflate:** Plug in the blower and turn it on. The bounce house will inflate rapidly, typically within 2 minutes.
5. **Secure:** Once fully inflated, use the provided bouncer stakes to anchor the bounce house to the ground at designated points. Use blower stakes to secure the blower.

Your browser does not support the video tag.

Video 1: Official Whubefy demonstration of the quick and easy setup process for the inflatable obstacle course.

5. OPERATING INSTRUCTIONS

The Whubefy Obstacle Course Bounce House offers multiple play features for engaging fun:

- **Dual-Racer Slide:** Children can race down the 3.5-foot high dual slide.
- **Crawling Tunnels:** Navigate through two inflatable tunnels.
- **Climbing Walls:** Challenge themselves on two climbing walls with handholds.
- **Spacious Bounce Area:** Enjoy free bouncing within the designated area.
- **Obstacle Elements:** Dodge and interact with various inflatable obstacles throughout the course.

This unit is designed for children aged 3-12 years. Always ensure children are playing safely and within the recommended weight limits.



Image 3: Kids enjoying the obstacle course, highlighting the tunnels, climbing walls, and spacious bouncing area.

Your browser does not support the video tag.

Video 2: A preview video showcasing the large bounce house obstacle course in action with children playing.

6. MAINTENANCE AND STORAGE

- **Cleaning:** Clean the bounce house with a damp cloth and mild soap. Ensure it is completely dry before storage to prevent mold and mildew.
- **Deflation:** To deflate, turn off the blower and disconnect it from the air intake tube. The unit will deflate quickly.
- **Folding:** Fold the deflated bounce house neatly to minimize its size.
- **Storage:** Place the folded bounce house into the provided storage bag. Store in a cool, dry place, such as a closet, under a bed, or in a garage.
- **Repairs:** Use the included repair patches for minor punctures. Follow the instructions provided with the patches for proper application.

7. TROUBLESHOOTING

- **Bounce House Not Inflating Fully:**
 - Ensure the blower is continuously running and properly connected.
 - Check that all air outlets are securely closed or tied off.
 - Verify there are no large tears or punctures. Small air leakage from seams is normal.
- **Air Leakage from Seams:** This is normal and intentional. It allows for continuous airflow, which is necessary to keep the product inflated and prevents overinflation. Do not attempt to seal these seams.
- **Unit Moving During Use:** Ensure the bounce house is properly anchored to the ground using all provided stakes. Re-check stake placement if movement occurs.

8. SPECIFICATIONS

Feature	Detail
Brand	Whubefy
Model Number	XD5162B
Inflated Dimensions (L x W x H)	18' x 8.2' x 7.0' (151.68"L x 107.88"W x 69.9"H)
Item Weight	48 Pounds
Maximum Weight Recommendation	400 Pounds (Unit), 90 lbs (Per User)
Number of Players	2-5
Age Range (Recommended)	36 months - 10 years (Little And Big Kid)
Material	0.4mm Vinyl, 420D+840D Puncture-Resistant Fabric
Blower Wattage	680W
UPC	066195425127, 661954251278



Image 4: Detailed product dimensions for the Whubefy Inflatable Obstacle Course Bounce House.

9. WARRANTY AND SUPPORT

All Whubefy Inflatable Bounce Houses come with a **180-day limited warranty** covering manufacturing defects. For any questions, concerns, or warranty claims, please contact Whubefy customer support through your purchase platform.