



[Manuals.plus](#) /

> [Whubefy](#) /

> Whubefy Inflatable Bounce House Instruction Manual

Whubefy XD5162C

Whubefy Inflatable Bounce House Instruction Manual

Model: XD5162C

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before setting up and using the Whubefy Inflatable Bounce House. Failure to follow these instructions may result in serious injury.

- Guardianship is required for children under the age of three.
- Ensure sufficient, flat, and sharp-object-free space for safety.
- The blower must continuously be running, and the bouncer's seams will let small amounts of air out to ensure it would not overinflate. This air leakage is normal and necessary for continuous airflow.
- Maximum weight on inflated area: 300 lbs. Individual weight limit: 100 lbs.
- Accommodates 3-5 children simultaneously.
- Recommended age: 36 months - 8 years.



Figure 1: Whubefy Inflatable Bounce House with multiple play areas.

SETUP INSTRUCTIONS

Setting up your Whubefy Inflatable Bounce House is quick and easy, typically taking only 60 seconds for inflation.

1. **Unpack and Expand:** Remove the bounce house from its storage bag and unroll it in the desired location. Ensure the area is clear of sharp objects and is flat.
2. **Connect Blower:** Attach the powerful 350W electric blower to the inflation tube of the bounce house. Ensure a secure connection.
3. **Inflate:** Plug in the blower and turn it on. The bounce house will rapidly inflate within approximately 60 seconds.
4. **Secure with Stakes:** Once fully inflated, use the provided 6 bouncer stakes to securely anchor the bounce house to the ground. Use the 4 blower stakes to secure the blower.
5. **Continuous Airflow:** Remember to keep the blower on continuously during use to maintain inflation.



Figure 2: Quick Inflation Steps for the Whubefy Bounce House.

OPERATING INSTRUCTIONS

The Whubefy Inflatable Bounce House offers multiple play areas designed for engaging and active fun.

- **Jumping Area:** The large central area is designed for jumping and bouncing. Ensure children remove shoes and any sharp objects from their pockets before entering.
- **Double Slide:** The bounce house features two slides for sliding competitions. Children should slide down feet first. Raised handrails and cushioning at the bottom enhance safety.
- **Central Obstacle:** A fun central obstacle allows children to crawl through and exercise their flexibility.
- **Mesh Safety Netting:** The surrounding mesh netting provides a safe enclosure, preventing falls while allowing visibility.
- **Storage Net:** Utilize the integrated storage net to keep shoes, hats, and other small items secure while children play.



Figure 3: Children enjoying the multiple play areas of the bounce house.



Figure 4: The Whubefy Bounce House is suitable for both indoor and outdoor use.

MAINTENANCE

Proper maintenance will extend the life of your Whubefy Inflatable Bounce House.

- **Cleaning:** After use, wipe down the surface of the bounce house with a damp cloth and mild soap if necessary. Ensure it is completely dry before folding and storing to prevent mold and mildew.
- **Storage:** Deflate the bounce house completely, fold it neatly, and place it back into the provided carry bag. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Puncture Repair:** The bounce house is made from durable 0.4mm vinyl and 420D + 840D puncture-resistant material. In case of small punctures, use the included repair patches and patchlines to mend the affected area. Follow the instructions provided with the repair kit.
- **Blower Care:** Keep the blower clean and free from debris. Ensure air vents are not blocked during operation.

840D OXFORD CLOTH SAFER & DURABLE

- ✓ Stronger load-bearing capacity
- ✓ Durable and non-cracking

840D Oxford Cloth

Adhesive Layer

PVC Coating PVC

840D Oxford cloth easily cope with scratches, not cracking

Easily cracked, easily decoupled, not load-bearing

- Waterproof
- Wear-resistant
- Not easy to fade
- Tearresistant

Mesh Netting Wall

Double Stitched

Enhanced Handrails

Multiple Belts

Figure 5: Durable construction and safety features of the bounce house materials.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Solution
Bounce house not fully inflating or losing air.	<p>Ensure the blower is continuously running and plugged in.</p> <p>Check for any large tears or punctures. Use the provided repair patches for small holes.</p> <p>Verify that all inflation tubes are securely attached to the blower and that no air is escaping from connections.</p> <p>Note: Slight air leakage at the seams is normal and necessary to prevent over-inflation.</p>
Blower not turning on.	<p>Check the power outlet and ensure the blower is properly plugged in.</p> <p>Inspect the power cord for any damage.</p>

Problem	Solution
Bounce house unstable during use.	Ensure all ground stakes (6 for bouncer, 4 for blower) are properly inserted and secured. Verify the setup surface is flat and level.

SPECIFICATIONS

Feature	Detail
Model Number	XD5162C
Inflated Size (L x W x H)	12.6' x 9' x 5.8' (216 x 98.4 x 86.4 inches)
Bouncing Area Size	8.5' x 8.5'
Double Slide Size (L x W x H)	4.9' x 5.7' x 2.5'
Maximum Weight Capacity	300 lbs (on inflated area)
Individual Weight Limit	100 lbs
Recommended Age	36 months - 8 years
Number of Players	3-5 children
Material	Heavy-duty 0.4mm vinyl, 420D + 840D puncture-resistant material
Blower Power	350W
Item Weight	33 pounds
UPC	661954251261

PRODUCT SIZE



Figure 6: Detailed product dimensions.

WARRANTY AND SUPPORT

Whubefy stands behind the quality of its products.

- **Warranty:** All Whubefy Inflatable Bounce Houses come with a 180-day guarantee, covering manufacturing defects.
- **Included Accessories:** Each item is equipped with a 350W air blower, carry bag, 6 bouncer stakes, 4 blower stakes, 12 repair patches, 4 patchlines, and this instruction manual.
- **Customer Support:** For any questions, concerns, or warranty claims, please contact Whubefy customer service through the retailer where the product was purchased or visit the official Whubefy store online.

