

Disney LKG4010

Disney The Lion King Mufasa LED Watch User Manual

Model: LKG4010

INTRODUCTION

Welcome to the user manual for your new Disney The Lion King Mufasa LED Watch. This digital watch features a vibrant LED display and a comfortable silicone band, perfect for young fans of The Lion King. This manual provides essential information on how to set up, operate, and maintain your watch to ensure long-lasting enjoyment.

PRODUCT FEATURES

- Mufasa print on the watch face.
- Printed Lion King silicone band.
- Easy-to-use watch face.
- Digital light-up display.
- Traditional buckle clasp for secure fit.

SETUP

Battery Installation

Your watch requires one CR2032 battery. The battery is typically pre-installed. If the display does not light up, or if the time is incorrect, the battery may need to be replaced or activated.

1. Locate the battery compartment cover on the back of the watch.
2. Using a small screwdriver (not included), carefully remove the screws and the cover.
3. Insert the CR2032 battery with the positive (+) side facing up.
4. Replace the cover and secure it with the screws.

Initial Activation

Upon first use or after battery replacement, press the button on the side of the watch to activate the display and check if the time is shown.

OPERATING INSTRUCTIONS

Displaying the Time

To view the time, simply press the button located on the side of the watch. The LED display will light up, showing the current time for a few seconds before turning off to conserve battery life.

Setting the Time

To set the time on your LED watch:

1. Press the button once to display the time.
2. While the time is displayed, press and hold the button for approximately 3-5 seconds until the hour digits begin to flash.
3. Release the button. Each subsequent short press of the button will advance the hour.
4. Once the correct hour is set, press and hold the button again for 3-5 seconds until the minute digits begin to flash.
5. Release the button. Each subsequent short press of the button will advance the minutes.
6. After setting the minutes, press and hold the button one last time for 3-5 seconds to confirm and exit the setting mode. The display will stop flashing and return to normal operation.

MAINTENANCE

Cleaning Your Watch

To keep your watch clean, gently wipe the watch face and band with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the watch's finish or the silicone band. The watch is not waterproof; avoid submerging it in water.

Battery Replacement

When the display becomes dim or stops lighting up, it's time to replace the CR2032 battery. Follow the battery installation steps outlined in the "Setup" section. Ensure proper disposal of old batteries according to local regulations.

TROUBLESHOOTING

- **Display not lighting up:**
Ensure the battery is correctly installed and has sufficient charge. Replace the battery if necessary. Press the side button firmly.
- **Incorrect time displayed:**
The time may need to be reset. Follow the "Setting the Time" instructions in the "Operating Instructions" section.
- **Watch band discomfort:**
Ensure the band is not too tight. Clean the band regularly to prevent skin irritation.

SPECIFICATIONS

Model Number:	LKG4010
Brand:	Disney (Manufactured by Accutime)
Battery Type:	1 x CR2032 (required)
Package Dimensions:	21.9 x 8.8 x 5.1 cm (8.6 x 3.5 x 2.0 inches)
Item Weight:	30 g (1.06 ounces)
Department:	Boys
First Available Date:	January 22, 2024


WARRANTY AND SUPPORT

This Disney The Lion King Mufasa LED Watch comes with **one-year warranty** from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

For warranty claims or technical support, please contact the retailer where the watch was purchased or refer to the contact information provided on the product packaging or the manufacturer's official website (Accutime).

PRODUCT IMAGES





This image shows a close-up front view of the Disney The Lion King Mufasa LED Watch. The watch face is black with "MUFASA" written in yellow above the red digital time display, which shows "10:10". The watch has a silver-colored plastic casing, and parts of the patterned silicone band featuring Mufasa are visible at the top and bottom.





This image presents a full-length view of the Disney The Lion King Mufasa LED Watch. It highlights the entire silicone band, which is adorned with multiple illustrations of Mufasa in various poses against a patterned background. The watch face displays "MUFASA" and "10:10" in red LED digits, and the traditional buckle clasp is visible at the top of the band.





This image shows the Disney The Lion King Mufasa LED Watch packaged in its official brand packaging. The packaging is a yellow and green card with the "Disney The Lion King" logo prominently displayed. The watch itself is visible through a clear window, showcasing its Mufasa-themed face and band, with "LED Watch" printed at the bottom of the packaging.

Related Documents

	<p>The Little Mermaid Twinkle Trove Activity Gym - Assembly and Care Instructions</p> <p>Comprehensive guide for the Disney's The Little Mermaid Twinkle Trove Activity Gym, including safety warnings, assembly instructions, care and cleaning tips, and battery information. Features multilingual support.</p>
	<p>Disney Frozen Find My Nose Olaf Interactive Toy</p> <p>Discover the Disney Frozen Find My Nose Olaf interactive toy, featuring 20 sounds and phrases, multiple noses (carrot, fish, flag, paddle ball), and a storage basket. Perfect for fans of Frozen.</p>
	<p>Disney Villainous: Instructions and Gameplay Guide</p> <p>A comprehensive guide to playing Disney Villainous, detailing game setup, components, turn structure, actions, card types, and frequently asked questions. Learn how to embody iconic Disney Villains and achieve your unique objectives.</p>
	<p>Mickey and Minnie Mouse RC Vehicle User Manual</p> <p>Instructions and safety information for operating the Disney 9 Inch Mickey Mouse Fire Truck RC Vehicle and Disney 9 Inch Minnie Mouse Bake Shop RC Vehicle by MegaGain International Ltd.</p>