

Micro MMD198

Micro Mini Deluxe Foldable LED Scooter User Manual

Model: MMD198

1. INTRODUCTION

Welcome to the user manual for your new Micro Mini Deluxe Foldable LED Scooter. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your scooter to ensure a safe and enjoyable experience for your child. Please read this manual thoroughly before first use and keep it for future reference.





Image: Front view of the Micro Mini Deluxe Foldable LED Scooter in Aqua.

2. IMPORTANT SAFETY INSTRUCTIONS

Your child's safety is paramount. Always adhere to the following safety guidelines:

- Always wear a helmet and protective gear (knee pads, elbow pads, wrist guards) when riding.
- Adult supervision is required at all times, especially for younger children.
- Ensure all clamps, bolts, and wheels are securely fastened before each ride.
- Do not ride on public roads, near motor vehicles, or on uneven/slippery surfaces.
- Avoid riding in wet conditions or at night without adequate lighting.
- The maximum weight capacity for this scooter is 50 kg (110 lbs). Do not exceed this limit.
- Familiarize your child with the braking mechanism before riding at speed.



Image: A child safely riding the Micro Mini Deluxe scooter, wearing a helmet and protective pads.

3. SETUP AND ASSEMBLY

3.1 Unpacking

Carefully remove all components from the packaging. The box should contain one Micro Mini Deluxe Foldable LED Scooter. Inspect for any damage during transit.

3.2 Handlebar Adjustment

The handlebar height is adjustable to accommodate children from 2 to 5 years old. To adjust, locate the quick-release clamp on the stem. Open the clamp, slide the handlebar to the desired height (between 44 cm and 64 cm), and securely close the clamp. Ensure the handlebar is firmly locked in place before use.

3.3 Folding Mechanism

This scooter features a convenient folding mechanism for compact storage and transport. To fold, locate the folding

button/lever near the base of the handlebar stem. Press or pull the mechanism as indicated, and gently fold the handlebar down towards the deck until it locks into the folded position. To unfold, reverse the process, ensuring the handlebar clicks securely into the upright riding position.






Image: Diagram illustrating the adjustable handlebar height (44-64 cm) and the folding mechanism of the scooter.

4. OPERATING INSTRUCTIONS

4.1 Steering and Balance

The Micro Mini Deluxe scooter uses an intuitive lean-to-steer system. To turn, the rider simply leans in the desired direction, which engages the steering mechanism. This design helps develop balance, coordination, and motor skills in young children.

4.2 Braking

The scooter is equipped with a rear brake. To slow down or stop, the rider should gently press down on the rear fender brake with their foot. Practice braking at low speeds in a safe area before riding faster.

4.3 LED Wheels

The front wheels of the Micro Mini Deluxe LED scooter illuminate as they spin. This feature is powered by kinetic energy, meaning no batteries are required. The lights provide added visibility and fun during rides.



Image: Side view of the scooter showcasing the illuminated LED front wheels during motion.

5. MAINTENANCE AND CARE

Regular maintenance will extend the life of your scooter and ensure safe operation:

- **Cleaning:** Wipe the scooter with a damp cloth to remove dirt and dust. Avoid using harsh chemicals or abrasive cleaners.
- **Wheel Inspection:** Periodically check the wheels for wear and tear. Ensure they spin freely and are not obstructed by debris.
- **Fastener Check:** Regularly inspect all bolts, screws, and clamps to ensure they are tight and secure. Tighten any loose fasteners.
- **Storage:** Store the scooter in a dry place, away from direct sunlight and extreme temperatures, to prevent material degradation. The foldable design makes storage convenient.
- **Spare Parts:** Micro scooters are designed for longevity, with spare parts available to ensure they can be maintained and passed down through generations.

6. TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Handlebar is loose	Quick-release clamp not tightened sufficiently.	Open the clamp, push the handlebar down firmly, and re-tighten the clamp securely.
Wheels not spinning freely	Debris caught in bearings or worn bearings.	Clean around the wheel axles. If problem persists, bearings may need replacement.
Brake not effective	Brake mechanism worn or dirty.	Clean the brake area. Inspect the brake for wear and replace if necessary.
Scooter does not fold	Folding mechanism obstructed or not fully disengaged.	Check for any obstructions. Ensure the folding lever/button is fully activated.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	Mini Deluxe Foldable LED
Item Model Number	MMD198
Brand	Micro
Age Range	2-5 years
Color	Aqua
Number of Wheels	3
Wheel Size	120 Millimeters
Wheel Material	Reinforced PU

Feature	Specification
Frame Material	Aluminum
Material Type	Polypropylene, Aluminum
Weight	2.1 Kilograms
Maximum Weight Capacity	50 Kilograms
Product Dimensions (L x W x H)	30 x 11 x 68 cm
Brake Type	Rear Braking
Features	Foldable, Luminous Wheel, Adjustable Handlebar Height
Suspension	Rigid
Batteries Included?	No (LED wheels are kinetic)
Components Included	Scooter

8. WARRANTY AND CUSTOMER SUPPORT

Micro products are known for their quality and durability. For specific warranty information, please refer to the documentation provided with your purchase or visit the official Micro website. In general, Micro scooters are designed to be long-lasting, with spare parts available to ensure continued use.

For any questions, technical assistance, or to inquire about spare parts, please contact Micro Mobility France or your local authorized Micro retailer. Please retain your proof of purchase for any warranty claims.

Please note that a 30-day return/replacement policy is typically offered for this product.

© 2024 Micro Mobility. All rights reserved.



[Micro Spare Parts Catalogue](#)

A comprehensive catalogue of spare parts for Micro Mobility scooters, including models for adults, kids, travel, and freestyle.

lang:en **score:10** filesize: 10.29 M page_count: 79 document date: 2023-10-13



[\[pdf\] Catalog](#)

PowerPoint Präsentation Gordan Topic Каталог запчастей для всех самокатов Micro здесьЗапчасти Самокаты Официальный и эксклюзивный представитель швейцарской компании Mobility Systems в России!RZ Ersatzteilbroschüre 29 01 2025static insales cdn files 1 7184 39214096 original RZ 2025 ||| MICRO SPARE PARTS CATALOGUE 29.01.2025 CONTENTS ADULTS Micro Classic White 7 Micro Classic Bla ... MMD011 3in1 Deluxe Aqua MMD076 Deluxe LED Aqua MMD155 Deluxe Foldable Aqua MMD131 Deluxe Magic Aqua **MMD198** Deluxe Foldable LED Aqua MMD002 Deluxe Green MMD010 3in1 Deluxe Green MMD051 Deluxe LED Green...

lang:nl **score:8** filesize: 11.62 M page_count: 89 document date: 2025-01-31