

FLEX FS1105

FLEX STACK PACK FS1105 3-Drawer Tool Box Instruction Manual

Model: FS1105

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your FLEX STACK PACK FS1105 3-Drawer Tool Box. Please read these instructions carefully before initial use and retain for future reference.



Figure 1: The FLEX STACK PACK FS1105 3-Drawer Tool Box. This image shows the grey and black tool box with three visible drawers and the FLEX STACK PACK branding.

2. SETUP AND INITIAL USE

The FLEX STACK PACK FS1105 3-Drawer Tool Box is designed for immediate use with minimal setup. Upon unpacking, ensure all included components are present.

2.1 Included Components

- 1x FLEX STACK PACK FS1105 3-Drawer Tool Box
- 1x Onboard Security Bar
- 6x Long Dividers
- 18x Short Dividers

2.2 Installing Dividers

The drawers are equipped with slots for customizable organization using the included dividers.

1. Open a drawer by lifting the handle and pulling it out.
2. Insert the long and short dividers into the desired slots within the drawer to create compartments for your tools and supplies.
3. Ensure dividers are securely seated to prevent movement.



Figure 2: A hand placing a removable divider into a drawer of the FLEX STACK PACK tool box, demonstrating the customizable organization feature for hardware and supplies.

3. OPERATING INSTRUCTIONS

3.1 Drawer Operation

The tool box features auto-locking drawers and durable, rust-resistant rails for smooth operation.

- To open a drawer: Lift the drawer handle and pull the drawer outwards.
- To close a drawer: Push the drawer inwards until it clicks into place. The auto-locking mechanism will engage, preventing accidental opening during transport.




Figure 3: A close-up of a hand operating an auto-locking drawer. The image highlights the mechanism that prevents drawers from opening during transport.

3.2 Using the Onboard Security Bar

The onboard security bar provides an additional layer of protection against theft.

1. Ensure all drawers are fully closed and locked.
2. Position the security bar across the front of the drawers, aligning it with the designated slots on the sides of the tool box.
3. Secure the bar with a padlock (not included) through the provided holes.
4. When not in use, the security bar can be stowed in its designated storage area.



Figure 4: A hand attaching a padlock to the onboard security bar of the FLEX STACK PACK tool box, illustrating how to prevent theft.

3.3 STACK PACK System Connectivity

The FS1105 3-Drawer Tool Box is part of the FLEX STACK PACK system, allowing for quick and effortless connection with other compatible STACK PACK components.

- To stack: Align the quick-connect latches of the FS1105 with the corresponding connection points on another STACK PACK unit. Press down firmly until the latches engage.
- To unstack: Release the quick-connect latches and lift the unit.



QUICK-CONNECT LATCHES

CONNECT TO ANY LATCH-COMPATIBLE STACK PACK™ PRODUCT

***Tool boxes sold separately**

Figure 5: A person connecting two FLEX STACK PACK units, demonstrating the quick-connect latches for interlocking connectivity.



Figure 6: A fully assembled FLEX STACK PACK system with multiple units and attachments, illustrating the modularity and attachment-ready design.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your tool box.

- **Cleaning:** Wipe down the exterior with a damp cloth and mild soap as needed. Avoid harsh chemicals or abrasive cleaners.
- **Drawer Rails:** The rust-resistant rails are designed for durability. If smooth operation is affected by debris, clean the rails thoroughly. Lubrication is generally not required but can be applied sparingly if necessary, using a silicone-based lubricant.
- **Inspection:** Periodically inspect the latches, hinges, and overall structure for any signs of wear or damage.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your FLEX STACK PACK FS1105 3-Drawer Tool Box.

Problem	Possible Cause	Solution
Drawers do not open or close smoothly.	Debris in drawer rails; drawers overloaded.	Clean debris from rails. Reduce load in drawers to within the 70 lb. capacity.
Drawers do not auto-lock.	Drawer not fully closed; latch mechanism obstructed.	Ensure drawer is pushed in completely until a click is heard. Check for obstructions around the latch mechanism.
STACK PACK units do not connect securely.	Latches misaligned or obstructed.	Verify proper alignment of units. Clear any debris from quick-connect latches.

6. SPECIFICATIONS

Feature	Detail
Model Number	FS1105
Brand	FLEX
Material	Polypropylene
Color	Grey/Black
Product Dimensions (L x W x H)	22" x 15.1" x 16.3"
Item Weight	32.7 pounds
Load Capacity	70 pounds
Water Resistance Level	Waterproof
Number of Drawers	3
Key Features	Auto-locking drawers, Durable rust-resistant rails, Attachment-ready, Onboard security bar, Removable dividers, Quick-connect latches, Impact protection
UPC	195532300329

7. WARRANTY AND SUPPORT

7.1 Limited Warranty






The FLEX STACK PACK FS1105 3-Drawer Tool Box is covered by a one-year limited warranty. To activate your warranty, register your product within 30 days of purchase at registermyflex.com. This warranty covers defects in materials and workmanship under normal use.

7.2 Customer Support

For technical assistance, warranty claims, or general inquiries, please visit the official FLEX website or contact their

customer service department. Refer to your product packaging or the FLEX website for the most current contact information.

Related Documents - FS1105

	<p>FLEX 24V Lithium-ion Battery Operator's Manual and Safety Guide</p> <p>Operator's manual for FLEX 24V Lithium-ion batteries (FXA0111, FXA0121, FXA0221, FXA0231). Provides essential safety instructions, operating procedures, maintenance guidelines, and warranty information for FLEX power tool batteries.</p>
	<p>Flex Monitor Connection and Setup Guide</p> <p>Instructions for connecting and setting up the Flex portable monitor, including single USB-C connection and cable connection methods with additional power requirements. Details on unfolding and storing the monitor, and adjusting the stand for different modes like Landscape, Triangular, and Single Portrait.</p>
	<p>FLEX GE 6 R-EC Giraffa: Levigatrice Rotativa per Pareti e Soffitti - Scheda Tecnica</p> <p>Scopri la levigatrice rotativa FLEX GE 6 R-EC Giraffa, ideale per pareti e soffitti. Caratteristiche tecniche, design leggero, motore brushless e accessori inclusi. Scheda prodotto completa.</p>
	<p>FLEX PE 150 18.0-EC Elektrowerkzeug Bedienungsanleitung</p> <p>Entdecken Sie die FLEX PE 150 18.0-EC, eine leistungsstarke 18V Akku-Poliermaschine für professionelle Polierarbeiten in Industrie und Handwerk. Diese Anleitung bietet detaillierte Informationen zur sicheren Bedienung, Wartung und Pflege.</p>
	<p>FLEX GM 270 Giraffe Mobile: Operating Manual and Safety Guide</p> <p>Comprehensive operating instructions and safety guide for the FLEX GM 270 Giraffe Mobile, a professional support stand for FLEX long-necked sanders used in wall and ceiling sanding applications. Includes technical specifications and intended use.</p>



[FLEX FX5351 24V Jobsite Radio Operator's Manual](#)

Operator's manual for the FLEX FX5351 24V Jobsite Radio, covering safety instructions, functional descriptions, specifications, operating instructions, maintenance, and warranty information.