

ALOADECOR 7148D50CS

ALOADECOR 7148D50CS 20-inch 5-Light Crystal Chandelier  
User Manual

Model: 7148D50CS

|                          |                                |                              |                                    |                             |                                 |                                        |
|--------------------------|--------------------------------|------------------------------|------------------------------------|-----------------------------|---------------------------------|----------------------------------------|
|                          |                                |                              | <a href="#">Safety Information</a> | <a href="#">Package</a>     |                                 |                                        |
| <a href="#">Contents</a> | <a href="#">Specifications</a> | <a href="#">Installation</a> | <a href="#">Operation</a>          | <a href="#">Maintenance</a> | <a href="#">Troubleshooting</a> | <a href="#">Warranty &amp; Support</a> |

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your ALOADECOR 7148D50CS 20-inch 5-Light Crystal Chandelier. This lighting fixture is designed for indoor use and features an antique silver finish with handcrafted clear crystal beads. It is suitable for various room types including living rooms, dining rooms, foyers, and entryways. Please read this manual thoroughly before beginning installation and retain it for future reference.

SAFETY INFORMATION

- **WARNING:** To avoid electric shock, ensure power is turned off at the circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Use only bulbs of the specified type and wattage (5 x Max 40W E12 bulbs, not included). Exceeding the maximum wattage may cause overheating and damage.
- Do not install this fixture in wet or damp locations. It is designed for indoor use only.
- Handle crystal components with care to prevent breakage.
- Ensure the mounting surface can support the weight of the fixture (approximately 44 pounds).
- Wear safety glasses and gloves during installation.

PACKAGE CONTENTS

Verify that all components listed below are present before beginning installation. If any parts are missing or damaged, contact ALOADECOR customer service.

- Chandelier Frame with pre-attached crystal beads
- Mounting Hardware (Canopy, Mounting Plate, Screws, Wire Nuts)

- Adjustable Chain
- Shade (Integrated with crystal beads)
- Instruction Manual

**Note:** E12 bulbs (Max 40W) are not included and must be purchased separately.

SPECIFICATIONS

|                           |                                                             |
|---------------------------|-------------------------------------------------------------|
| Brand                     | ALOADECOR                                                   |
| Model Number              | 7148D50CS                                                   |
| Dimensions (L x W x H)    | 20 inches x 20 inches x 32 inches                           |
| Adjustable Hanging Length | Minimum H43" - Maximum H92" (Chain Adjustable)              |
| Item Weight               | 44 Pounds                                                   |
| Material                  | Crystal, Iron                                               |
| Finish                    | Antique Silver (Polished)                                   |
| Shade Material            | Crystal (Clear)                                             |
| Number of Light Sources   | 5                                                           |
| Bulb Base                 | E12                                                         |
| Max Wattage per Bulb      | 40W (Bulbs not included)                                    |
| Total Wattage             | 200 watts                                                   |
| Voltage                   | 120 Volts                                                   |
| Dimmable                  | Yes (with compatible dimmer switch and bulbs, not included) |
| Power Source              | Hardwired                                                   |
| Installation Type         | Ceiling Mount (Flush Mount)                                 |
| Indoor/Outdoor Usage      | Indoor Only                                                 |
| Certification             | ETL Listed                                                  |



Image: Detailed diagram showing the chandelier's dimensions (20 inches width, 32 inches height, 59 inches adjustable chain) and key specifications like voltage, wattage, material, finish, color, and bulb type.

## INSTALLATION INSTRUCTIONS

---

### Tools Required (Not Included):

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers
- Pliers
- Electrical Tape
- Safety Glasses
- Ladder

### Pre-Installation:

1. **Turn off power** at the main circuit breaker or fuse box to prevent electrical shock.
2. Carefully unpack all components and inspect for any damage. Keep all packaging materials until you are satisfied with the product.
3. Review the "Package Contents" section to ensure all parts are present.

### **Mounting the Fixture:**

4. Attach the mounting plate to the junction box in the ceiling using the provided screws. Ensure the plate is securely fastened and can support the fixture's weight.
5. Determine the desired hanging height for the chandelier. The chain is adjustable from a minimum of 43 inches to a maximum of 92 inches. Adjust the chain length by opening and closing links with pliers as needed.
6. Thread the electrical wires through the chain and canopy.
7. Connect the chandelier's ground wire (usually bare copper or green) to the ground wire from the junction box (usually bare copper or green) using a wire nut.
8. Connect the chandelier's hot wire (usually black or smooth) to the hot wire from the junction box (usually black) using a wire nut.
9. Connect the chandelier's neutral wire (usually white or ribbed) to the neutral wire from the junction box (usually white) using a wire nut.
10. Carefully tuck all wires into the junction box.
11. Secure the canopy to the mounting plate using the provided screws, ensuring a snug fit against the ceiling. This fixture is suitable for sloped, flat, and vaulted ceilings.

### **Bulb Installation:**

12. Insert five (5) E12 base bulbs (Max 40W each, not included) into the sockets. Do not exceed the maximum wattage.

# Product Details



## Product Specification

|           |                      |
|-----------|----------------------|
| Voltage:  | 120V                 |
| Wattage:  | MAX 40W              |
| Material: | Metal & Crystals     |
| Finish:   | Plating              |
| Color:    | Antique Silver       |
| Bulb:     | 5*E12 (not included) |

Image: The ALOADECOR 20-inch 5-Light Crystal Chandelier, fully assembled and hanging, showcasing its antique silver finish and clear crystal beads. This image provides a visual reference for the completed installation.

Your browser does not support the video tag.

Video: An official product video from ALOADECOR showcasing the chandelier's design and illuminated appearance. This video provides a dynamic view of the fixture's aesthetic qualities.

## OPERATION

1. After successful installation, restore power at the circuit breaker.
2. Turn on the light switch connected to the chandelier.
3. **Dimmable Feature:** This chandelier is dimmable. If you wish to use the dimming function, ensure you have installed a compatible dimmer switch and dimmable E12 bulbs (both sold separately).

## MAINTENANCE

Cleaning:

- **Always turn off power** at the circuit breaker before cleaning the fixture.
- For the metal finish, wipe with a soft, dry cloth. Do not use abrasive cleaners or polishes as they may damage the finish.
- For the crystal beads, gently wipe with a soft, damp cloth. A mild glass cleaner can be used sparingly, applied to the cloth first, not directly to the crystals. Ensure no liquid drips into electrical components.
- Allow the fixture to dry completely before restoring power.

Bulb Replacement:

- **Turn off power** at the circuit breaker.
- Allow bulbs to cool completely before touching them.
- Carefully unscrew the old bulb from the socket.
- Screw in a new E12 base bulb (Max 40W). Ensure it is fully seated.
- Restore power at the circuit breaker.

TROUBLESHOOTING

| Problem                    | Possible Cause                                                                                         | Solution                                                                                                                                                                                                           |
|----------------------------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Light does not turn on.    | Power is off at the circuit breaker.<br>Loose wire connections.<br>Faulty bulb.<br>Faulty wall switch. | Check and restore power at the circuit breaker.<br>Verify all wire connections are secure (ensure power is off first).<br>Replace bulb with a new, working one.<br>Test the wall switch or consult an electrician. |
| Light flickers.            | Loose bulb.<br>Incorrect bulb type for dimmer.<br>Loose wire connection.                               | Tighten bulb securely.<br>Ensure dimmable bulbs are used with a dimmer switch.<br>Check wire connections (ensure power is off first).                                                                              |
| Chandelier hangs unevenly. | Improperly secured mounting plate.<br>Uneven chain links.                                              | Ensure mounting plate is level and securely fastened.<br>Adjust chain links to ensure even suspension.                                                                                                             |

WARRANTY AND SUPPORT

This ALOADECOR lighting fixture is covered by a **12-month warranty** from the date of purchase. The warranty will be void if there is any damage due to improper usage or modification to the fitting.

For technical assistance, missing parts, or warranty claims, please contact ALOADECOR customer service. Please have your model number (7148D50CS) and proof of purchase ready when contacting support.

You can visit the official ALOADECOR store for more information:[ALOADECOR Store on Amazon](#)

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CT25NCSR>

More documents and user manuals: <https://manuals.plus/>