

SuperFire X60-T

SuperFire X60-T Flashlight User Manual

Model: X60-T | Brand: SuperFire

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your SuperFire X60-T High Lumens Rechargeable LED Flashlight. Please read this manual thoroughly before operating the device and retain it for future reference.

2. PRODUCT FEATURES

- **High Powered Illumination:** Equipped with upgraded super bright LED chips (36W), delivering a maximum of 10000 lumens in turbo mode with a maximum beam distance of 350 meters (1148 feet).
- **Versatile Lighting Modes:** Features 5 distinct lighting modes: High, Medium, Strobe, SOS, and Turbo, allowing adaptation to various lighting requirements.
- **Zoomable Focus:** The flashlight offers a telescopic focusing design; zoom in for a wide floodlight covering 56 square meters, or zoom out for a narrow spotlight capable of illuminating over 350 meters.
- **Durable & Waterproof Construction:** Constructed from aviation-grade aluminum, ensuring heavy-duty performance and resistance to extreme conditions. It boasts an IP44 waterproof rating, suitable for use in heavy rain and snow.
- **Type-C Rechargeable:** Utilizes an upgraded high-capacity battery, providing approximately 6 hours of operation in high mode and 15 hours in low mode. Fast-charging via a Type-C port takes 4-6 hours for a full charge, compatible with laptops, power banks, and adapters.
- **Portable Design:** Compact size (15.8 cm / 6.22 in L x 4.1 cm / 1.61 in W) with an integrated clip for easy storage and carrying in pockets or backpacks.
- **Power Bank Functionality:** Can function as a portable power bank to charge smartphones or tablets in emergency situations.

3. PACKAGE CONTENTS

Please verify that all items are present and in good condition upon opening the package:

- SuperFire X60-T Flashlight
- USB-C Charging Cable

- Belt Clip (pre-attached or included separately)
- User Manual (this document)

4. SETUP

4.1 Initial Charging

Before first use, fully charge the flashlight. The charging port is a Type-C port located on the side of the flashlight, typically protected by a rubber cover.

1. Locate the Type-C charging port on the flashlight.
2. Gently lift the rubber cover to expose the port.
3. Connect the provided USB-C charging cable to the flashlight's port.
4. Connect the other end of the USB-C cable to a compatible USB power source (e.g., wall adapter, computer USB port, power bank).
5. The indicator light on the flashlight will show charging status. It typically glows red while charging and turns blue when fully charged.
6. Charging usually takes 4-6 hours for a full charge.
7. Once fully charged, disconnect the cable and securely close the rubber cover to maintain water resistance.

Multi-Function EDC Flashlight

Field / cycling / home / Lighting Meet your needs



Power Bank



Strong Compatibility

Type-C CHARGING
input

PORTABLE SOURCE
output



TACTICAL WAIST CLIP

Figure 1: Type-C Charging Port and Tactical Waist Clip. The image displays a close-up of the flashlight's body, highlighting the Type-C input and USB output ports, along with a visual of the tactical waist clip.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button located on the side of the flashlight to turn it on or off.

5.2 Changing Lighting Modes

With the flashlight powered on, short press the power button repeatedly to cycle through the 5 lighting modes:

- **High:** Maximum brightness for general illumination.
- **Medium:** Moderate brightness for extended battery life.
- **Low:** Minimal brightness for close-range tasks or preserving night vision.

- **Strobe:** Rapid flashing light for signaling or disorientation.
- **SOS:** International Morse code signal for emergencies (three short, three long, three short flashes).
- **Turbo:** (If applicable, usually a double-click from off or on) Provides the absolute maximum lumen output for a short burst. Refer to product specifications for activation.



Figure 2: Five Lighting Modes. This image illustrates the different light output levels and special modes (Strobe, SOS) of the flashlight in various outdoor scenarios.

5.3 Zoom Functionality

The SuperFire X60-T features a telescopic focusing design to adjust the beam from a wide floodlight to a narrow spotlight.

1. To adjust the beam, gently slide the head of the flashlight forward or backward.
2. Sliding the head forward will narrow the beam, creating a focused spotlight for long-distance illumination.
3. Sliding the head backward will widen the beam, creating a broad floodlight for illuminating a larger area.



Figure 3: Telescopic Focusing. The image shows the flashlight's zoomable design, illustrating the wide beam (floodlight) and narrow beam (spotlight) capabilities.

5.4 Using as a Power Bank

The flashlight can serve as a portable power bank to charge other devices.

1. Locate the USB output port, usually next to the Type-C input port, under the same rubber cover.
2. Connect your device's charging cable (e.g., smartphone, tablet) to the USB output port on the flashlight.
3. The flashlight will begin charging your device. Monitor your device's charging indicator.
4. Disconnect when charging is complete or when the flashlight's battery is low.

6. MAINTENANCE

- **Cleaning:** Wipe the flashlight with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, charge the battery every 3-6 months to maintain its lifespan.

- **Water Resistance:** Ensure the rubber cover for the charging ports is always securely closed to maintain the IP44 water resistance rating. Avoid submerging the flashlight in water.
- **Battery Care:** Use only the provided charging cable or a compatible Type-C cable. Do not attempt to replace the internal battery.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is depleted.	Charge the flashlight fully using the provided Type-C cable.
Light output is dim.	Low battery or incorrect mode.	Charge the battery. Cycle through modes to ensure High or Turbo mode is selected.
Flashlight not charging.	Cable or adapter issue; port not connected properly.	Ensure the Type-C cable is securely connected to both the flashlight and the power source. Try a different USB port or adapter.
Zoom function is stiff.	Dust or debris in the mechanism.	Gently clean the sliding mechanism. Avoid forcing the zoom.

8. SPECIFICATIONS

Feature	Detail
Model	X60-T
Brand	SuperFire
Light Source Type	LED
Brightness (Max)	10000 Lumens (Turbo Mode) / 2100 Lumens (Standard)
Beam Distance (Max)	350 meters (1148 feet)
Power Source	Battery Powered (1 Lithium Ion battery included)
Charging Port	Type-C
Charging Time	4-6 hours
Runtime (High Mode)	6 hours
Runtime (Low Mode)	15 hours
Material	Aviation-grade Aluminum
Water Resistance Level	IP44 (Waterproof)
Product Dimensions	2.1"D x 2.1"W x 6.7"H (15.8 cm L x 4.1 cm W)
Item Weight	1.01 pounds
Special Features	Adjustable Focus, Durable, High Power, Portable, Weatherproof, Power Bank Functionality

SIZE



	RUN TIME		LUMEN
X60	2.5H	X60	1000LM
X60-T	4.5H	X60-T	2100LM


Figure 4: Size and Performance Comparison. This image provides a visual comparison of the X60-T's size relative to a smartphone and another model (X60), along with a table detailing their respective runtimes and lumen outputs.

9. WARRANTY & SUPPORT

For warranty information, technical support, or any inquiries regarding your SuperFire X60-T flashlight, please refer to the contact information provided on the product packaging or visit the official SuperFire website. Keep your purchase receipt as proof of purchase for warranty claims.

Related Documents - X60-T


Features: 1. 300 lumens: (variable and adjustable for step control) 2. 100 mAh: (extra bright, energy-efficient light) 3. Portable: (easy to carry, suitable for outdoor use) 4. Multifunctional: (suitable for various activities and safety) Operations Instructions: 1. Power: Press the power button (marked with a power icon) to turn on or off the flashlight. 2. Light Adjustment: Press the side of the flashlight to adjust the beam. Press the side of the flashlight to a smaller, long-distance beam. 3. Charging: Connect the flashlight to a power source using the USB cable. The flashlight will be charged. Warning: 1. Do not look directly at the light beam when it is on. 2. Do not disassemble the flashlight.	ESMARTER F15-T Portable UV Flashlight User Manual & Features Detailed guide for the ESMARTER F15-T portable UV flashlight. Learn about its features, operation, charging, and safety warnings. Includes UV 395NM, zoomable beam, and multiple modes.
	Superfire X60 and X Series Flashlights User Manual Comprehensive user manual for Superfire X60, X60-T, A2, A2 P50, A2-X, A2-S, A3, A3-S, A5, A5-L2, A6, and A10 series flashlights, covering features, operation, charging, and safety.
Charging Instructions: It has a built-in rechargeable battery, which can be charged by connecting the USB cable to the charging port. -Do not use in extremely cold or hot environments below -10°C or above 60°C. -This product is only compatible with the original built-in lithium battery, so do not disassemble or replace it by yourself. -Please use a high-quality power socket and a standard USB charging head to charge this product. -Please charge for 5-8 hours or more before use to avoid unnecessary disputes. -Do not charge in light mode. Instructions for use: The common working method is to click the switch to turn on the light. If the anti-touch switch is set, there are multiple ways to turn on the light: such as long press the switch, double-click the switch, tap the switch three times, etc. Please try it, thank you.	ESMARTER F15-T Tactical Flashlight User Manual and Charging Instructions Comprehensive guide for the ESMARTER F15-T tactical flashlight, covering charging instructions, safe usage, and operation of its various lighting modes. Learn how to properly charge and use your flashlight.
SUPERFIRE L28 User Manual	Superfire L28 Flashlight User Manual: Specifications and Operation Official user manual for the Superfire L28 flashlight. Details product specifications including power (5W max), waterproof rating (IP44), battery requirements (2xAAA), and dimensions. Provides instructions on operating the 5 light modes: Strong, Medium, Low, Strobe, and SOS.
	SunFire X Series Gas Restaurant Ranges Installation and Operation Manual This manual provides comprehensive installation, operation, and maintenance instructions for SunFire X Series Gas Restaurant Ranges manufactured by Garland Commercial Industries. It covers safety precautions, technical specifications, installation procedures, testing, operation, and cleaning guidelines for various models.
	SunFire X Series Gas Restaurant Ranges: Installation and Operation Manual Comprehensive guide for Garland SunFire X Series Gas Restaurant Ranges, covering installation, operation, maintenance, safety, and specifications for various models. Includes important warnings and technical details for professional use.



[pdf] User Manual

Latarki z serii A i X X60 T A2 P50 S A3 A5 L2 A6 A10 CZ User manual rum Superfire zseblámpa 1500lm USB 56540 19684 a1666c2e2a16971f01ec2231eb441d7f puputeve hu media wysiwyg attachments ||| Lanterne SUPERFIRE A i X Manual de utilizare Avertisment : Stimat client, v mulumim pentru achizi ... dul Aurora . inei apsat butonul timp de aproximativ 1 secund , pentru a opri lanterna. 4. Lanterna **X60-T** are 5 moduri, apsai pur i simplu butonul frontal pentru a porni sursa de lumin , continuai s r...

lang:it score:32 filesize: 1.18 M page_count: 11 document date: 2024-07-10




[pdf]

PL SRODOWISKO A5 Instrukcja obsługi pol Superfire X60 T zseblámpa 1500lm USB 48020 19684 0a82a0adeb4efd85eee1cdb03b1125a3 puputeve hu media wysiwyg attachments |||

Latarka Superfire **X60-T** Instrukcja Opis Porczna latarka Superfire **X60-T** moe wieci w zasigu do nawet 300 m. Oferuje a 5 trybw dzialania, dziki czemu z latwoci dostosujesz j do niemal kadej sytuacji. Czas pracy 3-8 godzin oraz wodoodporno IP34 sprawiaj, e zaskoczy Ci niezawodnym dzialaniem. Umoowiwa d...

lang:pl score:31 filesize: 565.91 K page_count: 2 document date: 2024-03-14



[pdf]

Latarki z serii A i X X60 T A2 P50 S A3 A5 L2 A6 A10 CZ files innpro pl s3 amazonaws Superfire New ||| SUPERFIRE Hoky ady A a X Nvod k obsluze Varovn: Vzen zkaznku, dkujeme Vm za zakoupen tohoto produk ... 1. Svtlna X60 pouzvj jako zdroj napjen baterii 18650 voliteln vestavnou nebo vymnitelnou , svtlna **X60-T** pouzvj jako zdroj napjen baterii 26650. Baterii instalujte sprvnsm smrem znamen kladn a - ...

lang:hr score:27 filesize: 4.65 M page_count: 11 document date: 2023-05-08

SUPERFIRE

Svítilny A a X

Návod k obsluze

[\[pdf\]](#)

Latarki z serii A i X X60 T A2 P50 S A3 A5 L2 A6 A10 CZ Návod k obsluze pol Superfire zseblámpa 650lm USB töltéssel 49765 15815 c5266219ed741bbade0a9760622a7aad puputeve hu media wysiwyg attachments |||

SUPERFIRE Svítilny A a X Nvod k obsluze Varovn: Vzen zkaznku, dkujeme Vm za zakoupen tohoto produkt ... 1. Svitlna X60 pouzvj jako zdroj napjen baterii 18650 voliteln vestavnou nebo vymnitelnou , svitlna **X60-T** pouzvj jako zdroj napjen baterii 26650. Baterii instalujte sprvnm smrem znamen kladn a - ...

lang:hr **score:25** filesize: 4.72 M page_count: 11 document date: 2024-04-05

Latarki Superfire serii A i X Instrukcja Obsługi

[\[pdf\]](#)

Latarki z serii A i X X60 T A2 P50 S A3 A5 L2 A6 A10 CZ Instrukcja Obsługi pol Superfire zseblámpa 550lm USB töltéssel 49635 15816 6aadee97360c8fab147fd364ebf9f7e5 puputeve hu media wysiwyg attachments |||

Latarki Superfire serii A i X Instrukcja Obsługi Producent: Shenzhen Supfire Prosperity Equ. Co., Lt ... X60 wykorzystuje akumulator 18650 opcjonalnie wbudowany lub wymienny jako rdlo zasilania, latarka **X60-T** wykorzystuje akumulator 26650 jako rdlo zasilania. Akumulator naley zainstalowa we wlaciwym ki...

lang:pl **score:25** filesize: 4.17 M page_count: 12 document date: 2024-04-02

Producer: Shenzhen Supfire Prosperity Equ. Co., Ltd.
Address: 9th Floor, Building 10, Shui'an Garden, Yuanyang
Xintandi, Dnystryk Longgang, Shenzhen, China

SUPERFIRE Zseblámpák

A és X Használati útmutató


[\[pdf\]](#)

Latarki z serii A i X X60 T A2 P50 S A3 A5 L2 A6 A10 CZ Használati utasítás hun Superfire zseblámpa 1500lm USB 56543 19684 95a5764e02f1dfcf44c94c4232646b26 puputeve hu media wysiwyg attachments |||

SUPERFIRE Zseblmpk A s X Hasznlati tmutat Figyelmeztets : Kedves Vsrlnk Ksznjnk, hogy megvsrolta t ... solja az Aurora mdot . A zseblmpa kikapcsolshoz tartsa lenyomva a gombot krlbell 1 mpercig . 4. Az **X60-T** zseblmpa 5 zemmddal rendelkezik, egyszeren nyomja meg az ells gombot a fnyforrs bekapcsolshoz,...

lang:no **score:24** filesize: 1.34 M page_count: 15 document date: 2024-07-10

尺寸: 70x105mm



[Superfire X60 and X Series Flashlights User Manual](#)

Comprehensive user manual for Superfire X60, X60-T, A2, A2 P50, A2-X, A2-S, A3, A3-S, A5, A5-L2, A6, and A10 series flashlights, covering features, operation, charging, and safety.

lang:no **score:13** filesize: 2.31 M page_count: 1 document date: 2022-08-29