

LITFAD LT1236982G

LITFAD Shoe Rack Instruction Manual

Model: LT1236982G

IMPORTANT SAFETY INFORMATION

Read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all parts are present before beginning assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Tighten all screws and bolts securely, but do not overtighten.
- Do not stand on the unit or allow children to climb on it.
- Distribute weight evenly on shelves to prevent tipping.
- Handle glass components with care to avoid breakage.

PACKAGE CONTENTS

Verify that all components listed below are included in your package:

Item	Description	Quantity
Shoe Storage Cabinet	Main unit with glass doors and adjustable shelves	1
Assembly Tools	Necessary tools for assembly	1 Set
Instruction Manual	This document	1
Hardware Pack	Screws, dowels, and other fasteners	1 Set

SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended that two adults assemble the unit to ensure safety and ease of construction.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent damage.
2. **Identify Parts:** Refer to the included assembly diagrams (not provided in this manual) to identify each component

and hardware piece.

3. **Assemble Frame:** Begin by assembling the main frame of the cabinet according to the step-by-step instructions in the separate assembly guide. Ensure all connections are secure.
4. **Install Back Panel:** Attach the closed back panel to the assembled frame.
5. **Attach Doors:** Mount the glass doors to the cabinet frame. Ensure they open and close smoothly. The doors feature a push-type opening mechanism.
6. **Insert Shelves:** Place the adjustable shelves into the desired positions. The shelves can be moved to accommodate different shoe heights, including boots.
7. **Final Check:** Once assembled, gently move the cabinet to its desired location. Verify that all connections are tight and the unit is stable.



Image: Overall view of the LITFAD Shoe Rack, illustrating its dimensions and multi-layer design.




Image: Detailed view of the shoe rack's glass door and interior shelving, showcasing the storage capacity.

OPERATING INSTRUCTIONS

- **Opening Doors:** The cabinet doors operate with a push-type mechanism. Gently press the door to release the latch, then pull to open.
- **Closing Doors:** Push the door firmly until you hear a click, indicating the latch has engaged.
- **Adjusting Shelves:** To adjust shelf height, remove all items from the shelf. Carefully lift the shelf and reposition the shelf pegs to the desired height. Ensure all four pegs are securely in place before placing items back on the shelf.
- **Storing Shoes:** Place shoes neatly on the shelves. The widened design accommodates men's and women's shoes up to size 15.

MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish and glass.
- **Glass Care:** Use a standard glass cleaner for the glass doors. Spray cleaner onto a cloth, then wipe the glass to avoid overspray on wood or metal components.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Overloading:** Do not exceed the weight capacity of the shelves. Distribute items evenly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly.	Loose connections or uneven floor.	Ensure all screws are tightened. Adjust leveling feet if present, or place shims under the base on uneven floors.
Door does not close properly.	Misaligned hinges or latch.	Check hinge alignment and adjust if necessary. Ensure the push-latch mechanism is functioning correctly and not obstructed.
Shelf does not fit or is uneven.	Shelf pegs not fully inserted or misaligned.	Remove the shelf and ensure all four shelf pegs are fully and evenly inserted into the corresponding holes.
Glass door appears scratched or damaged.	Improper cleaning or impact.	Use only soft cloths and glass cleaner. For significant damage, contact customer support for replacement options.

SPECIFICATIONS

Model Number	LT1236982G
Dimensions (L x W x H)	35" x 14" x 47" (88.9 cm x 35.56 cm x 119.38 cm)
Material	Engineered Wood, Metal, Glass
Color	Grey
Number of Shelves	6 (Adjustable)
Door Type	Glass, Push-to-open
Assembly Required	Yes
Mounting Type	Freestanding

WARRANTY INFORMATION

This product comes with a limited manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your purchase or contact LITFAD customer support. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact LITFAD customer support.

For the most up-to-date contact information, please visit the official LITFAD website or refer to your purchase documentation.

When contacting support, please have your model number (LT1236982G) and purchase date available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CT2Q928H>

More documents and user manuals: <https://manuals.plus/>