

PERLESMITH PSTVMC06&PSTVS18

PERLESMITH Mobile TV Stand & Universal Swivel TV Stand User Manual

Models: PSTVMC06 & PSTVS18

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your PERLESMITH Mobile TV Stand (PSTVMC06) and Universal Swivel TV Stand (PSTVS18). Please read these instructions carefully before installation and use to ensure safe and optimal performance of your product.

The PERLESMITH PSTVMC06 is a versatile mobile TV cart designed for easy relocation and adjustable viewing angles. The PERLESMITH PSTVS18 is a robust tabletop swivel TV stand offering enhanced stability and flexible viewing positions.



Image: The PERLESMITH Mobile TV Stand (PSTVMC06) on the left, featuring a TV mounted on a wheeled base with a shelf, and the PERLESMITH Universal Swivel TV Stand (PSTVS18) on the right, showing a fixed base with a swivel mount for a TV.

SAFETY INFORMATION

- Do not exceed the maximum weight capacity specified for each stand.
- Ensure all screws and bolts are securely tightened before use.
- Always use the provided safety locks and anti-skid features to prevent accidental tipping.
- Keep children and pets away from the stand during assembly and operation.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately.

SETUP AND ASSEMBLY

1. VESA Compatibility and TV Size Check

Before assembly, verify that your television's VESA mounting pattern and weight are compatible with the respective stand.

- **PSTVMC06 (Mobile TV Stand):** Supports TVs from 23" to 60" with VESA patterns from 100x100mm (4"x4") to 400x400mm (16"x16"). Maximum weight capacity: 88 lbs.
- **PSTVS18 (Universal Swivel TV Stand):** Supports TVs from 37" to 75" with VESA patterns from 200x100mm to 600x400mm. Maximum weight capacity: 88 lbs.



Image: A diagram illustrating the wide TV compatibility of the PSTVMC06 mobile stand, showing supported screen sizes from 23" to 60" and a maximum weight of 88 lbs, along with various VESA patterns.

Larger Base Enhances Stability



Image: A diagram illustrating the TV compatibility of the PSTVS18 swivel stand, showing supported screen sizes from 37" to 75" and a maximum weight of 88 lbs, along with various VESA patterns.

2. Assembly Steps (General Guidelines)

Refer to the detailed assembly instructions provided in the packaging for step-by-step guidance specific to your model (PSTVMC06 or PSTVS18). The following are general steps:

1. **Unpack and Identify Parts:** Lay out all components and hardware. Verify against the parts list in your product's specific manual.
2. **Assemble the Base:** For PSTVMC06, attach the wheels to the mobile base. For PSTVS18, secure the tempered glass base to the main support column.
3. **Attach Support Column:** Connect the vertical support column to the assembled base.
4. **Install TV Brackets:** Secure the TV mounting brackets to the back of your television using the appropriate screws and spacers. Ensure they are level and centered.
5. **Mount TV to Stand:** Carefully lift the TV and hook the brackets onto the stand's mounting plate. Engage any safety locks to secure the TV in place.

6. **Adjust Height (PSTVS18):** The PSTVS18 offers two-position adjustable TV plate and three-position adjustable TV bracket for optimal height. Adjust as needed to accommodate soundbars or other devices.
7. **Install Shelf (PSTVMC06):** Attach the media shelf to the mobile stand at your desired height.




Image: A close-up view highlighting the strong and stable support features of the TV stand, including security locks, heavy-duty steel construction, and anti-slip pads on the base.




Image: A diagram illustrating the 6 height configurations available with the PSTVS18 swivel TV stand, showing how the TV can be positioned at different vertical levels.

OPERATING INSTRUCTIONS

PSTVMC06 (Mobile TV Stand)

- **Mobility:** To move the stand, ensure the TV is securely mounted and all cables are managed to prevent snagging. Gently push the stand to your desired location. Lock the wheels once positioned to ensure stability.
- **Tilt Adjustment:** The PSTVMC06 features a 15° upward angle adjustment. Loosen the tilt knobs on the side of the TV brackets, adjust the TV to your preferred viewing angle, and then securely tighten the knobs. This helps reduce glare and optimize viewing comfort.

Tilt Up for A Better Angle



Image: A person on a treadmill viewing a TV mounted on the PSTVMC06 mobile stand, demonstrating the 15-degree upward tilt feature for an improved viewing angle.

PSTVS18 (Universal Swivel TV Stand)

- **Swivel Function:** The PSTVS18 allows for a 35° swivel to the left or right. Gently rotate the television to achieve your desired viewing angle from any seat in the room.
- **Height Adjustment:** As mentioned in setup, the TV plate and bracket offer multiple height positions. Adjust these during assembly to ensure optimal viewing and space for soundbars or other media devices.

Designed for Large TVs



Max
Weight Capacity
88 lbs

TV VESA

600 × 400mm	600 × 200mm	400 × 400mm
400 × 300mm	300 × 300mm	300 × 200mm
200 × 300mm	200 × 200mm	200 × 100mm

Image: A living room scene showing a TV mounted on the PSTVS18 swivel stand, demonstrating its ability to swivel up to 35 degrees left or right for a perfect view from any seat.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the stand. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying. Avoid abrasive cleaners or solvents.
- **Regular Checks:** Periodically inspect all bolts and screws to ensure they remain tight. Over time, vibrations or movement can cause them to loosen.
- **Cable Management:** Ensure cables are neatly organized and not under tension, especially for the mobile stand, to prevent damage or tripping hazards.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
TV is not stable on the stand.	Loose connections, incorrect VESA mounting, or exceeding weight capacity.	Ensure all bolts are tightened. Verify TV VESA and weight are within specified limits. Re-check safety locks.
Mobile stand (PSTVMC06) is difficult to move.	Wheels are locked, or debris is obstructing movement.	Unlock the wheels. Clear any debris from the wheels.
Swivel/Tilt function is stiff or not working.	Tightened too much during assembly, or obstruction.	Ensure no cables or objects are obstructing movement. Check if tilt knobs are too tight (PSTVMC06).
Missing parts after unboxing.	Packaging error.	Do not proceed with assembly. Contact PERLESMITH customer support immediately.

SPECIFICATIONS

PERLESMITH Mobile TV Stand (PSTVMC06)

- **Compatible TV Sizes:** 23" - 60"
- **Maximum Weight Capacity:** 88 lbs (40 kg)
- **VESA Compatibility:** 100x100mm to 400x400mm (e.g., 100x100, 100x200, 200x200, 200x300, 300x200, 300x300, 400x200, 400x300, 400x400)
- **Tilt Angle:** Up to 15° upward
- **Features:** Mobile wheels (lockable), adjustable media shelf

PERLESMITH Universal Swivel TV Stand (PSTVS18)

- **Compatible TV Sizes:** 37" - 75"
- **Maximum Weight Capacity:** 88 lbs (40 kg)
- **VESA Compatibility:** 200x100mm to 600x400mm (e.g., 200x100, 200x200, 200x300, 300x200, 300x300, 400x200, 400x300, 400x400, 600x200, 600x400)
- **Swivel Angle:** ±35° (70° total)
- **Height Adjustment:** Two-position adjustable TV plate, three-position adjustable TV bracket
- **Base Material:** Tempered glass

Enhanced Multi-TV Viewing



Image: A living room setting showcasing both the mobile TV stand (PSTVMC06) with a TV and laptop, and the universal swivel TV stand (PSTVS18) with a TV and soundbar, demonstrating their use in different viewing scenarios.

LIMITED WARRANTY

PERLESMITH products are manufactured with high-quality materials and craftsmanship. This product is backed by a limited warranty against defects in materials and workmanship under normal use. The specific terms and duration of the warranty may vary. Please retain your proof of purchase for warranty claims.

For detailed warranty information, please refer to the warranty card included with your product or visit the official PERLESMITH website.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues with your PERLESMITH TV stand, please do not hesitate to contact our customer support team.

Contact Information:








Website: [Visit the PERLESMITH Store on Amazon](#) (for general inquiries and product information)



Email: (Refer to product packaging or official website for direct email support)

Phone: (Refer to product packaging or official website for phone support)

Please have your model number (PSTVMC06 & PSTVS18) and purchase date ready when contacting support.

Related Documents - PSTVMC06&PSTVS18

<div><div>INSTRUCTION MANUAL</div><div></div><div>PSTVS17</div><div></div><div>Tabletop TV Stand</div><div><div>1-800-488-4888 (US/CA)</div><div>844-888-198-3881 (UK)</div><div>support@perlesmith.com</div><div>www.perlesmith.com</div></div></div>	<p>PERLESMITH PSTVS17 Universal Swivel Tabletop TV Stand - Instruction Manual</p> <p>Comprehensive instruction manual for the PERLESMITH PSTVS17 universal swivel tabletop TV stand. Learn how to safely assemble and install your TV stand with detailed steps, parts lists, and compatibility checks.</p>
<div><div>INSTRUCTION MANUAL</div><div></div><div>PSTVS13</div><div></div><div><div><div>Table Top TV Stand</div><div>Perlesmith - Technische</div><div>Manuel de l'utilisateur à télécharger</div><div>1-800-488-4888 (US/CA)</div><div>844-888-198-3881 (UK)</div><div>support@perlesmith.com</div><div>www.perlesmith.com</div></div><div><div>Support de l'utilisateur à télécharger</div><div>Perlesmith - Technische</div><div>Manuel de l'utilisateur à télécharger</div><div>1-800-488-4888 (US/CA)</div><div>844-888-198-3881 (UK)</div><div>support@perlesmith.com</div><div>www.perlesmith.com</div></div></div></div>	<p>PERLESMITH PSTVS13 Table Top TV Stand Instruction Manual</p> <p>This instruction manual provides detailed assembly steps, safety guidelines, and compatibility checks for the PERLESMITH PSTVS13 table top TV stand, designed for TVs up to 88 lbs. It covers VESA compatibility, parts identification, and step-by-step assembly for various TV back types.</p>
<div><div>Installation Instruction</div><div></div><div>Model: PSTM1</div><div><div>Thank you for choosing this product. We strive to provide you with the best quality products and services. If you have any questions, please contact our technical support team. We are here to help you. Technical Support: 1-800-488-4888 (US/CA) 844-888-198-3881 (UK) support@perlesmith.com www.perlesmith.com</div></div></div>	<p>PERLESMITH PSTM1 TV Tripod Stand Installation Guide</p> <p>Detailed installation instructions for the PERLESMITH PSTM1 TV Tripod Stand, a portable and height-adjustable floor stand for 23-55 inch LED, LCD, and OLED flat-screen TVs with VESA 400x400mm compatibility and an 88 lbs weight capacity.</p>
<div><div></div><div>TV Tripod Stand Instruction Manual</div><div></div><div>Model: PSTM2</div><div><div>Thank you for choosing this product. We strive to provide you with the best quality products and services. If you have any questions, please contact our technical support team. We are here to help you. Technical Support: 1-800-488-4888 (US/CA) 844-888-198-3881 (UK) support@perlesmith.com www.perlesmith.com</div></div></div>	<p>Perlesmith PSTM2 TV Tripod Stand Instruction Manual</p> <p>Comprehensive instruction manual for the Perlesmith PSTM2 TV Tripod Stand. Includes safety instructions, parts list, hardware list, and step-by-step assembly and adjustment guides for mounting TVs.</p>

 <p>PERLESMITH INSTRUCTION MANUAL TABLETOP TV STAND PSTVS33</p> <p>1-800-856-6888 (Toll Free) Mon-Fri 9am - 5pm (EST) 404-886-1916 (Sat) Mon-Fri 9am - 5pm (EST) support@perlesmith.com www.perlesmith.com</p>	<p>PERLESMITH PSTVS33 Tabletop TV Stand Instruction Manual</p> <p>This instruction manual provides detailed steps for assembling and installing the PERLESMITH PSTVS33 Tabletop TV Stand. It covers compatibility checks for VESA patterns and weight limits, lists all included parts and hardware, and guides users through each installation step, including attaching brackets, assembling the base, mounting the TV plate, securing the TV, and managing cables. Safety warnings and contact information are also provided.</p>
 <p>TV Tripod Stand Instruction Manual Model PSTM2</p> <p><small>Thank you for choosing the product. We strive to provide you with the best quality products and services in the industry. Should you have any doubts, please don't hesitate to contact us.</small></p> <p><small>Technical Support: US/CA: 1-800-856-6888 Mon-Fri 9am - 5pm (EST) Other Time: support@perlesmith.com</small></p>	<p>PERLESMITH PSTM2 TV Tripod Stand Instruction Manual</p> <p>Instruction manual for the PERLESMITH PSTM2 TV Tripod Stand, detailing assembly, safety instructions, and adjustments for mounting TVs up to 75 inches.</p>