

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kircuit](#) /

› **Kircuit 12V AC/DC Adapter for EcoXGear Soundextreme GDI-EXSNDXTR01 SE26 Soundbar Speaker Instruction Manual**

Kircuit GDI-EXSNDXTR01 SE26

Kircuit 12V AC/DC Adapter Instruction Manual

Model: GDI-EXSNDXTR01 SE26 Compatible

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Kircuit 12V AC/DC Adapter. This power supply is designed to convert standard AC wall power into the DC power required by compatible devices, specifically the EcoXGear Soundextreme GDI-EXSNDXTR01 SE26 Soundbar Speaker. Please read this manual thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

To prevent electric shock, fire, or damage to the adapter or your device, always observe the following safety precautions:

- Do not expose the adapter to rain, moisture, or extreme temperatures.
- Do not disassemble or modify the adapter. Refer all servicing to qualified personnel.
- Ensure the power outlet voltage matches the adapter's input voltage (100-240V AC).
- Avoid placing heavy objects on the power cord.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Kircuit 12V AC/DC Adapter



Image 1: The Kircuit 12V AC/DC Adapter. This image displays the power adapter with its barrel plug connector and power cord, ready for connection to a compatible device and a wall outlet.

4. SETUP

Follow these steps to set up your AC/DC adapter:

- 1. Identify the Device Port:** Locate the power input port on your EcoXGear Soundextreme GDI-EXSNDXTR01 SE26 Soundbar Speaker. This port is typically a circular barrel-type connector.
- 2. Connect the Adapter:** Insert the barrel plug connector of the Kircuit adapter firmly into the power input port of your soundbar speaker.
- 3. Connect to Power Outlet:** Plug the AC end of the adapter into a standard electrical wall outlet (100-240V AC).
- 4. Verify Connection:** Ensure all connections are secure. The soundbar speaker should now be receiving power.

5. OPERATING INSTRUCTIONS

Once the adapter is properly connected, your EcoXGear Soundextreme GDI-EXSNDXTR01 SE26 Soundbar Speaker will be ready for operation or charging.

- Powering On:** Use the power button on your soundbar speaker to turn it on.
- Charging:** If your soundbar speaker has an internal battery, the adapter will automatically begin charging it when connected to a live power outlet. Refer to your soundbar speaker's manual for charging indicators.
- Disconnection:** To disconnect, first turn off your soundbar speaker, then unplug the adapter from the wall outlet, and finally disconnect the barrel plug from the soundbar speaker.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly winding the cable to prevent damage.
- **Inspection:** Periodically inspect the power cord and connectors for any signs of damage, such as fraying or bent pins. If damage is observed, discontinue use and replace the adapter.

7. TROUBLESHOOTING

If you encounter issues with your Kircuit AC/DC adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on/charging.	<ul style="list-style-type: none">◦ Adapter not properly connected.◦ Power outlet is not active.◦ Adapter or device is faulty.	<ul style="list-style-type: none">◦ Ensure all connections are secure.◦ Test the power outlet with another device.◦ Try a different compatible adapter if available, or contact support.
Adapter feels unusually hot.	<ul style="list-style-type: none">◦ Overload or poor ventilation.◦ Internal fault.	<ul style="list-style-type: none">◦ Ensure the adapter is used in a well-ventilated area.◦ Disconnect immediately and discontinue use. Contact support.

8. SPECIFICATIONS

Key technical specifications for the Kircuit 12V AC/DC Adapter:

- **Brand:** Kircuit
- **Input Voltage:** 100-240V AC
- **Output Voltage:** 12 Volts
- **Output Current:** Up to 10 Amps
- **Output Wattage:** 120 Watts
- **Connector Type:** Barrel Plug
- **Color:** Black
- **Compatible Devices:** EcoXGear Soundextreme GDI-EXSNDXTR01 SE26 Soundbar Speaker

Note: The adapter provides 12V output suitable for devices requiring up to 10A (120W). The 500W rating mentioned in some product descriptions typically refers to the peak power handling of the compatible soundbar speaker, not the adapter's continuous output.

9. WARRANTY AND SUPPORT

This Kircuit product is designed for reliability and performance. For warranty information or technical support, please refer to the documentation provided with your purchase or contact Kircuit customer service directly. Ensure you have your product model number (B0CT33GKG8) and purchase details available when contacting

support.

For further assistance, please visit the Kircuit official website or contact your retailer.