

[Manuals.plus](#) /

> [Kircuit](#) /

> Kircuit 2Pin 5V AC/DC Adapter Instruction Manual for Andis CNG-1 Article# 65915 Nail Grinder

Kircuit 2Pin 5V AC/DC Adapter

Kircuit 2Pin 5V AC/DC Adapter Instruction Manual

Model: 2Pin 5V AC/DC Adapter | Brand: Kircuit

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Kircuit 2Pin 5V AC/DC Adapter. This adapter is designed to convert standard AC power into the DC power required by your compatible device, such as the Andis CNG-1 Article# 65915 Cord/Cordless Animal Nail Grinder. It allows you to operate your device or charge its battery from electrical power outlets. The adapter has been validated and tested to ensure compatibility and reliable performance.

Key features include a 100% brand new, high-quality AC/DC power charger, wide input voltage range (100V-240V AC), and built-in dynamic IC, charger IC, and power fuse for rapid charging and overcharge protection.

2. SAFETY INFORMATION

- Read all instructions before use.
- Do not expose the adapter to water, rain, or excessive moisture.
- Use only with compatible devices as specified. Using with incompatible devices may cause damage or injury.
- Ensure the adapter is plugged into a properly grounded and accessible electrical outlet.
- Do not disassemble, modify, or attempt to repair the adapter. Refer servicing to qualified personnel.
- Keep out of reach of children.
- Unplug the adapter from the outlet when not in use or during electrical storms.
- Ensure adequate ventilation around the adapter during operation to prevent overheating.

3. PACKAGE CONTENTS

Your package should contain the following item:

- 1 x Kircuit 2Pin 5V AC/DC Adapter



This image displays the Kircuit AC/DC adapter, highlighting its integrated power cord with a length of 6.5 feet, which provides ample reach for various setups.

4. SETUP

Follow these steps to set up your Kircuit AC/DC Adapter:

1. Identify the charging port on your compatible device (e.g., Andis CNG-1 Nail Grinder).
2. Carefully insert the barrel plug of the Kircuit adapter into your device's charging port. Ensure a snug and secure connection.
3. Plug the 2-pin AC plug of the adapter into a standard 100V-240V AC electrical wall outlet or power strip.
4. Verify that the adapter is firmly seated in both the device and the power outlet.



This image shows the Kircuit AC/DC adapter with its 2-pin plug inserted into a standard power strip, demonstrating how to connect it to an electrical outlet for power.

5. OPERATING INSTRUCTIONS

Once the adapter is properly connected to both the power source and your device, it will automatically begin to supply power or charge the device's battery. No further action is typically required from the user for basic operation.

- Observe your device's charging indicator (if available) to confirm that it is receiving power or charging.
- The adapter is designed for continuous use, but it is recommended to disconnect it when the device is fully charged or not in use for extended periods.



A close-up view of the Kircuit AC/DC adapter, highlighting its label which details the input (100-240V AC, 50/60Hz, 0.3A) and output (5V DC) specifications.

6. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners, aerosols, or harsh chemicals.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid wrapping the cord too tightly around the adapter, as this can damage the cable.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as cuts, frayed wires, or bent pins. If damage is found, discontinue use immediately.

7. TROUBLESHOOTING

If you encounter issues with your Kircuit AC/DC Adapter, refer to the following common problems and solutions:

- **Device not powering on or charging:**
 - Ensure the adapter's barrel plug is fully inserted into your device's charging port.
 - Verify that the 2-pin AC plug is securely connected to a functional electrical outlet. Test the outlet with another device if unsure.
 - Check for any visible damage to the adapter's cable or connectors. If damaged, discontinue use.
 - Confirm that your device is compatible with a 5V DC power supply and the adapter's barrel plug size.
- **Adapter feels excessively hot:**
 - It is normal for the adapter to feel slightly warm during operation. However, if it becomes excessively hot, emits smoke, or produces a burning smell, immediately disconnect it from the power outlet and your device.
 - Ensure the adapter is not covered or placed in an enclosed space that restricts airflow.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Brand	Kircuit
Input Voltage	100V-240V AC, 50/60Hz, 0.3A
Output Voltage	5V DC
Main Power Connector Type	2 Pin (US Standard)
Device Connector Type	Barrel Plug
Cord Length	6.5 feet (approx. 2 meters)
Compatible Devices	Andis CNG-1 Article# 65915, AN65915 Groomers, E-TEK ZDJ050100US Lithium-ion Battery Charger
Special Features	Built-in Dynamic IC, Charger IC & Power fuse for rapid charging and overcharge protection.

9. WARRANTY AND SUPPORT

This Kircuit product is covered by a standard manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary. Please retain your proof of purchase for warranty claims.

For technical assistance, troubleshooting beyond this manual, or to inquire about warranty service, please contact Kircuit customer support through your original retailer or visit the official Kircuit website for contact information.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CT368SCQ>

More documents and user manuals: **<https://manuals.plus/>**