

[Manuals.plus](#) /

> [Kircuit](#) /

> Kircuit AC/DC Adapter User Manual

Kircuit Tresanti 1646074, 1645976, ODP720-D908, ODP720-D913

Kircuit AC/DC Adapter User Manual

Compatible with Tresanti 1646074, 1645976, ODP720-D908, ODP720-D913 Adjustable Height Desks

INTRODUCTION

This manual provides essential information for the safe and effective use of your Kircuit AC/DC Adapter. This adapter is designed to convert AC power from a wall outlet into the DC power required by compatible devices, such as Tresanti adjustable height desks. It serves as a reliable power source for operating your device or charging its battery.

SAFETY INFORMATION

- Always ensure the adapter's voltage and current ratings match your device's requirements.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to severe impact.
- Do not attempt to open or modify the adapter. Refer all servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Kircuit AC/DC Power Adapter
- 2 x Power Cords (one for AC input, one for DC output)



Image: The Kircuit AC/DC power adapter unit shown with its two accompanying power cords. One cord connects the adapter to a wall outlet, and the other connects the adapter to the compatible device.

SETUP

1. **Connect the AC Input Cord:** Take the power cord with the two-prong AC plug (NEMA 1-15P) and the C7 connector. Insert the C7 connector firmly into the AC input port on the Kircuit AC/DC adapter unit.
2. **Connect the DC Output Cord:** Take the power cord with the barrel plug connector. Insert the barrel plug into the DC output port on the Kircuit AC/DC adapter unit.
3. **Plug into Wall Outlet:** Insert the two-prong AC plug into a standard 100V-240V AC electrical wall outlet.
4. **Connect to Device:** Insert the barrel plug from the DC output cord into the power input port of your compatible device (e.g., Tresanti adjustable height desk).



Image: The Kircuit AC/DC power adapter unit is shown connected to a wall outlet and extending to a device, illustrating a typical setup for use.

OPERATING

Once properly connected, the Kircuit AC/DC adapter will supply power to your device. A small indicator light on the adapter unit may illuminate to confirm it is receiving power.

- The adapter is designed for continuous operation within its specified voltage and current limits.
- It features built-in dynamic IC, charger IC, and power fuse for rapid charging and overcharge protection, ensuring safe operation for your connected device.



Image: The Kirccuit AC/DC power adapter unit with its dimensions labeled (4.2 inches length, 1.8 inches width, 1.2 inches height). The image also highlights an anti-interference magnetic ring on the output cable, designed for system reliability and stability.

MAINTENANCE

- **Cleaning:** Disconnect the adapter from all power sources and devices before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid wrapping the cords too tightly around the adapter unit to prevent damage to the cables.
- **Inspection:** Periodically inspect the adapter and cords for any signs of damage, such as frayed wires, cracked casing, or bent pins. If damage is found, discontinue use immediately.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not receiving power	Adapter not plugged in correctly; faulty outlet; damaged adapter/cords; incompatible device.	Ensure all connections are secure. Try a different wall outlet. Inspect adapter and cords for damage. Verify device compatibility.

Problem	Possible Cause	Solution
Adapter feels excessively hot	Overload; poor ventilation; internal fault.	Ensure the device's power requirements do not exceed the adapter's output. Place the adapter in a well-ventilated area. If overheating persists, discontinue use.
Indicator light not on	No power from outlet; loose connection; adapter fault.	Check wall outlet with another device. Re-seat all connections. If still no light, the adapter may be faulty.

SPECIFICATIONS

Feature	Detail
Brand	Kircuit
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Input Voltage	100-240V AC
Connector Type	Barrel Plug
Compatible Devices	TRESANTI 1646074, 1645976, GELLAR SIT/STAND, ODP720-D908, ODP720-D913
Color	Black
Included Components	2 x Power Cords
Special Feature	100% Brand New, High Quality AC/DC Power Charger (non-OEM)
Total USB Ports	1 (Note: This adapter primarily uses a barrel plug for power output, the USB port specification might refer to an internal component or a general product line feature.)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CT36NTVX>

More documents and user manuals: **<https://manuals.plus/>**