

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PEACHAR](#) /

› [Dog Training Collar, Dog Shock Collar with Remote Control, Shock Collar for Large Medium Dogs 40-120lbs Waterproof, Training Collar for Dogs with Beep Vibration Shock and Security Lock Instruction Manual](#)

## PEACHAR X200

# PEACHAR Dog Training Collar Instruction Manual

Model: X200

## INTRODUCTION

Thank you for choosing the PEACHAR Dog Training Collar. This manual provides comprehensive instructions for the safe and effective use of your new training system. Designed for large to medium dogs weighing 40-120 lbs, this collar offers multiple training modes to help you establish clear communication and reinforce desired behaviors with your pet. Please read this manual thoroughly before operation.

## PRODUCT OVERVIEW

The PEACHAR Dog Training Collar system includes a remote transmitter and a receiver collar. The remote allows you to control various training modes, while the receiver collar delivers the chosen stimulation to your dog.



Image: The PEACHAR Dog Training Collar system, showing the remote transmitter and the receiver collar.

#### **Included Components:**

- 1 x Remote Transmitter
- 1 x Receiver Collar
- 1 x USB Charging Cable (split for simultaneous charging)
- 1 x Test Light Tool
- 2 x Long Contact Points

- 2 x Long Silicone Caps
- 1 x User Guide

## 2-Year Free Replacement Promise

- 1 x Remote
- 1 x Receiver
- 1 x User Manual
- 1 x Charging Cable
- 1 x Test Light Tool
- 2 x Long Contact Points
- 2 x Long Silicone caps
- 1 x Colorful User Guide



Image: A visual representation of all components included in the PEACHAR Dog Training Collar package.

## SETUP

---

### 1. Charging the Devices

Before first use, fully charge both the remote transmitter and the receiver collar. The included USB cable allows for simultaneous charging.

- Connect the split USB charging cable to both the remote and the receiver.
- Plug the USB end into a compatible USB power adapter (not included).
- Charging time is approximately 1.5 hours.
- The remote display will show battery levels for both devices.



Image: The remote and collar connected to the USB charging cable, illustrating the charging process.



Image: The remote's digital display showing the battery levels for both the remote and the receiver collar.

## 2. Adjusting the Collar Strap

The collar strap is adjustable and can be cut to fit your dog's neck size. It is suitable for dogs weighing 40-120 lbs with neck measurements ranging from 8 to 27 inches.

- Ensure the collar fits snugly but comfortably around your dog's neck. You should be able to fit two fingers between the collar and your dog's neck.
- If the strap is too long, you can trim it to the appropriate length.



## 3. Attaching Contact Points

Select the appropriate contact points (long or short) based on your dog's coat length to ensure proper contact with the skin. For added comfort and safety, use the silicone caps over the contact points.

Video: An official product video demonstrating the features and usage of the Dog Training Collar with Remote Control, including the contact

points.

## OPERATING INSTRUCTIONS

### 1. Training Modes

The PEACHAR Dog Training Collar offers four distinct training modes:

- **Beep Tone:** Delivers an audible sound.
- **Vibration:** Offers 8 adjustable levels of vibration.
- **Shock:** Provides 18 adjustable levels of static stimulation.
- **Shock Boost:** Delivers an additional 10% higher shock level for immediate attention.



Image: Illustration of the four training modes: Beep Tone, Vibration (1-8 levels), Safe Shock (1-18 levels), and Shock Boost (10% higher).

### 2. Remote Control Range and Security

The remote control has an effective range of up to 2300 feet in open spaces, allowing for flexible training both indoors and

outdoors. It features a security keypad lock to prevent accidental activation.

- To lock the keypad, slide the security switch on the side of the remote.
- This prevents unintended commands during transport or handling.

## 2300FT REMOTE RANGE (Open Space)



### One-Key Locking, No Accidental Shock

Unlock  
↑  
↓ Lock



Image: A person using the remote control with a dog in the background, highlighting the 2300ft remote range and the one-key locking feature.

## Security Keypad Lock

One-Key Locking to Prevent Accidental Opening



Image: A detailed view of the remote's security keypad lock, designed to prevent accidental button presses.

### 3. Multi-Dog Training

The system supports training up to three dogs simultaneously with a single remote transmitter. Each dog can be assigned a dedicated channel.

- Use the channel selection buttons on the remote to switch between dogs.
- The remote features a memory function for settings, eliminating the need to reset for each dog.

### 3 Dog Channels

Allows training of 3 dogs of all breeds or sizes, using a single remote transmitter simultaneously




Image: A visual demonstrating the capability to train up to three dogs using a single remote transmitter.

## MAINTENANCE

### 1. Waterproof Design

The receiver collar features an IP68 waterproof design, allowing your dog to play freely in water without damaging the device.

# IP68 Waterproof Receiver Collar



Your pet can enjoy water-related activities freely



Image: The dog training collar submerged in water, illustrating its IP68 waterproof rating.

## 2. Battery Life

The receiver can last up to 7 days on a single charge, while the transmitter can last for an impressive 35 days. Monitor battery power on the remote display.

## 3. Care Instructions

To ensure the longevity of your device, keep it in a dry place when not in use. Regularly inspect the collar and contact points for cleanliness and wear.

## TROUBLESHOOTING

If you encounter issues with your PEACHAR Dog Training Collar, please refer to the following common solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Collar not charging	Faulty charging cable or port; internal battery issue.	Ensure the charging cable is securely connected. Try a different USB power source. If the issue persists, contact customer support for warranty replacement.
Remote not turning on/working	Low battery; remote malfunction.	Charge the remote fully. Ensure the security keypad lock is disengaged. If the remote remains unresponsive, contact customer support.
Collar not responding to remote	Not paired correctly; out of range; incorrect channel selected.	Ensure both devices are powered on. Verify the remote and collar are on the same channel. Move closer to your dog to ensure you are within the effective range. Refer to the pairing instructions in the full user manual if re-pairing is needed.

## SPECIFICATIONS

---

- **Model:** X200
- **Brand:** PEACHAR
- **Training Modes:** Beep, Vibration (8 levels), Shock (18 levels), Shock Boost
- **Remote Range:** Up to 2300 feet (open space)
- **Waterproof Rating:** IP68 (Receiver Collar)
- **Battery Type:** 2 Lithium Ion batteries (included)
- **Charging Time:** Approximately 1.5 hours
- **Battery Life (Remote):** Up to 35 days
- **Battery Life (Receiver):** Up to 7 days
- **Collar Fit:** Neck measurements 8-27 inches, suitable for dogs 40-120 lbs
- **Material:** Acrylonitrile Butadiene Styrene
- **Item Weight:** 9.9 ounces (281 Grams)
- **Product Dimensions:** 5.51 x 1.57 x 0.71 inches

## WARRANTY AND SUPPORT

---

PEACHAR offers a **2-YEAR WORRY FREE Replacement Warranty** for this product. For any questions, concerns, or warranty claims, please contact PEACHAR customer service. Details for contacting support can typically be found on the product packaging or the official PEACHAR website.



Image: A graphic highlighting the 2-Year Replacement Promise and 24/7 Customer Service offered by PEACHAR.