

## GZWANHANGMY M2-2-1-1

# GZWANHANGMY Mini Soft Warm LED Night Light with Timer (Model M2-2-1-1) User Manual

Model: M2-2-1-1 | Brand: GZWANHANGMY

## 1. INTRODUCTION

Thank you for choosing the GZWANHANGMY Mini Soft Warm LED Night Light. This portable, battery-operated glass lamp is designed to provide a soft, warm glow with the convenience of a built-in timer function. Its compact size and wireless operation make it suitable for various indoor and outdoor settings, offering ambient lighting where needed. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your product.

## 2. SAFETY INFORMATION

- Use only the specified battery type (2 x AAA batteries). Do not mix old and new batteries, or different types of batteries.
- Ensure batteries are inserted with correct polarity (+/-).
- Remove batteries if the lamp will not be used for an extended period to prevent leakage.
- Keep the lamp away from extreme temperatures and direct sunlight.
- The lamp features a glass shade. Handle with care to prevent breakage.
- Although rated as waterproof, avoid submerging the lamp in water. Clean with a damp cloth only.
- This product is not a toy. Keep out of reach of children.

## 3. PACKAGE CONTENTS

- 1 x GZWANHANGMY Mini Soft Warm LED Night Light (Model M2-2-1-1)

*Note: AAA batteries are not included and must be purchased separately.*

## 4. SETUP

### 4.1 Battery Installation

1. Locate the battery compartment cover on the bottom of the lamp.
2. Gently slide or unclip the battery cover to open it.
3. Insert 2 x AAA batteries, ensuring the positive (+) and negative (-) terminals match the indicators inside the compartment.
4. Replace the battery compartment cover securely.



Figure 1: Battery compartment on the underside of the lamp, showing space for two AAA batteries.



Figure 2: The compact size of the night light, emphasizing its portability and battery operation.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off and Timer Activation

The GZWANHANGMY Mini LED Night Light features a simple toggle switch on the bottom for operation. This switch also activates the integrated timer function.

1. Locate the toggle switch on the bottom of the lamp, near the battery compartment.
2. Flip the switch to the "ON" position. The light will illuminate with a soft, warm glow.
3. Once turned on, the 6-hour timer function is automatically activated. The light will remain on for 6 hours, then automatically turn off for 18 hours, repeating this cycle daily.
4. To turn the light off manually and reset the timer, flip the switch to the "OFF" position.



6h / 18h

AUTO TIME

6 HOURS ON / 18 HOURS OFF

Figure 3: Illustration of the automatic 6-hour on / 18-hour off timer cycle.

## 5.2 Placement and Usage

The compact and wireless design allows for versatile placement:

- **Bedside Table:** Provides a gentle light for nighttime without disturbing sleep.
- **Bookshelf:** Adds an aesthetic touch and subtle illumination.
- **Bathroom:** Offers soft lighting for navigating in the dark.
- **Entryway/Hallway:** Can serve as a guiding light.
- **Outdoor (Covered Areas):** Suitable for patios or decks, given its waterproof rating, but avoid direct exposure to heavy rain.



Figure 4: Examples of the night light's versatile placement in different rooms.



Figure 5: The night light providing ambient illumination on a nightstand.



Figure 6: Two night lights placed together, demonstrating their aesthetic contribution to a space.

## 6. MAINTENANCE

### 6.1 Cleaning

- Ensure the lamp is turned off before cleaning.
- Wipe the exterior surfaces with a soft, slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or glass.
- Avoid getting water into the battery compartment or internal electronics.

### 6.2 Battery Replacement

When the light dims or stops working, it is time to replace the batteries. Follow the battery installation steps in Section 4.1.

## 7. TROUBLESHOOTING

| Problem                                 | Possible Cause                                 | Solution                                                                                                                           |
|-----------------------------------------|------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| Light does not turn on.                 | Batteries are dead or incorrectly inserted.    | Check battery polarity and replace with fresh AAA batteries.                                                                       |
| Light flickers or is dim.               | Low battery power.                             | Replace with fresh AAA batteries.                                                                                                  |
| Timer function not working as expected. | Switch was turned off/on, resetting the timer. | Ensure the switch remains in the "ON" position for the timer to cycle correctly. The timer resets each time the switch is toggled. |
| Glass shade is broken.                  | Accidental impact.                             | Discontinue use and contact customer support for replacement options.                                                              |

## 8. SPECIFICATIONS

|                      |                                                          |
|----------------------|----------------------------------------------------------|
| Brand                | GZWANHANGMY                                              |
| Model Name           | M2-2-1-1                                                 |
| Product Dimensions   | 2.56"D x 2.56"W x 4.33"H (6.5 cm D x 6.5 cm W x 11 cm H) |
| Item Weight          | 7.2 ounces (204 grams)                                   |
| Material             | Glass (Shade and Base)                                   |
| Light Source Type    | LED                                                      |
| Power Source         | Battery Powered (2 x AAA batteries, not included)        |
| Voltage              | 3 Volts                                                  |
| Special Features     | Cordless, Auto On/Off (6h/18h timer), Waterproof         |
| Control Method       | Toggle Switch                                            |
| Indoor/Outdoor Usage | Indoor, Outdoor (Waterproof)                             |
| Style                | Art Deco, Vintage                                        |

## 9. WARRANTY AND SUPPORT

GZWANHANGMY is committed to providing high-quality products. If you encounter any issues with your Mini Soft Warm LED Night Light, please contact our customer support team.

We offer an after-sales guarantee. For any product problems, please reach out to us. We aim to reply within 24 hours and provide a satisfactory solution.

For support, please refer to the contact information provided with your purchase or visit the official GZWANHANGMY website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**