

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Good Housekeeping](#) /

› [Good Housekeeping Lanier Falls 52-inch Ceiling Fan \(Model 63011R-BN\) Instruction Manual](#)

Good Housekeeping 63011R-BN

Good Housekeeping Lanier Falls 52-inch Ceiling Fan (Model 63011R-BN) Instruction Manual

Your guide to installation, operation, and maintenance for optimal performance.

INTRODUCTION

Thank you for choosing the Good Housekeeping Lanier Falls 52-inch Ceiling Fan. This fan is designed to provide efficient air circulation and integrated lighting, enhancing the comfort and aesthetics of your living space. This manual provides essential information for the safe and proper installation, operation, and maintenance of your new ceiling fan.



Image: The Good Housekeeping Lanier Falls 52-inch Ceiling Fan with brushed nickel finish and five reversible blades.

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to follow these instructions could result in electric shock, fire, or personal injury.

- Ensure the power is turned off at the circuit breaker before installation or servicing.

- All wiring must be in accordance with national and local electrical codes.
- The mounting bracket must be securely fastened to a ceiling joist or an outlet box approved for ceiling fan support (at least 35 lbs).
- Do not bend blade holders during installation or cleaning.
- Keep hands clear of rotating fan blades.
- This fan is for indoor use only.

PACKAGE CONTENTS

Verify that all components are present before proceeding with installation.



Image: Exploded view diagram showing the fan's components, including the motor housing, blades, light kit, and remote control.

- Motor Housing Assembly
- 5 Reversible Fan Blades
- Mounting Bracket
- Downrod Assembly
- Canopy
- Light Kit with Integrated LED
- Frosted Glass Shade
- Remote Control with Wall Mount
- Hardware Pack (screws, washers, wire nuts)

SETUP AND INSTALLATION

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before starting.

1. **Mounting Bracket Installation:** Secure the mounting bracket to an approved ceiling electrical box or a structural support capable of holding the fan's weight (minimum 35 lbs).
2. **Downrod Assembly:** Insert the downrod through the canopy and motor housing. Secure with the provided pin and screw.
3. **Wiring:** Connect the fan's electrical wires to the household wiring according to local electrical codes. Ensure all connections are secure using wire nuts.
4. **Motor Housing Attachment:** Carefully lift the fan assembly and hang it on the mounting bracket. Secure the

motor housing to the bracket.

5. **Blade Attachment:** Attach each of the five reversible blades to the motor housing using the provided screws. Ensure they are firmly secured.
6. **Light Kit Installation:** Connect the light kit wiring to the fan's internal wiring. Secure the light kit to the bottom of the motor housing.
7. **Glass Shade Installation:** Twist the frosted glass shade into place over the integrated LED light.
8. **Remote Control Pairing:** Follow the instructions included with the remote control to pair it with your fan.



Image: A detailed view of the fan's brushed nickel motor housing and the integrated LED light with its frosted glass shade.

OPERATING INSTRUCTIONS

Your Lanier Falls ceiling fan is operated using the included remote control.



Image: A graphic highlighting the fan's key features: reversible blades, included remote control, and integrated LED lighting.

Remote Control Functions:

- **Power Button:** Turns the fan and light ON/OFF.
- **Fan Speed Control:** Adjusts the fan speed through 3 settings (Low, Medium, High).
- **Light ON/OFF:** Toggles the integrated LED light.
- **Light Dimming:** Hold the light button to dim or brighten the light.
- **Color Temperature Adjustment:** Some models allow adjustment of light color temperature (e.g., warm white to cool white). Refer to your remote for specific buttons.
- **Reverse Function:** Changes the direction of blade rotation for seasonal use.
 - **Summer Mode (Downward Airflow):** Blades rotate counter-clockwise to create a cooling breeze.
 - **Winter Mode (Upward Airflow):** Blades rotate clockwise to circulate warm air trapped near the ceiling.

Ensure the remote control batteries are installed correctly. The remote can be conveniently stored in its included wall mount.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** The reversible blades can be cleaned with a dry or slightly damp cloth.
- **Light Kit:** The integrated LED light does not require bulb replacement. Clean the frosted glass shade with a soft, dry cloth.
- **Tightness Check:** Periodically check all screws and connections for tightness. Re-tighten as necessary.
- **Lubrication:** The fan's motor is permanently lubricated and does not require additional oiling.

TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start.	No power, loose wiring, remote not paired.	Check circuit breaker. Verify all wire connections. Re-pair remote control.
Light does not work.	Loose wiring, integrated LED failure.	Check light kit wiring. If LED is faulty, contact customer support.
Fan is noisy (humming/clicking).	Loose screws, motor issue, improper installation.	Ensure all mounting and blade screws are tight. Verify proper installation. If noise persists, contact support.
Fan wobbles.	Loose blades, unbalanced blades, loose mounting.	Check all blade screws. Ensure blades are not bent. Verify mounting bracket is secure.
Light dims randomly.	Electrical interference, faulty light kit.	Ensure stable power supply. If issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Good Housekeeping
Model Name	Lanier Falls
Model Number	63011R-BN

Feature	Detail
Color	Brushed Nickel
Style	Lanier
Product Dimensions	52"D x 52"W x 11.5"H
Number of Blades	5 (Reversible)
Light Source	Integrated LED
Control Method	Remote Control
Power Source	Hardwired (AC)
Voltage	120V
Wattage	75 watts
Air Flow Capacity	3778 Cubic Feet Per Minute
Item Weight	16.87 Pounds
Indoor/Outdoor Usage	Indoor
UPC	877697002101




Image: Energy Guide label providing estimated yearly energy cost and airflow capacity details.

WARRANTY INFORMATION

The Good Housekeeping Lanier Falls Ceiling Fan comes with the following warranty coverage:

- Lifetime Motor Warranty:** The fan motor is covered for the lifetime of the product.
- 2-Year Light Kit Warranty:** The integrated LED light kit is covered for two years from the date of purchase.
- 2-Year Parts Warranty:** All other parts are covered for two years from the date of purchase.

Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the documentation included with your product or visit the Good Housekeeping website.


CUSTOMER SUPPORT


For technical assistance, replacement parts, or warranty inquiries, please contact Good Housekeeping customer support.

- **Brand:** Good Housekeeping
- **Manufacturer:** OceanAire HomeGoods Company
- **Website:** ghseal.com (for warranty details)
- Refer to your product packaging for specific contact numbers or email addresses.

© 2024 Good Housekeeping. All rights reserved.

Related Documents - 63011R-BN

	<p><u>Good Housekeeping Retro Pedestal Fan Owner's Manual</u> Owner's manual for the Good Housekeeping Retro Pedestal Fan, detailing assembly, operation, safety, maintenance, troubleshooting, and warranty information.</p>
	<p><u>3 Speed Universal Ceiling Fan Remote Control FAN61T-3SP1 User Manual</u> Comprehensive guide to operating and setting up the GOOD HOUSEKEEPING 3 Speed Universal Ceiling Fan Remote Control (Model FAN61T-3SP1). Learn about remote functions, code synchronization, and troubleshooting.</p>
	<p><u>Good Housekeeping Bath Ventilator with Light Installation Guide</u> This installation guide provides instructions for installing a Good Housekeeping Bath Ventilator with Light. It includes safety warnings, part identification, and maintenance tips.</p>
	<p><u>Good Housekeeping Bath Ventilator with Light Installation Guide</u> This guide provides detailed instructions for installing the Good Housekeeping Bath Ventilator with Light, including safety warnings, maintenance procedures, troubleshooting tips, and warranty information for models 90052, 90053, and 90054.</p>

	<p><u>Good Housekeeping Buckingham Bath Ventilator with Light and Night Light Owner's Manual</u></p> <p>Comprehensive owner's manual for the Good Housekeeping Buckingham Bath Ventilator, detailing installation, maintenance, troubleshooting, and warranty information for models 90063, 90064, 90065, and 90068.</p>
	<p><u>Good Housekeeping Retro Oscillating Fan Owner's Guide</u></p> <p>Owner's guide for the Good Housekeeping Retro Oscillating Fan, providing detailed instructions on safety, setup, operation, maintenance, troubleshooting, and warranty for models 92602 through 92606.</p>