

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [FSE](#) /

> [FSE 373-LX-PNADJ-LW Pneumatic Adjustable-Height Lectern/Mobile Standing Desk User Manual](#)

FSE 373-LX-PNADJ-LW

FSE 373-LX-PNADJ-LW Pneumatic Adjustable-Height Lectern/Mobile Standing Desk User Manual

PRODUCT: PNEUMATIC ADJUSTABLE-HEIGHT LECTERN/MOBILE STANDING DESK

Model: 373-LX-PNADJ-LW

1. Introduction

This manual provides essential information for the safe and efficient use of your FSE 373-LX-PNADJ-LW Pneumatic Adjustable-Height Lectern/Mobile Standing Desk. Please read these instructions thoroughly before initial use and retain them for future reference. This product is designed for versatility in various environments, including office, education, training, and healthcare settings.

2. Safety Information

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of the desktop.
- Keep hands and fingers clear of moving parts during height adjustment.
- Use the desk on a stable, level surface to prevent tipping.
- Avoid placing hot items directly on the desktop surface without protection.
- Do not allow children to operate the height adjustment mechanism unsupervised.

3. Package Contents

Verify that all the following components are present in your package:

- Desktop with integrated paper stopper
- Pneumatic column assembly
- Base with casters and leveling feet
- Assembly hardware (if applicable)
- Built-in USB Port (integrated into the desktop)

If any items are missing or damaged, please contact customer support.

4. Setup

The FSE 373-LX-PNADJ-LW desk is designed for minimal assembly. Please follow these steps for initial setup:

1. Carefully remove all components from the packaging.
2. Place the base on a flat, stable surface.
3. Attach the pneumatic column to the base and desktop according to the included quick-start guide (if provided). Ensure all connections are secure.
4. Verify that the casters are locked if you intend for the desk to remain stationary, or unlocked for mobility.
5. Inspect the desk for any signs of damage or loose parts before first use.



Figure 1: FSE 373-LX-PNADJ-LW Lectern/Mobile Standing Desk in its standard configuration.

5. Operating Instructions

This desk features pneumatic height adjustment and a lever-adjustable desktop for optimal ergonomic positioning.

5.1. Height Adjustment

To adjust the height of the desk:

- Locate the pneumatic foot pedal at the base of the column.
- To raise the desk, gently press the foot pedal while applying slight upward pressure to the desktop.
- To lower the desk, gently press the foot pedal while applying slight downward pressure to the desktop.
- Release the foot pedal to lock the desk at the desired height.



Figure 2: Desk adjusted to a lower height setting.



Figure 3: Desk adjusted to a higher height setting.

5.2. Desktop Angle Adjustment

The desktop/presenter's shelf can be adjusted to various angles:

- Locate the lever mechanism typically found beneath the desktop.
- Engage the lever to unlock the desktop angle.
- Adjust the desktop to one of the preset angles: 10°, 20°, 30°, or 90°.
- Release the lever to lock the desktop securely in place.



Figure 4: Desk with a laptop on the desktop, demonstrating an angled position.

5.3. Integrated Paper Stopper

The desktop includes an integrated paper stopper to prevent materials and equipment from sliding off when the desktop is angled.

6. Maintenance

Regular maintenance ensures the longevity and proper function of your desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth and a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and fasteners to ensure they are tight.
- **Casters:** Clean casters regularly to remove debris that may hinder movement.

7. Troubleshooting

If you encounter issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not adjust height	Foot pedal not fully engaged or pneumatic cylinder issue.	Ensure the foot pedal is pressed completely. If the issue persists, contact customer support.
Desktop angle does not hold	Angle adjustment lever not fully engaged.	Ensure the lever is released and locked after setting the desired angle.
Desk is unstable or wobbly	Loose connections or uneven surface.	Check all assembly connections and tighten if necessary. Ensure the desk is on a level surface. Adjust leveling feet if present.

8. Specifications

Feature	Detail
Brand	FSE
Model Number	373-LX-PNADJ-LW
Item Weight	27 Pounds
Base Material	Stainless Steel
Top Material Type	Stainless Steel
Finish Type	Polished
Special Feature	Collapsible
Included Components	Built-in USB Port
Assembly Required	No
Style	Modern
Shape	Rectangular
Desk Design	Computer Desk

9. Warranty and Support

FSE products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official FSE website. For technical support, replacement parts, or any inquiries, please contact FSE customer service through their official channels.



