

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [STANLEY](#) /

› [Stanley Quick Flip GO Water Bottle 24 oz Instruction Manual](#)

STANLEY Quick Flip GO Bottle 24 OZ

Stanley Quick Flip GO Water Bottle 24 oz Instruction Manual

Model: Quick Flip GO Bottle 24 OZ

INTRODUCTION

The Stanley Quick Flip GO Water Bottle is designed for durability and convenience, keeping your beverages at the desired temperature for extended periods. Crafted from 18/8 stainless steel with double-wall vacuum insulation, this bottle is leakproof, BPA-free, and built for life's adventures. Its push-button lid allows for easy one-handed use, making it ideal for travel, sports, and daily hydration.





Image: Stanley Quick Flip GO Water Bottle, 24 oz, Pomelo color, with the lid securely closed.

KEY FEATURES

- **Double-Wall Vacuum Insulation:** Keeps drinks hot for up to 8 hours, cold for up to 12 hours, and iced for up to 40 hours.
- **18/8 Stainless Steel Construction:** Ensures durability and resistance to wear.
- **Leakproof Push-Button Lid:** Designed for one-handed operation with a secure latch to prevent spills.
- **BPA-Free Materials:** All components are made without BPA for safe consumption.
- **Dishwasher Safe:** All parts are designed for easy cleaning.
- **Car Cup Holder Compatible:** Slim design fits most standard car cup holders.



**18/8 STAINLESS
STEEL**



**DISHWASHER
SAFE**



**LEAKPROOF
+ PACKABLE**



BPA FREE



**DOUBLE-WALL
VACUUM INSULATION**



**FLIP STRAW LID
FOR EASY SIPPING**



Image: Infographic highlighting the bottle's features, including insulation, material, and safety.

SETUP

Initial Cleaning

1. Before first use, disassemble the lid components.
2. Wash all parts (bottle, lid, and any removable seals) with warm, soapy water.
3. Rinse thoroughly and allow to air dry completely before reassembling.





Image: The water bottle with its lid separated into components, illustrating how to disassemble for thorough cleaning.

OPERATING INSTRUCTIONS

Filling the Bottle

- Unscrew the lid from the bottle.
- Fill the bottle with your desired beverage. Do not overfill; leave space for the lid.
- Securely screw the lid back onto the bottle until it is hand-tight.

Using the Push-Button Lid

1. To prevent accidental opening, ensure the metal latch is engaged over the push button.
2. To drink, disengage the metal latch by pulling it back.
3. Press the large push button to flip open the mouthpiece.
4. After drinking, push the mouthpiece back down until it clicks securely into place.
5. For added security, re-engage the metal latch over the push button.



Image: The water bottle with its push-button lid open, revealing the drinking spout.

Carrying the Bottle

The integrated carry loop on the lid allows for easy transport. You can hold it by hand or attach it to a backpack or bag using a carabiner (not included).

MAINTENANCE AND CLEANING

Dishwasher Cleaning

All components of the Stanley Quick Flip GO Water Bottle are dishwasher safe. Place the bottle and disassembled lid parts on the top rack of your dishwasher for best results.

Hand Washing

- Disassemble the lid completely.
- Wash the bottle interior with a bottle brush, warm water, and mild dish soap.
- Clean all lid components thoroughly, paying attention to seals and crevices, to prevent odor and bacteria buildup.
- Rinse all parts thoroughly with clean water.
- Allow all components to air dry completely before reassembling to prevent moisture buildup.

TROUBLESHOOTING

- **Leaking:** Ensure the lid is screwed on tightly and the mouthpiece is fully closed and latched. Check that all silicone seals are properly seated and free from damage or debris.
- **Poor Temperature Retention:** Verify that the lid is securely closed and sealed. Extreme external temperatures can affect performance; keep the bottle out of direct sunlight or very cold environments when possible.
- **Difficulty Opening/Closing Lid:** Check for any debris obstructing the push-button mechanism or the latch. Ensure the lid is not cross-threaded when screwing it onto the bottle.

SPECIFICATIONS

Feature	Detail
Brand	STANLEY
Model Name	Stanley Quick Flip GO Bottle 24 OZ Pomelo
Capacity	24 Fluid Ounces
Color	Pomelo
Material Type	Stainless Steel
Special Feature	Leakproof
Cap Type	Flip Top Cap
Item Height	11.5 inches
Item Weight	0.95 Pounds

UPC

041604392429

WARRANTY AND SUPPORT

Stanley products are 'BUILT FOR LIFE'. Since 1913, Stanley has promised to provide capable gear for food and drink, built to last a lifetime. This promise is upheld with a lifetime warranty for Stanley products purchased from authorized Stanley Resellers. For support or warranty claims, please visit the official Stanley website or contact their customer service.

SUSTAINABILITY AT STANLEY

Stanley is committed to creating a more sustainable and less disposable world through invention and originality. Their design principles prioritize functionality and durability, ensuring products are built to last a lifetime. Stanley actively uses recycled and upcycled materials, aiming for at least 50% recycled content in their stainless steel products by 2025. They also focus on sustainable packaging, reducing conventional plastic and certifying all paper packaging as sustainable or recycled by 2025. Furthermore, Stanley partners with suppliers who meet high standards of environmental responsibility and invests in communities.



Image: Stanley's commitment to sustainability, highlighting over 100 years of building better products.

Materials & Design

We've been inventing better ways to build for 100 years – sustainable design and materials are how we work.



Image: Focus on sustainable design and materials in Stanley products.

Our Signature Material

Sourcing recycled stainless steel isn't just better for the planet – it's the single most impactful decision our brand can make for what comes next. In 2024, 65% of the materials in our products were recycled content.



Image: Stanley's use of recycled content in their products.