Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PUPKIDS B0CT4PK6CK

PUPKIDS Anti Barking Device (Model B0CT4PK6CK) User Manual

Comprehensive instructions for effective dog barking control.

1. Introduction

Thank you for choosing the PUPKIDS Anti Barking Device. This device is designed to assist in controlling excessive dog barking by emitting an ultrasonic sound that is harmless to pets but effective in deterring unwanted barking. Please read this manual thoroughly before use to ensure proper operation and safety.

2. Important Safety Information

- This device is intended for use with dogs aged 6 months to 8 years.
- Do not use this device on aggressive dogs or dogs with hearing impairments.
- Keep the device out of reach of children.
- Avoid exposing the device to extreme temperatures, direct sunlight, or water.
- The ultrasonic sound is generally inaudible to humans but can be perceived by some individuals. If you experience discomfort, adjust placement or settings.
- This device is designed to be plugged in for continuous operation and does not contain a rechargeable battery.

3. Package Contents

Verify that all items are present in your package:

- PUPKIDS Anti Barking Device
- User Manual (this document)
- Power Cable
- Mounting accessories (if included, e.g., screws, strap)

4. Product Overview

The PUPKIDS Anti Barking Device utilizes advanced ultrasonic technology to detect and deter dog barking. It features

multiple operating modes to adapt to different dog temperaments and environments.



Figure 1: PUPKIDS Anti Barking Device. This image shows the black device with its two ultrasonic emitters and a central microphone sensor. A dog is pictured below, with a "no barking" symbol over its mouth, illustrating the device's function.

Device Components:

- **Ultrasonic Emitters:** Two circular grilles on the front that emit the ultrasonic sound.
- **Microphone Sensor:** Central triangular sensor that detects dog barking.
- **LED Indicator:** Light that indicates operation status.
- **Mode Switch:** Located on the back or side, used to select operating modes.
- **Power Port:** For connecting the power cable.

5. Setup

5.1 Power Connection

1. Connect the provided power cable to the power port on the device.
2. Plug the other end of the power cable into a standard electrical outlet. The device requires continuous power for operation.

3. The LED indicator should illuminate, indicating the device is powered on.

5.2 Placement

Optimal placement is crucial for the device's effectiveness. Consider the following:

- Place the device within 50 feet (approximately 15 meters) of the area where barking occurs.
- Ensure a clear line of sight between the device and the dog. Obstacles like walls, furniture, or dense foliage can reduce effectiveness.
- Position the device at a height similar to the dog's head when standing or sitting.
- For outdoor use, place it in a sheltered area to protect it from rain and direct harsh weather.
- Avoid placing the device near other ultrasonic devices or loud noise sources that could interfere with its operation.

6. Operating the Device

The PUPKIDS Anti Barking Device features 3 adjustable modes to customize its response to barking.

6.1 Mode Selection

Locate the mode switch on the device. Select one of the following modes based on your dog's sensitivity and the environment:

- **Mode 1 (Low Sensitivity):** For dogs that are highly sensitive to ultrasonic sounds or for use in quieter environments.
- **Mode 2 (Medium Sensitivity):** A balanced setting suitable for most dogs and typical environments.
- **Mode 3 (High Sensitivity):** For dogs that are less responsive to ultrasonic sounds or for use in noisier outdoor settings.

It is recommended to start with Mode 1 and gradually increase the sensitivity if needed. Observe your dog's reaction to determine the most effective setting.

6.2 How it Works

When the device detects barking within its 50-foot range, it automatically emits a high-frequency ultrasonic sound. This sound is designed to be unpleasant to dogs, interrupting their barking behavior without causing harm. The sound stops once the barking ceases.
Important Note: Consistency is key. For best results, use the device consistently. Some dogs may adapt quickly, while others may require more time to associate the ultrasonic sound with their barking.

7. Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** When not in use, store the device in a cool, dry place, away from direct sunlight and moisture.
- **Inspection:** Periodically check the power cable for any signs of damage. If damaged, discontinue use and contact customer support.

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device does not turn on.	No power connection.	Ensure the power cable is securely plugged into the device and a working electrical outlet.
Device is not deterring barking.	Incorrect mode selected. Obstructions blocking the signal. Dog is out of range. Dog has hearing issues. Multiple barking dogs.	Try a higher sensitivity mode (Mode 2 or 3). Relocate the device to ensure a clear line of sight to the dog. Ensure the dog is within the 50-foot effective range. Consult a veterinarian if you suspect hearing problems. The device may be less effective in multi-dog households where multiple dogs bark simultaneously. Consider individual training or alternative solutions for such scenarios.
LED indicator is not working.	Device malfunction.	Contact customer support for assistance.

9. Specifications

- **Model:** B0CT4PK6CK
- **Brand:** PUPKIDS
- **Effective Range:** Up to 50 feet (approximately 15 meters)
- **Operating Modes:** 3 adjustable sensitivity levels
- **Power Source:** Plug-in (requires continuous power)
- **Item Weight:** 5.9 ounces (approx. 167 grams)
- **Item Dimensions (L x W x H):** 4.06 x 2.91 x 2.64 inches (approx. 10.3 x 7.4 x 6.7 cm)
- **Target Audience:** Dogs (6 months to 8 years old)
- **Specific Uses:** Behavior modification (barking control)

10. Warranty Information

The PUPKIDS Anti Barking Device is covered by a **12-MONTH** limited warranty from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance. Please retain your proof of purchase for warranty claims.

11. Customer Support

If you have any questions, concerns, or require assistance with your PUPKIDS Anti Barking Device, please contact our customer support team. Refer to the contact information provided with your product packaging or visit the official PUPKIDS website for support details.

© 2024 PUPKIDS. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CT4PK6CK

More documents and user manuals: **https://manuals.plus/**