

Manuals.plus /

› LINSY HOME /

› LINSY HOME Farmhouse 8 Drawers Dresser Instruction Manual

LINSY HOME LH618

LINSY HOME Farmhouse 8 Drawers Dresser Instruction Manual

Model: LH618 | Brand: LINSY HOME

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Anti-Tipping Device:** This dresser includes an anti-falling accessory to prevent injury from unexpected tipping. It is crucial to install this device securely to a wall stud or appropriate anchor point.
- **Stability:** The back of the drawer dresser is equipped with a stabilizing device. Ensure this device is properly installed to enhance the dresser's overall stability and durability.
- **Weight Capacity:** Each drawer is designed to hold up to 55 lbs. Do not exceed this weight limit to prevent damage or instability.
- **Children Safety:** Do not allow children to climb on or play with the dresser. Always secure the dresser to the wall using the provided anti-tip kit.



Premium Edge
Sealing Process

Figure 1.1: Illustration of the anti-tip device installation for enhanced safety.

2. PRODUCT OVERVIEW

The LINSY HOME Farmhouse 8 Drawers Dresser is a versatile storage solution designed for various spaces including bedrooms, living rooms, and hallways. It combines a rustic oak finish with antique metal pulls, offering a modern farmhouse aesthetic.

2.1 Key Features

- **Multifunctional Storage:** Features 8 spacious drawers suitable for clothes, books, and other household items.
- **Durable Construction:** Crafted from high-grade solid wood and P2 grade panels, complemented by sturdy metal glides.
- **Enhanced Durability:** Utilizes a premium edge sealing process for longer service life and resistance to cracking or molding.
- **Safety Features:** Includes an anti-falling accessory and a stabilizing device for secure placement.

2.2 Dimensions and Weight

- **Overall Dimensions:** 15.6"D x 47.2"W x 42.2"H
- **Item Weight:** 100 Pounds
- **Drawer Capacity:** Each drawer holds up to 55 lbs.

Product Size



Figure 2.1: Product dimensions and individual drawer measurements.



15+
Tissue

50+
Socks

30+
Underwear

30+
Snacks

15+
Toys

20+
Shirt

Large storage space



X5

3. SETUP AND ASSEMBLY

Assembly is required for this product. The package includes detailed installation instructions, and all parts and accessories are coded for easy identification. Precise holes ensure accurate and faster assembly.

3.1 Before You Begin

- Unpack all components and verify against the parts list in the included user manual.
- Ensure you have adequate space for assembly.
- Gather necessary tools (e.g., screwdriver, hammer - typically not included).

3.2 Assembly Steps

1. Follow the step-by-step instructions provided in the separate user manual included in the packaging.
2. Pay close attention to the orientation of parts as indicated in the diagrams.
3. Securely fasten all screws and connectors. Do not overtighten.
4. **Important:** Install the anti-tipping device as the final step to secure the dresser to a wall. This is critical for safety.

4. OPERATING INSTRUCTIONS

The LINSY HOME dresser is designed for straightforward use, providing ample storage for various items.

4.1 Drawer Usage


- Gently pull the antique metal finish pulls to open drawers.
- Push drawers firmly to close them completely. The sturdy metal glides ensure smooth operation.
- Distribute weight evenly within drawers and do not exceed the 55 lbs capacity per drawer.

4.2 Storage Recommendations

Utilize the eight drawers for organized storage of clothing, linens, accessories, or other personal items. The design allows for classified storage to keep your belongings tidy.



Figure 4.1: Example of organized storage within a dresser drawer.



Classified storage

Figure 4.2: Illustration of the ample storage capacity.

5. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your LINSY HOME dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Immediately wipe up any spills with a soft, dry cloth to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Temperature and Humidity:** Maintain a stable room temperature and humidity level to prevent wood from warping or cracking.
- **Drawer Glides:** Periodically check and clean the metal drawer glides to ensure smooth operation. If needed, a small amount of silicone lubricant can be applied.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your dresser. For problems not listed here, please contact customer support.

Problem	Possible Cause	Solution
Drawers stick or do not slide smoothly.	Misaligned drawer glides. Obstruction in the drawer track. Overloaded drawer.	Check that the drawer glides are properly aligned and secured. Remove any items obstructing the glides. Reduce the weight in the drawer.
Dresser feels wobbly or unstable.	Loose assembly screws. Anti-tip device not installed or improperly secured. Uneven floor surface.	Tighten all assembly screws. Ensure the anti-tip device is correctly installed and anchored to a wall stud. Place shims under the dresser legs to level it on an uneven floor.
Minor scratches or blemishes on surface.	Normal wear and tear. Accidental impact.	Use a wood repair kit or furniture marker that matches the rustic oak finish. For deeper scratches, consult a professional.

7. SPECIFICATIONS

Attribute	Detail
Brand	LINSY HOME
Model Name	LH618E
Item Model Number	LH618
Product Dimensions	15.6"D x 47.2"W x 42.2"H
Color	Rustic Oak
Room Type	Bedroom, Closet, Entryway, Hallway, Living Room
Product Care Instructions	Wipe with Dry Cloth
Assembly Required	Yes
Item Weight	100 Pounds
Size	15.6"D x 47.2"W x 42.2"H (8 Drawers)
Number of Pieces	1
Manufacturer	LINSY HOME
Global Trade Identification Number (GTIN)	00810147762897
Finish Types	Painted
Batteries Required	No
Included Components	User Manual

8. WARRANTY AND SUPPORT

LINSY HOME is committed to providing quality products and customer satisfaction.

8.1 Return Policy

This product is eligible for a 30-day easy return policy. Please refer to your purchase platform's return guidelines for detailed instructions.

8.2 Customer Support

For any questions, concerns, or assistance with assembly or product issues, please contact LINSY HOME customer support. You can often find contact information on the retailer's website or within your purchase documentation.

Visit the official LINSY HOME store for more products and information:[LINSY HOME Store](#)

9. ADDITIONAL PRODUCT VIEWS

Here are additional images showcasing the LINSY HOME Farmhouse Dresser in various settings and details.



Figure 9.1: Front view of the dresser.



Figure 9.2: Dresser in a bedroom setting.



Figure 9.3: Dresser in a living room setting.



Figure 9.4: Dresser showcasing its style.



Figure 9.5: Detail of the dresser top and pulls.



Figure 9.6: Dresser in a styled room.

10. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found in the provided data to embed in this manual.