

Salora SLV-3555 QGTV

Salora SLV-3555 QGTV 55-inch QLED 4K Ultra HD Smart Google TV User Manual

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Salora SLV-3555 QGTV 55-inch QLED 4K Ultra HD Smart Google TV. Please read this manual thoroughly before using the television and retain it for future reference.



Figure 1: Front view of the Salora SLV-3555 QGTV television.

WHAT'S IN THE BOX

Verify that all components are present upon unboxing:

- 1 Main Unit (Salora SLV-3555 QGTV Television)
- 1 Remote Control
- 1 Wallmount Kit
- 1 User Manual (this document)
- 2 AAA Batteries (for remote control)

SAFETY INFORMATION

Observe the following safety precautions to prevent damage and ensure safe operation:

- Do not expose the television to rain or moisture.
- Ensure proper ventilation around the television.

- Avoid placing the television near heat sources or in direct sunlight.
- Use only the power cord supplied with the television.
- Do not open the television casing; refer all servicing to qualified personnel.
- Keep batteries out of reach of children.

PHYSICAL SETUP

Mounting Options

Your Salora SLV-3555 QGTV can be set up using either the included table-top stands or a wall mount. Follow the instructions provided with the respective mounting hardware.




Figure 2: Television dimensions for installation planning.

Connecting Peripherals

Connect your external devices to the appropriate ports on the rear of the television. The TV features multiple HDMI and USB ports, along with other connectivity options.



Figure 3: Rear view illustrating port locations.

Power Connection

After connecting all necessary cables, plug the power cord into the television and then into a suitable AC power outlet (220 Volts AC).

INITIAL SETUP AND CONFIGURATION

Powering On

Press the power button on the remote control or on the television itself to turn on the device.

Remote Control Pairing

Insert the two AAA batteries into the remote control. If the remote does not respond, follow the on-screen instructions or refer to the remote control guide for pairing via Bluetooth.



Figure 4: The voice-enabled smart remote control.

Network Connection

During the initial setup, you will be prompted to connect to a network. Select your Wi-Fi network and enter the password. The television supports dual-band Wi-Fi (2.4GHz and 5GHz) and 2-way Bluetooth 5.0.

Google TV Setup

Follow the on-screen prompts to complete the Google TV setup. This includes signing in with your Google account, accepting terms of service, and configuring personalized content recommendations and watchlists. A dedicated Kids Profile option is available.




Figure 5: Google TV interface displaying available applications.

OPERATING YOUR TV

Basic TV Functions

- **Power:** Press the power button on the remote to turn the TV on or off.
- **Volume:** Use the Volume Up/Down buttons on the remote.
- **Input:** Press the Input button to select connected devices (HDMI 1, HDMI 2, USB, etc.).
- **Navigation:** Use the directional pad and OK button on the remote to navigate menus.

Using Google Assistant and Voice Control

Press the Google Assistant button on your remote and speak into the microphone to control your TV, search for content, or ask questions. The voice control remote allows for hands-free operation.

Accessing Applications

The Google TV interface provides access to a wide range of streaming applications. Use the dedicated hotkeys on the remote for quick access to Netflix, Prime Video, and YouTube. Other applications can be

downloaded from the Google Play Store.

Connecting External Devices

The television is equipped with multiple ports for connecting various devices:

- **HDMI Ports (x3):** For set-top boxes, Blu-ray players, gaming consoles, and personal computers.
- **USB 2.0 Ports (x2):** For external storage devices to play supported media formats like MP3.
- **Bluetooth:** For connecting wireless headphones or other Bluetooth-enabled audio devices.
- **Wi-Fi:** For internet connectivity and streaming.



Figure 6: Overview of connectivity ports.

MAINTENANCE

Cleaning the Television

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen-specific cleaning solution applied to the cloth, not directly to the screen.
- **Body:** Wipe the television's frame and stand with a soft, dry cloth. Avoid using abrasive cleaners or

solvents.

- **Before Cleaning:** Always unplug the television from the power outlet before cleaning.

Software Updates

Your Salora Smart Google TV may receive periodic software updates to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates. You can usually check for updates in the TV's settings menu.

TROUBLESHOOTING

If you encounter issues with your television, refer to the following common problems and solutions:

- **No Power:**

- Check if the power cord is securely plugged into both the TV and the wall outlet.
- Verify the power outlet is functional by plugging in another device.
- Try pressing the power button on the TV itself, not just the remote.

- **No Picture, But Sound is Present:**

- Ensure the correct input source is selected (e.g., HDMI 1, HDMI 2).
- Check the cable connections between the TV and the external device.
- Restart the external device.

- **No Sound:**

- Increase the volume.
- Check if the TV is muted.
- Verify audio cable connections for external devices.
- If using external speakers, ensure they are powered on and correctly connected.

- **Remote Control Not Responding:**

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the TV's IR sensor.
- Re-pair the Bluetooth remote if necessary (refer to initial setup).

- **Network Connection Issues:**

- Restart your Wi-Fi router.
- Check Wi-Fi password and ensure it is entered correctly.
- Move the TV closer to the router or consider a wired Ethernet connection if available.

For issues not covered here, please contact customer support.

TECHNICAL SPECIFICATIONS

The following table outlines the key technical specifications of the Salora SLV-3555 QGTV:




Figure 7: Key features and specifications summary.

Feature	Specification
Model	SLV-3555 QGTV
Display Size	55 Inches (139 cm)
Display Technology	QLED
Resolution	4K Ultra HD (3840 x 2160 pixels)
Refresh Rate	60 Hz
Viewing Angle	178 Degrees
HDR Support	Dolby Vision, HDR10, HLG
Audio Output	20W Stereo Speakers with Dolby Atmos
Operating System	Google TV

Feature	Specification
Processor	Quad Core A53 1.5 GHz (Mali G52 Graphics Coprocessor)
RAM	2 GB
Storage	16 GB
Connectivity	3 x HDMI, 2 x USB 2.0, Dual-band Wi-Fi, 2-way Bluetooth 5.0
Power Consumption	150 Watts
Voltage	220 Volts (AC)
Product Dimensions (LxWxH)	122.5 x 9.5 x 70.8 cm
Item Weight	17.2 kg



Figure 8: Explanation of Quantum Dot Technology for vibrant colors.



DOLBY VISION

Dolby Vision delivers better contrast, brightness, and nuanced colours in every scene for an outstanding visual experience.

Figure 9: Dolby Vision enhances contrast, brightness, and color nuance.



DOLBY ATMOS

Experience the sensation of being surrounded by captivating, lifelike sound with our cutting-edge audio innovation, Dolby Atmos.

Figure 10: Dolby Atmos provides immersive, lifelike sound.

A53 1.5 GHZ QUAD CORE

Mali G52


Ensures smooth and lag-free performance allowing you to switch between apps and channels effortlessly. It also enhances the picture quality to deliver stunning visuals with vibrant colours.

16GB+2GB
Memory RAM



*Available memory may vary due to OS and preloaded application

Figure 11: Internal components including the Quad Core processor and memory.



*Ownership rights for the logos, belong to their respective trademark applicant or owners.

Figure 12: Overview of Google TV features and display technologies.







WARRANTY INFORMATION

Your Salora SLV-3555 QGTV television comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures peace of mind. Please retain your purchase receipt as proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact Salora customer service. Refer to the contact information provided on the official Salora website or your purchase documentation.

Related Documents - SLV-3555 QGTV

	<p>Salora 55UA550 Gebruiksaanwijzing</p> <p>Gedetailleerde gebruikershandleiding voor de Salora 55UA550 kleurentelevisie met afstandsbediening, inclusief installatie, functies, bediening en probleemoplossing.</p>
	<p>Salora BEAMER 45BHM2550 LED Projector User Manual and Guide</p> <p>Comprehensive user manual for the Salora BEAMER 45BHM2550 LED projector, covering safety instructions, specifications, setup, operation, multimedia playback, and wireless connectivity.</p>
	<p>Salora 32HWA555 Handleiding: Installatie, Bediening en Specificaties</p> <p>Ontdek de Salora 32HWA555 LED TV met deze uitgebreide gebruikershandleiding. Leer over installatie, functies, bediening, instellingen en probleemoplossing voor uw Salora televisie.</p>
	<p>Salora 40RPA650 Gebruiksaanwijzing - Handleiding voor uw TV</p> <p>Vind gedetailleerde instructies en handleidingen voor de Salora 40RPA650 televisie. Leer hoe u uw apparaat installeert, bedient en optimaliseert.</p>
	<p>Salora VIDAA Smart TV User Manual - 32XHV3300, 43XFV3300, 50XUV3300</p> <p>Comprehensive user guide for Salora VIDAA Smart TVs, covering models 32XHV3300, 43XFV3300, and 50XUV3300. Includes setup instructions, feature explanations, safety precautions, and troubleshooting tips.</p>
	<p>SALORA DPF1040ST 10-inch Digitale Fotolijst Gebruikershandleiding</p> <p>Handleiding voor de SALORA DPF1040ST 10-inch digitale fotolijst. Leer hoe u het apparaat instelt, foto's beheert, verbindt met Wi-Fi en meer.</p>

