

[Manuals.plus](#) /

› [JoySpark](#) /

› JoySpark Kids Bluetooth Headphones Instruction Manual

JoySpark T5

JoySpark Kids Bluetooth Headphones Instruction Manual

Model: T5

Brand: JoySpark

PRODUCT OVERVIEW

The JoySpark Kids Bluetooth Headphones are designed to provide a safe, comfortable, and high-quality audio experience for children. Featuring volume limiting technology, a durable and lightweight design, and long battery life, these headphones are ideal for music, learning, and travel.



A pair of JoySpark Kids Bluetooth Headphones, showcasing their vibrant purple and teal color scheme and over-ear design.

KEY FEATURES

- **Prioritizing Comfort:** Memory foam ear cushions and a fully adjustable headband ensure a gentle, breathable, and strain-free fit for extended wear.
- **Immersive Surround Sound & Volume Limit:** Built-in 40mm speaker units deliver rich bass and lifelike audio. Volume is limited to 85/94dB to protect children's hearing, with combination keys preventing accidental changes.
- **Bluetooth 5.3 & Built-In Microphone:** Enjoy seamless wireless connectivity with Bluetooth 5.3. One-button control allows for effortless play, pause, and call management, providing hands-free convenience.
- **Hours of Uninterrupted Listening:** Up to 60 hours of playtime on a single charge. A 3.5mm backup jack ensures continuous enjoyment even when the battery is low.




Illustration highlighting the safe volume mode feature, showing a child happily wearing the headphones with a graphic indicating 85/94dB volume limits.



Detailed view of the headphones emphasizing their softer and compact design, including features like an adjustable headband and comfortable earmuffs.



60 HOURS PLAYTIME



LARGE CAPACITY
BATTERY



60 HOURS
PLAYTIME



USB C
CHARGING CABLE



WIRELESS
& WIRED

60
HOURS



3-4 HOURS OF PLAYBACK ON
A 10 MINUTE CHARGING

+∞
HOURS



Visual representation of the impressive 60-hour playtime, highlighting the USB-C charging capability and the option for both wireless and wired use.

BROAD COMPATIBILITY



Bluetooth 5.3

Image illustrating the broad compatibility of the headphones with various devices, including smartphones, tablets, laptops, and gaming consoles, powered by Bluetooth 5.3.



Depiction of the super-lightweight design, showing a child wearing the headphones comfortably and a graphic comparing their weight to a smartphone.



PREMIUM SOUND QUALITY

40MM DYNAMAMAIC DRIVERS CRYSTAL CLEAR



Image showcasing the premium sound quality delivered by the 40mm dynamic drivers, with children enjoying their audio experience.

SETUP GUIDE

1. Charging the Headphones

Before first use, fully charge your JoySpark headphones. Connect the provided USB-C charging cable to the charging port on the headphone ear cup and plug the other end into a compatible USB power source. The charging indicator light will show the charging status. A full charge takes approximately 2.5 hours.

2. Bluetooth Pairing

1. Ensure the headphones are fully charged.

2. Press and hold the Power button on the headphone ear cup for a few seconds until the LED indicator light begins to flash blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "JoySpark-T5" from the list of devices. Once connected, the LED indicator light will turn solid blue.

3. Wired Connection (Optional)

For devices without Bluetooth or when the battery is depleted, you can use the included 3.5mm audio cable. Simply plug one end into the headphone's 3.5mm jack and the other end into your audio device's headphone port.

OPERATING INSTRUCTIONS

1. Power On/Off

- **Power On:** Press and hold the Power button until the LED indicator light turns on.
- **Power Off:** Press and hold the Power button until the LED indicator light turns off.

2. Volume Control

- **Increase Volume:** Press the "+" button.
- **Decrease Volume:** Press the "-" button.
- **Volume Limit:** The headphones feature an 85/94dB volume limit to protect hearing. Use the dedicated switch to toggle between these modes.

3. Playback Control

- **Play/Pause:** Press the Multi-function button (usually the Power button or a dedicated Play/Pause button) once.
- **Next Track:** Long press the "+" button.
- **Previous Track:** Long press the "-" button.

4. Call Management

- **Answer/End Call:** Press the Multi-function button once during an incoming call or active call.
- **Reject Call:** Press and hold the Multi-function button during an incoming call.

MAINTENANCE

1. Cleaning

Wipe the headphones with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface or internal components.

2. Storage

The JoySpark headphones feature a foldable design for compact storage. Fold them inward to save space when not in use or when traveling. Store them in a cool, dry place away from direct sunlight and extreme temperatures.



Demonstration of the headphones' portable and foldable design, making them easy to store and carry, along with the included cables and user manual.

3. Battery Care

To prolong battery life, charge the headphones regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods. Do not expose the headphones to extreme heat or cold.

TROUBLESHOOTING

1. Cannot Power On

- Ensure the headphones are fully charged. Connect to a power source and allow some time for charging.

2. Cannot Pair via Bluetooth

- Make sure the headphones are in pairing mode (flashing blue and red light).
- Ensure Bluetooth is enabled on your device and it is within the 10-meter range.
- Try forgetting the device from your device's Bluetooth settings and re-pairing.
- Restart both the headphones and your device.

3. No Sound

- Check the volume levels on both the headphones and your connected device.
- Ensure the headphones are successfully paired and connected to your device.
- If using a wired connection, ensure the 3.5mm cable is fully inserted into both jacks.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	JoySpark-T5

Feature	Specification
Connectivity Technology	Wireless (Bluetooth 5.3), Wired (3.5mm Jack)
Bluetooth Range	10 Meters (33 feet)
Audio Driver Size	40 Millimeters
Frequency Response	20Hz-20KHz
Impedance	32 Ohm
Volume Limit	85/94dB (Switchable)
Battery Life	Up to 60 Hours
Charging Time	Approx. 2.5 Hours
Material	Plastic, Foam
Item Weight	170 Grams (6 ounces)
Noise Control	Passive Noise Cancellation
Age Range (Description)	Kid, Teen, Toddler

WHAT'S IN THE BOX

- JoySpark Kids Bluetooth Headphones
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual

WARRANTY AND SUPPORT

JoySpark stands behind the quality of its products. For any issues or inquiries regarding your headphones, please contact our customer service team. We are committed to resolving any concerns within 24 hours.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question