

Easytry22649

Generic Replacement Remote Control User Manual

For S.M.S.L SU-9 PRO MQA & DAC D0200 MKI & DO200 MKI High-Performance Audio DAC Decoders

1. INTRODUCTION

This manual provides instructions for the Generic Replacement Remote Control, designed for use with specific S.M.S.L High-Performance Audio DAC Decoders, including the SU-9 PRO MQA, D0200 MKI, and DO200 MKI models.

This remote is an infrared (IR) replacement unit. For optimal compatibility, please ensure your original remote control matches the appearance and button layout of this replacement unit as shown in the images provided.

Important Note: This replacement remote may not offer all functions identical to your original device's remote. Refer to your S.M.S.L DAC device's original manual for specific functions and advanced operations.



Figure 1: Front view of the Generic Replacement Remote Control, showing all buttons.

2. SETUP: BATTERY INSTALLATION

The remote control requires two (2) AAA batteries (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2: Back view of the remote control with the battery compartment open, illustrating battery insertion.

3. OPERATING THE REMOTE CONTROL

To operate your S.M.S.L DAC device using this remote control, ensure there is a clear, unobstructed line of sight between the remote's infrared emitter and the DAC's IR receiver. The maximum effective range is approximately 8 meters (26 feet).

Button Functions:

- **Power Button (Red):** Turns the connected S.M.S.L DAC device on or off.
- **Standby Button (Green):** Puts the device into or out of standby mode.
- **FN Button:** Likely for function selection or mode switching. Refer to your DAC's manual for specific FN button functionality.
- **Directional Arrows (Up, Down, Left, Right):** Used for navigation within menus or adjusting settings.
- **OK Button:** Confirms selections or enters menus.
- **VOL- / VOL+ Buttons:** Decreases or increases the audio output volume.
- **Mute Button:** Mutes or unmutes the audio output.
- **A, B, C Buttons:** These are typically programmable or assigned to specific functions by the DAC device. Consult your DAC's manual for their exact purpose.

4. CARE AND MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, or immerse it in water.

5. TROUBLESHOOTING

- **Remote Not Responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there is no obstruction between the remote and the DAC device.
 - Confirm you are within the effective operating range (approx. 8 meters).
- **Limited Functionality:**
 - As a replacement remote, some advanced or device-specific functions may not be fully supported. Refer to your S.M.S.L DAC's original manual for comprehensive functionality.

6. SPECIFICATIONS

Brand	Generic
Model Number	Easytry22649
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Maximum Range	8 Meters (approx. 26 feet)
Compatible Devices	S.M.S.L SU-9 PRO MQA, D0200 MKI, DO200 MKI DACs
Color	Black

7. WARRANTY INFORMATION

This product is covered by a 90-day warranty from the date of purchase. This warranty covers manufacturing defects and allows for hassle-free returns. Please retain your proof of purchase for warranty claims.

8. CUSTOMER SUPPORT

For any questions, concerns, or technical assistance regarding this replacement remote control, please contact the seller directly through your purchase platform. For detailed information on your S.M.S.L DAC device's specific functions, please refer to its original user manual or the manufacturer's support resources.

