



[Manuals.plus](#) /

› [HOENGAGER](#) /

› Superview Gaming PC Desktop Computer Instruction Manual

HOENGAGER SN-OPW5713213165

Superview Gaming PC Desktop Computer Instruction Manual

Model: SN-OPW5713213165 | Brand: HOENGAGER

1. INTRODUCTION

Welcome to the HOENGAGER Superview Gaming PC Desktop Computer. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new gaming system. Please read this manual thoroughly before using the product to ensure optimal performance and safety.



Figure 1.1: HOENGAGER Superview Gaming PC Desktop Computer (White model with RGB lighting)

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent damage to the product or injury to yourself.

- **Electrical Safety:** Ensure the power supply voltage matches your local power grid. Do not overload power outlets. Disconnect the power cord before cleaning or servicing.
- **Ventilation:** Do not block ventilation openings. Ensure adequate airflow around the PC to prevent overheating.
- **Liquid and Moisture:** Keep the PC away from liquids. Do not operate in high humidity environments.
- **Placement:** Place the PC on a stable, flat surface. Avoid placing it near heat sources or in direct sunlight.

- **Servicing:** Do not attempt to open or repair the PC yourself. Refer all servicing to qualified personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the package before proceeding with setup.

- HOENGAGER Superview Gaming PC Desktop Computer
- Power Cable
- Documentation (Quick Start Guide, Warranty Card)
- (Optional) Keyboard and Mouse (if purchased as a bundle)



Figure 3.1: The HOENGAGER Superview Gaming PC, showcasing its design.

4. SETUP

4.1 Unpacking

1. Carefully remove the PC from its packaging.
2. Remove any protective films or foam inserts from the exterior and interior of the PC.
3. Place the PC on a flat, stable surface with good ventilation.

4.2 Connecting Peripherals

Connect your monitor, keyboard, mouse, and other peripherals to the appropriate ports on the back of the PC.

- **Monitor:** Connect your monitor to the graphics card's HDMI or DisplayPort output. Ensure it is connected to the dedicated graphics card (NVIDIA GeForce RTX 4060), not the motherboard's integrated graphics ports.
- **Keyboard/Mouse:** Connect to any available USB ports (USB 2.0 or USB 3.0).
- **Network:** For wired internet, connect an Ethernet cable to the LAN port. For wireless, ensure the Wi-Fi antenna is connected (if applicable).
- **Power:** Connect the power cable to the PC's power input and then to a wall outlet.







Figure 4.1: Rear view of the PC, highlighting connectivity ports.

4.3 Initial Power On

1. After connecting all peripherals, press the power button located on the front of the PC.
2. The system will boot into Windows 11 Pro. Follow the on-screen instructions for initial setup, including language, region, and user account creation.

5. OPERATING YOUR PC

5.1 Starting Up and Shutting Down

- **To Start:** Press the power button on the front of the PC.
- **To Shut Down:** Click the Start button in Windows, then select Power > Shut down. Avoid forced shutdowns unless absolutely necessary.

5.2 Using Windows 11 Pro

Your PC comes pre-installed with Windows 11 Pro 64-bit, offering a secure and efficient operating environment. Familiarize yourself with the Windows interface and its features for optimal use.

5.3 Gaming Performance

Equipped with an AMD Ryzen 7 5700X processor and NVIDIA GeForce RTX 4060 graphics card, this PC is designed for high-performance gaming. Expect smooth gameplay and high frame rates in popular titles.



Figure 5.1: Gaming performance benchmarks for popular titles at 1080p Ultra settings.

For best gaming experience, ensure your graphics drivers are up to date. You can download the latest drivers from the NVIDIA official website.

6. MAINTENANCE

Regular maintenance helps prolong the life and performance of your PC.

6.1 Cleaning

- **Exterior:** Use a soft, damp cloth to wipe the exterior. Avoid harsh chemicals.
- **Dust:** Periodically clean dust from the ventilation grilles and fans using compressed air. Ensure the PC is powered off and unplugged before cleaning.



Figure 6.1: Illustration of the PC's heat dissipation design with ventilated dust meshes.

6.2 Software Updates

Regularly update your operating system (Windows Update) and graphics drivers (NVIDIA website) to ensure security, stability, and optimal performance.

6.3 System Optimization

Consider running disk cleanup and defragmentation tools periodically (for HDD, SSDs do not require defragmentation). Manage startup programs to improve boot times.

7. TROUBLESHOOTING

This section addresses common issues you might encounter. For more complex problems, please contact customer support.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
PC does not power on.	Power cable loose, power supply switch off, faulty outlet.	Check power cable connections. Ensure PSU switch is ON. Try a different power outlet.
No display on monitor.	Monitor cable loose, connected to wrong port, monitor off.	Ensure monitor cable is securely connected to the graphics card. Check monitor power.
System is slow or freezing.	Too many programs running, insufficient RAM, overheating, malware.	Close unnecessary programs. Check task manager for resource usage. Ensure proper ventilation. Run antivirus scan.
Games perform poorly.	Outdated graphics drivers, high in-game settings, background applications.	Update graphics drivers. Lower in-game graphics settings. Close background applications.

8. SPECIFICATIONS

Feature	Detail
Processor	AMD Ryzen 7 5700X (8-Core, 3.4 GHz)
Graphics Card	NVIDIA GeForce RTX 4060 8GB
RAM	32GB DDR4 3200MHz
Storage	1TB M.2 PCIe SSD
Power Supply	650W PSU
Cooling	360mm AIO Liquid Cooler
Operating System	Windows 11 Pro 64-bit
Wireless Connectivity	802.11AC Wi-Fi & Bluetooth
USB Ports	USB 2.0, USB 3.0
Video Output	HDMI, DisplayPort
Dimensions (LxWxH)	19 x 19 x 15 inches
Weight	25 pounds

9. WARRANTY AND SUPPORT

HOENGAGER provides a **1-year warranty on parts and labor** for this product. This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or further assistance, please visit the official HOENGAGER Store on Amazon or contact their customer service directly.

Official HOENGAGER Store: [HOENGAGER Store](#)

