Pokémon POK4239AC

Pokémon Pikachu Digital LCD Quartz Wrist Watch Instruction Manual

Model: POK4239AC

1. Introduction

Thank you for choosing the Pokémon Pikachu Digital LCD Quartz Wrist Watch. This manual provides essential information for the proper setup, operation, and maintenance of your watch. Please read these instructions carefully to ensure optimal performance and longevity of your product.

2. Product Overview

The Pokémon Pikachu Digital LCD Quartz Wrist Watch features a clear digital display and a vibrant yellow strap adorned with popular Pokémon characters. It is designed for ease of use and readability.



This image shows the Pokémon Pikachu Digital LCD Quartz Wrist Watch. The watch features a yellow strap with Bulbasaur on the upper strap and Charmander on the lower strap. The watch face displays Pikachu and the digital time '3:36'.

Key Features:

- Easy-to-read LED Digital Display
- Adjustable strap for comfortable fit
- Bright colors for visibility

3. Setup

3.1 Unboxing

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. Remove any protective films from the display.

3.2 Setting the Time

Your digital watch typically has one or more buttons on the side for setting the time. While specific button functions may vary, the general procedure is as follows:

1. Locate the 'SET' or 'MODE' button, usually on the right side of the watch.
2. Press and hold the 'SET' or 'MODE' button until the digits on the display begin to flash. This indicates you are in setting mode.
3. Use the 'ADJUST' or 'START' button (often another button on the side) to change the flashing digits (hours, minutes, date). Each press will advance the number.
4. Press the 'SET' or 'MODE' button again to move to the next setting (e.g., from hours to minutes, then to month, day, etc.).
5. Once all settings are correct, press the 'SET' or 'MODE' button one last time to exit the setting mode. The digits will stop flashing.

3.3 Adjusting the Strap

The watch features an adjustable strap. Fasten the strap securely around your wrist, ensuring it is comfortable but not too tight. The buckle should fit into one of the holes on the strap.

4. Operating Instructions

4.1 Reading the Time

The watch displays the time in a digital format (e.g., HH:MM). Simply glance at the display to read the current time.

4.2 Display Activation

If the display is off to conserve battery, press any button briefly to activate the LED digital display and show the time.

5. Maintenance

5.1 Cleaning

To clean your watch, wipe it gently with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

5.2 Battery Replacement

The watch is powered by a small button-cell battery. When the display becomes dim or stops working, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to avoid damaging the watch's internal components or compromising its water resistance.

5.3 Water Resistance

This watch is designed for everyday use and is generally resistant to splashes and light rain. It is not suitable for swimming, showering, or submersion in water. Avoid pressing buttons while the watch is wet.

6. Troubleshooting

6.1 Display Not Working

- Check if the battery needs replacement.
- Ensure no buttons are stuck in a pressed position.

6.2 Incorrect Time Display

- Follow the 'Setting the Time' instructions in Section 3.2 to reset the time.
- If the time consistently loses accuracy, the battery may be low or require professional inspection.

6.3 Strap Damage

If the strap becomes damaged, it may be possible to replace it. Contact the manufacturer or a watch repair service for suitable replacement options.

7. Specifications

Feature	Detail
Model Number	POK4239AC
Display Type	Digital LCD
Movement	Quartz
Manufacturer	AWC CANADA LLC
Country of Origin	China
Parcel Dimensions	17.9 x 12 x 3.5 cm
Item Weight	30 g

8. Warranty and Support

Specific warranty details for the Pokémon Pikachu Digital LCD Quartz Wrist Watch are not provided in the product information. For warranty inquiries or technical support, please contact the retailer or the manufacturer, AWC CANADA LLC, directly. Retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question