

[Manuals.plus](#) /

> [Razer](#) /

> Razer Seiren V3 Chroma RGB USB Microphone User Manual

Razer RZ19-05060100-R3U1

Razer Seiren V3 Chroma RGB USB Microphone User Manual

Model: RZ19-05060100-R3U1

Brand: Razer

1. PRODUCT OVERVIEW

The Razer Seiren V3 Chroma is an RGB USB microphone engineered for high-quality audio capture and dynamic lighting integration. It is designed to provide clear vocal performance for streaming, gaming, and content creation, featuring advanced controls and customization options through Razer Synapse software.





Figure 1: Front view of the Razer Seiren V3 Chroma RGB USB Microphone. This image displays the microphone's sleek black design with its illuminated RGB grille, showcasing the vibrant lighting capabilities.

2. KEY FEATURES

- **Stream and Game Reactive Lighting:** The microphone features Razer Chroma RGB lighting that dynamically responds to in-game events, alerts, and emotes, enhancing the visual experience of your setup.

STREAM AND GAME REACTIVE LIGHTING

Powered by Razer Chroma RGB



Figure 2: A streamer using the Razer Seiren V3 Chroma, highlighting its reactive RGB lighting that synchronizes with on-screen events and stream interactions.

- **Multi-Function Tap-to-Mute Sensor:** An intuitive sensor located on the top of the microphone allows for instant muting with a single tap. It can also be configured for double and triple tap commands to adjust lighting or toggle the digital gain limiter.

MULTI-FUNCTION TAP-TO-MUTE SENSOR

For instant and intuitive control



Figure 3: A hand is shown tapping the top of the Razer Seiren V3 Chroma, illustrating the tap-to-mute functionality for quick audio control.

- **Supercardioid Condenser Mic:** Equipped with a supercardioid pickup pattern, the microphone focuses on capturing your voice while effectively reducing background noise from the sides and rear, ensuring vocal clarity.

SUPERCARDIOID CONDENSER MIC

For stellar vocal clarity and quality



Figure 4: A user engaged in a streaming session with the Razer Seiren V3 Chroma, emphasizing its ability to capture clear vocals for content creation.

- **Digital Gain Limiter and Built-in Shock Absorber:** These features work in tandem to prevent audio distortion from loud sounds and minimize vibrations, ensuring a clean and steady audio output even during intense moments.

DIGITAL GAIN LIMITER AND BUILT-IN SHOCK ABSORBER

For clean, steady sound



Figure 5: The Razer Seiren V3 Chroma is displayed with graphical representations of audio waveforms, illustrating the function of its digital gain limiter and built-in shock absorber for stable sound.

- **Plug-and-Play Design:** The microphone connects via USB, allowing for immediate use with PC systems without requiring additional drivers or complex software installations. It is compatible with popular platforms like Discord, OBS Studio, and XSplit.

PLUG-AND-PLAY DESIGN

For a fuss-free setup



Figure 6: A user is shown with a streamlined setup featuring the Razer Seiren V3 Chroma, highlighting its straightforward plug-and-play connectivity for quick integration into a PC environment.

- **Advanced Customization via Razer Synapse:** For comprehensive control, the Razer Synapse software allows users to personalize lighting effects, adjust sample and bit rates, and manage stream volume mixes, providing a tailored audio experience.

ADVANCED CUSTOMIZATION VIA RAZER SYNAPSE For one-stop control




Figure 7: A screenshot of the Razer Synapse software interface, demonstrating the extensive customization options available for the Razer Seiren V3 Chroma, including audio and lighting controls.

3. SETUP

1. **Unboxing:** Carefully remove the Razer Seiren V3 Chroma microphone and its included 2.0m USB-C to USB-A cable from the packaging. Retain the Important Product Information Guide for future reference.
2. **Placement:** Position the microphone on a stable, flat surface using its integrated stand. For optimal audio capture, ensure the microphone is placed directly in front of the speaker, ideally within 6-12 inches.
3. **Connect to PC:** Plug the USB-C end of the provided cable into the USB-C port located on the back of the microphone. Connect the USB-A end of the cable to an available USB port on your personal computer.





S/N: UC23WWAAAAXXXXX
P/N: RZ19-05060100-XXXX

RZR: RAZ-RZ19-0506

CAN ICES-003(B1) / NMB-003(B1)

Razer Europe GmbH
Rita-Tischweg 25, 22081 Hamburg, Germany



Figure 8: Rear view of the Razer Seiren V3 Chroma, showing the USB-C port for connection to a computer.

4. **Driver Installation:** The Razer Seiren V3 Chroma is designed for plug-and-play functionality. Your operating system should automatically detect and install the necessary drivers. No manual driver installation is typically required.
5. **Software Installation (Optional but Recommended):** For advanced customization and control, download and install the Razer Synapse software from the official Razer website. This software allows you to fine-tune audio settings, customize RGB lighting, and manage stream mixes.

4. OPERATING THE MICROPHONE

- **Tap-to-Mute Sensor:** Gently tap the top of the microphone to instantly mute or unmute your audio. The RGB lighting will change to indicate the mute status (e.g., red for muted).
- **Front Dial Control:** The dial on the front of the microphone primarily controls the microphone's gain (input volume). Rotate clockwise to increase gain and counter-clockwise to decrease it. This dial's function can be remapped in Razer Synapse to control headphone volume instead.
- **3.5mm Headphone Jack:** Connect your headphones to the 3.5mm jack located on the back of the microphone for direct audio monitoring. This allows you to hear your own voice and system audio in real-time.
- **Razer Synapse Customization:**
 - **Lighting:** Customize RGB lighting effects, brightness, and reactive behaviors.
 - **Audio Settings:** Adjust microphone gain, sampling rate (up to 96 kHz), and activate features like the High-Pass Filter to reduce low-frequency noise.
 - **Stream Mixer:** Manage multiple audio sources and create custom mixes for your stream or recording.
 - **Mute Button Remapping:** Assign different functions to the tap-to-mute sensor, such as cycling Chroma effects or toggling the digital gain limiter.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the microphone's exterior. Avoid using harsh chemicals, abrasive materials, or excessive moisture, as these can damage the device.
- **Storage:** When not in use, store the microphone in a clean, dry environment away from extreme temperatures and direct sunlight to prevent damage.
- **Cable Care:** Avoid sharp bends or excessive pulling on the USB cable to prevent internal wire damage. Always grasp the connector when plugging or unplugging.

6. TROUBLESHOOTING

- **No Audio Output:**
 - Ensure the USB cable is securely connected to both the microphone and your PC.
 - Verify that the microphone is selected as the default input device in your operating system's sound settings.
 - Check if the microphone is muted (indicated by red lighting on the grille). Tap the top to unmute.
 - Adjust the microphone gain using the front dial or via Razer Synapse.
- **Distorted or Unclear Audio:**
 - Reduce the microphone gain if the audio is clipping or distorted.
 - Ensure the microphone is positioned correctly, not too close to the sound source.

- Enable the High-Pass Filter in Razer Synapse to reduce low-frequency rumble.
- Check for background noise and try to minimize it in your environment.
- **RGB Lighting Not Working:**
 - Ensure Razer Synapse software is installed and running.
 - Check lighting settings within Razer Synapse to ensure effects are enabled and brightness is adequate.
 - Verify that the microphone is properly connected via USB.

7. SPECIFICATIONS

Attribute	Value
Brand	Razer
Model Name	Seiren V3 Chroma
Item Model Number	RZ19-05060100-R3U1
Connectivity Technology	USB
Connector Type	USB Type-A
Microphone Form Factor	Boundary
Polar Pattern	Super Cardioid
Frequency Range	20 Hz - 20 kHz
Signal-to-Noise Ratio	96 dB
Item Weight	14.4 ounces (0.9 Pounds)
Product Dimensions (L x W x H)	3.55 x 3.55 x 8.39 inches
Hardware Platform	PC
Color	Black
Recommended Uses	Gaming, Karaoke, Streaming, Video Conference

8. WHAT'S IN THE BOX

- Razer Seiren V3 Chroma Microphone
- Important Product Information Guide
- 1x 2.0m USB cable

9. WARRANTY AND SUPPORT

Razer products are designed for durability and performance. For detailed warranty information, please refer to the Important Product Information Guide included in your packaging or visit the official Razer support website. Additional protection plans may be available for purchase to extend coverage beyond the standard warranty period.

- **3-Year Protection Plan:** Available for extended coverage.
- **4-Year Protection Plan:** Available for extended coverage.

- **Complete Protect:** A monthly plan covering eligible past and future purchases.

For technical assistance, troubleshooting, or product inquiries, please contact Razer Customer Support through their official channels.