

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GAOMON](#) /

› [GAOMON Kids Chair Instruction Manual \(Model LY-1106\)](#)

## GAOMON LY-1106

# GAOMON Kids Chair Instruction Manual

Model: LY-1106

## 1. INTRODUCTION

---

Thank you for choosing the GAOMON Kids Chair. This manual provides essential information for the safe and proper assembly, use, and maintenance of your new chairs. Please read these instructions carefully before use and retain them for future reference.



Image: A single GAOMON Kids Chair in dark grey, showcasing its design and adjustable legs.

## 2. SAFETY INFORMATION

---

Your child's safety is our top priority. Please observe the following safety guidelines:

- **Maximum Load Capacity:** The chair is designed to support a maximum weight of 180 lbs (81.6 kg). Do not exceed this limit.
- **Non-slip Foot Covers:** Ensure all four non-slip foot covers are securely attached to the chair legs before use. These protect both your child from slipping and your floors from scratches.
- **Smooth Edges:** The chairs feature soft, rounded corners to prevent injuries. Regularly inspect for any damage that might create sharp edges.
- **Certified Materials:** The chairs are CPC and CE certified, made from non-toxic and environmentally friendly polypropylene material.
- **Adult Supervision:** Always supervise children when they are using the chairs.
- **Proper Use:** Instruct children to sit properly and avoid standing on the chairs or rocking excessively.

# Ergonomic Curved Back Design



Image: A close-up view of the non-slip foot cover on a chair leg, highlighting its textured bottom for stability.

## 3. PRODUCT FEATURES

The GAOMON Kids Chair is designed with your child's comfort and safety in mind, offering several key features:

- **3-Level Height Adjustment:** Easily adjust the chair height to accommodate children aged 2-6 years. The available heights are 10.6" (26cm), 11.4" (28cm), and 12.2" (30cm).
- **Ergonomic Curved Back:** The seat back is curved to support the child's waist, promoting good posture and helping to prevent hunchback.
- **Non-slip Design:** Each chair includes four non-slip foot covers for enhanced stability and floor protection.
- **Lightweight & Portable:** The chair is lightweight and features an easy-to-grab handle on the backrest, making it simple for children to move it around.
- **Durable & Safe Material:** Constructed from sturdy, non-toxic polypropylene with soft rounded corners.
- **Easy to Clean:** The waterproof surface allows for quick and easy cleaning with a damp cloth.
- **Stackable Design:** Chairs can be stacked for convenient storage, saving space when not in use.



Image: An illustration highlighting the ergonomic curved back design, easy-to-grab handle, sunken seat, and non-slip pads of the GAOMON Kids Chair.

## 4. SETUP AND ASSEMBLY

---

The GAOMON Kids Chair is designed for simple assembly. While the product specifications state "No assembly required," some initial setup of the legs and foot covers may be necessary to adjust the height. A Phillips screwdriver may be needed for securing the leg adjustments.

1. **Unpack Components:** Carefully remove all chair components from the packaging.
2. **Attach Legs (if separate):** If the legs are not pre-attached, align them with the designated slots on the chair base and secure them according to the included diagrams.
3. **Install Non-slip Foot Covers:** Ensure the non-slip foot covers are firmly placed on the bottom of each chair leg.
4. **Adjust Height:** Refer to the 'Operating Instructions' section for details on adjusting the chair height.

## 5. OPERATING INSTRUCTIONS

---

The GAOMON Kids Chair features a 3-level height adjustment to grow with your child.

## Adjusting Chair Height:

1. **Identify Adjustment Points:** Locate the adjustment pins or screws on each chair leg.
2. **Unlock Adjustment:** Depending on the design, you may need to press a button or loosen a screw to release the leg extension.
3. **Select Height Level:** Extend or retract the inner leg section to one of the three desired height levels:
  - Level 1: 10.6 inches (26 cm)
  - Level 2: 11.4 inches (28 cm)
  - Level 3: 12.2 inches (30 cm)
4. **Secure Adjustment:** Ensure the leg is securely locked into place at the chosen height. If screws were loosened, tighten them firmly. Verify that all four legs are set to the same height for stability.

## 3 Heights Adjustable

Adjust the height according to your child's height

Level	Chair Height	Suitable Age
Level 1	21.3"	Age 2-5
Level 2	22.0"	Age 5-8
Level 3	22.8"	Age 8-12



Image: A visual guide illustrating the three adjustable height levels of the chair and their corresponding measurements.

## 6. MAINTENANCE

To ensure the longevity and hygiene of your GAOMON Kids Chairs, follow these simple maintenance steps:

- **Cleaning:** The chairs are made from waterproof polypropylene. Use a damp cloth and mild soap to wipe away spills and dirt. Avoid abrasive cleaners or harsh chemicals that could damage the material.
- **Regular Inspection:** Periodically check all parts for wear and tear, especially the leg adjustments and foot covers. Ensure all connections are secure.
- **Storage:** When not in use, the chairs can be stacked to save space. Store them in a dry, cool place away from direct sunlight to prevent material degradation.

## Stackable Design, Save Space



Image: Two GAOMON Kids Chairs neatly stacked on top of each other, demonstrating their space-saving design.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your GAOMON Kids Chairs, please refer to the following common solutions:

- **Chair feels wobbly:** Ensure all four legs are adjusted to the same height and that any securing pins or screws are fully engaged and tightened. Check for any loose connections.
- **Difficulty adjusting height:** Make sure the adjustment mechanism is fully disengaged before attempting to change the height. Clean any debris from the leg channels.
- **Non-slip covers falling off:** Re-attach the foot covers firmly. If they are worn or damaged, they may need replacement to ensure proper grip.

If the problem persists, please contact customer support.

## 8. SPECIFICATIONS

---

Attribute	Detail
Brand	GAOMON
Model Name	Kids Chairs 2 Pack Dark Grey
Item Model Number	LY-1106
Color	Dark Grey
Material	Polypropylene
Product Dimensions	11.8"D x 11.8"W x 21.3"H
Adjustable Height Levels	3 (10.6", 11.4", 12.2" seat height)
Maximum Weight Recommendation	180 Pounds (81.6 kg)
Item Weight	7.6 pounds (3.4 kg)
Age Range (Description)	Child (2-6 years old recommended for height adjustment)
Special Features	Adjustable Height, Ergonomic, Lightweight, Portable, Stackable

# Product Dimensions




Image: A detailed diagram illustrating the product dimensions and maximum weight capacity of the GAOMON Kids Chair.

## 9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact GAOMON customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official GAOMON website or contact their support team.