

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Suright](#) /

› [Suright Bluetooth Light Alarm Clock User Manual](#)

Suright LD082-WH

Suright Bluetooth Light Alarm Clock User Manual

Model: LD082-WH

1. INTRODUCTION

Welcome to the user manual for your new Suright Bluetooth Light Alarm Clock. This device combines a smart alarm clock with sunrise/sunset simulation, a multi-color light, natural soundscapes, FM radio, and a Bluetooth speaker. Please read this manual carefully to ensure proper use and to fully enjoy all the features of your new alarm clock.

2. PRODUCT OVERVIEW

2.1 Key Features

- Sunrise & Sunset Simulation:** Gradually brightens or dims to simulate natural light cycles for waking up or falling asleep.
- Dual Alarms & Snooze:** Set two independent alarms with an unlimited snooze function.
- 17 Lighting Modes:** Includes 8 monochrome colors and 9 RGB atmosphere effects.
- 22 Natural Sounds:** Built-in nature sounds like crickets, birds, rain, and white noise for relaxation and sleep.
- FM Radio:** Automatic scanning and saving of radio stations (76-108 MHz).
- Bluetooth Speaker:** Connect your smartphone to play audio.
- Roller Control Design:** Easy adjustment of brightness (1-20 levels) and volume (1-16 levels).
- Adjustable Time Display Brightness:** 5 levels of brightness for the LED time display.

2.2 Package Contents

- 1 x Suright Bluetooth Speaker Sunrise Wake Up Light
- 1 x User Manual

- 1 x Power Cable
- 1 x Adapter

2.3 Product Diagram



Figure 2.3.1: Front view of the alarm clock, displaying time and various function icons.



Figure 2.3.2: Detailed view of the top control panel featuring roller adjustments for volume and brightness, and the rear panel with the USB-C charging port.

3. SETUP

3.1 Power Connection

1. Connect the provided power cable to the 'INPUT 5V' port on the back of the alarm clock.
2. Plug the adapter into a standard wall outlet.
3. The alarm clock will power on and the time display will illuminate.

3.2 Initial Time Setting

Upon first power-on, you may need to set the current time. Refer to the 'Operating Instructions' section for detailed steps on time adjustment.

3.3 Bluetooth Pairing

1. Long press the 'DIMMER/BT' button for 2 seconds to activate Bluetooth pairing mode. The Bluetooth symbol on the display will flash.
2. On your mobile device, enable Bluetooth and search for the device named "K8".
3. Select "K8" to connect. Once connected, the Bluetooth symbol will stop flashing and remain solid.
4. *Note: If the Bluetooth connection is successful, the alarm clock's time will automatically calibrate.*



Figure 3.3.1: The alarm clock functioning as a wireless Bluetooth speaker, allowing audio streaming from a connected device.

4. OPERATING INSTRUCTIONS

4.1 Time Display Brightness Adjustment

Click the 'DIMMER/BT' button in the time display interface to cycle through 5 levels of brightness for the time display (High - Low - Medium - Low - Off).

4.2 Alarm Settings (Dual Alarms & Snooze)

The alarm clock features two independent alarms. You can set them for daily, weekdays, or weekend operation. The

snooze function provides an additional 9 minutes of sleep and can be used an unlimited number of times.

4.3 Sunrise & Sunset Simulation

Sunrise Simulation: The light gradually brightens from 10% to 100% over a selectable period of 10 to 60 minutes before your set alarm time, simulating a natural sunrise to gently wake you up.

Sunset Simulation: For bedtime, the alarm light will gradually dim from 100% to 0% over a period of 10, 120, 180, or 480 minutes, helping you relax and fall asleep.



Figure 4.3.1: Visual representation of the sunrise simulation for waking up and sunset simulation for falling asleep.

4.4 Light Modes (17 Colors)

The LED alarm light offers 17 distinct color modes, including 8 solid colors (pink, green, blue, indigo, purple, white, red, orange) and 9 dynamic RGB atmosphere effects. You can adjust the light brightness across 20 levels.

7 Lichtmodi

8 Volltonfarben und 9 RGB-Farben

20 Helligkeitsstufen



Figure 4.4.1: The alarm clock displaying different light colors, with a visual palette of 17 available color modes.

4.5 Natural Sounds & White Noise (22 Sounds)

This device functions as a sound machine with 22 integrated natural sounds, such as crickets, campfires, birds, frogs, seagulls, river, rain, wind chimes, and white noise. These sounds can be used for waking up or for creating a relaxing environment for sleep.

Integrierte 22 natürliche Geräusche, die Ihnen beim Schlafen helfen

22 Schlafgeräusche 

Bluetooth 

FM-Radio 

10-480 Minuten Sleep-Timer 




Figure 4.5.1: The alarm clock providing integrated natural sounds to aid in relaxation and sleep.

4.6 FM Radio Operation

Press the "Radio" button to turn on the FM radio. To automatically scan and save all available stations (frequency 76-108 MHz), press the "Radio" button for 2 seconds. Manual tuning is also supported.

Wecken Sie Sie mit 7 natürlichen Effekten und UKW-Radio



Figure 4.6.1: The alarm clock can wake you with natural effects or FM radio.

4.7 Volume and Brightness Adjustment

The device features a convenient roller control design. Simply roll the control to easily adjust the volume from level 1 to 16, and the light brightness from level 1 to 20.

5. MAINTENANCE

To maintain your Suright Bluetooth Light Alarm Clock in optimal condition, please follow these guidelines:

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Do not immerse the device in water or expose it to excessive humidity.
- Avoid placing the device in direct sunlight or near heat sources.
- Store in a cool, dry place when not in use for extended periods.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Power cable not connected properly or power outlet issue.	Ensure the power cable is securely connected and try a different power outlet.
Bluetooth connection fails.	Device not in pairing mode, or mobile device Bluetooth is off.	Ensure the alarm clock is in pairing mode (flashing BT symbol). Check Bluetooth settings on your mobile device. Try restarting both devices.
Alarm does not sound.	Alarm not set, volume too low, or alarm is disabled.	Verify alarm settings, increase volume using the roller control, and ensure the alarm is enabled.
FM Radio reception is poor.	Weak signal or interference.	Adjust the position of the device to improve signal. Perform an automatic station scan again.
Light is not working or flickering.	Brightness set to minimum or off, or a temporary glitch.	Adjust the light brightness using the roller control. Try power cycling the device.

7. SPECIFICATIONS

Feature	Detail
Brand	Suright
Model Number	LD082-WH
Product Dimensions	19.1 x 18.9 x 9.9 cm
Item Weight	680 Grams
Power Input	5V
Light Colors	17 (8 monochrome, 9 RGB effects)
Natural Sounds	22
FM Radio Frequency	76-108 MHz
Batteries	1 CR2 battery (included)
Finish Type	Matte
Lamp Type	Wake Up Light

8. WARRANTY AND SUPPORT



Your Suright Bluetooth Light Alarm Clock is covered by a manufacturer's warranty. Please refer to the product packaging or contact customer support for specific warranty terms and conditions.

For technical support, troubleshooting assistance, or any inquiries regarding your product, please contact Suright customer service:

- Email: support@surights.com

© 2024 Suright. All rights reserved.

Related Documents - LD082-WH

	<p>Suright LED Night Light User Manual and Instructions</p> <p>User manual for the Suright LED Night Light (Model LD261-WH-EU). Provides detailed information on product features, specifications, how to use the brightness adjustment and modes, and important safety precautions.</p>
	<p>ADT Security System Owner's Manual: Setup, Features, and Operation</p> <p>Comprehensive guide to setting up, using, and maintaining your ADT Security System. Learn about components, installation, features, and troubleshooting for ADT Base, sensors, keypads, and more.</p>
	<p>Karran Vitreous China Sinks: Care and Maintenance Guide</p> <p>Comprehensive guide on how to care for and maintain Karran vitreous china sinks, including regular cleaning, stain removal, and recommended cleaning products.</p>
	<p>Panasonic Air-to-Water Hydromodule + Tank Operating Instructions</p> <p>Comprehensive operating instructions for the Panasonic Air-to-Water Hydromodule + Tank system, covering safety precautions, system overview, operating conditions, and detailed setup and servicing information for installers and users.</p>
	<p>Jackson WH Series Rack Conveyor Dishmachines Installation & Operation Manual</p> <p>This manual provides comprehensive installation, operation, and maintenance guidance for Jackson WH Series Rack Conveyor Dishmachines. It covers models WH-44, WH-44CS, WH-44CSS, WH-44S, WH-66, WH-66CS, WH-66CSS, and WH-66S, along with associated option packages like the Side Loader. Detailed sections include specifications, installation procedures, operating instructions, preventative maintenance, troubleshooting, service procedures, and parts lists.</p>