

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Outsunny](#) /

› [Outsunny Raised Garden Bed with Trellis \(Model 84H-077V00CG\) Instruction Manual](#)

## Outsunny 84H-077V00CG

# Outsunny Raised Garden Bed with Trellis (Model 84H-077V00CG) Instruction Manual

Model: 84H-077V00CG | Brand: Outsunny

## INTRODUCTION

---

This instruction manual provides detailed guidance for the assembly, safe operation, and maintenance of your Outsunny Raised Garden Bed with Trellis. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The Outsunny Raised Garden Bed with Trellis, featuring a dark gray planter box and a slatted trellis, positioned in a garden next to a wooden fence.

## SAFETY INFORMATION

**WARNING:** This product is designed for outdoor use and can support climbing plants that may grow to considerable heights and weights. Always ensure the product is stable and secure before use. Be cautious of sharp edges when handling the product. Do not exceed the weight capacity of 165 lbs (75 kg). Keep the product away from extreme weather conditions to prevent damage or hazards. Always follow the assembly instructions carefully to ensure the product's stability and safety.

- Ensure all components are present and undamaged before assembly.
- Assemble on a flat, stable surface.
- Do not overtighten fasteners during assembly to avoid damaging materials.
- For added stability, especially in windy conditions, consider securing the unit to a wall or weighing down the planter box with sufficient soil or stones (at least 77 lbs recommended).
- Regularly inspect the product for any signs of wear or damage.

## PACKAGE CONTENTS

---

Verify that all parts are included in your package before beginning assembly. Refer to the assembly diagram (if provided separately) for specific component identification.

- Aluminum frame components
- Wood-plastic composite boards for planter box
- Wood-plastic composite boards for trellis sections
- Fasteners (screws, nuts, bolts)
- Assembly tools (usually an Allen wrench, not always included)



Image: A brown cardboard box with the Outsunny logo, indicating the product comes in one package.

## SETUP AND ASSEMBLY

---

Assembly requires careful attention to detail. It is recommended to have two people for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat, and soft surface to prevent scratches.
2. **Assemble Planter Box Frame:** Connect the aluminum frame pieces to form the base of the planter box. Ensure all connections are secure but do not fully tighten bolts until all frame pieces are in place.
3. **Install Planter Box Boards:** Slide the wood-plastic composite boards into the designated slots of the planter box frame. Ensure they are correctly oriented.
4. **Attach Trellis Frame:** Connect the vertical aluminum frame pieces for the trellis to the back of the planter box frame.
5. **Install Trellis Boards:** Insert the wood-plastic composite boards into the trellis frame, ensuring even spacing and secure fit.
6. **Final Tightening:** Once all components are assembled, systematically tighten all bolts and screws. Avoid overtightening to prevent material damage.
7. **Positioning:** Place the assembled garden bed in its desired outdoor location. For enhanced stability, especially in areas prone to wind, consider placing it against a wall or securing it.



Image: A close-up view of the secure connection points, showing the bolts and the dark gray wood-plastic composite boards.



Image: A detailed view highlighting the wood-plastic composite board material, emphasizing its anti-cracking, anti-fading, and wire-drawing treatment properties.

## OPERATING INSTRUCTIONS


- **Filling the Planter Box:** Fill the planter box with appropriate potting soil. The spacious planting area (34.75" L x 13.25" W x 8.75" H) can hold up to 17 gallons (65 liters) of soil.
- **Planting:** Plant your desired herbs, vegetables, fruits, or climbing plants. Ensure adequate spacing for plant growth.
- **Watering:** Water plants as needed. The integrated bottom draining gap allows excess water to drain, preventing root rot and maintaining soil freshness.
- **Utilizing the Trellis:** Guide climbing plants such as roses, beans, peas, or vines up the trellis sections. The trellis provides vertical support and can also serve as a decorative element or privacy screen.

# PLENTY OF SPACE



## Planter Box

Holds up to 17 gallon/65 litres soil



## Back Trellis

Plants climbing vines or decorated with a string of lights

Image: An illustration showing the dimensions of the planter box (34.75" x 13.25") and the trellis, highlighting its capacity for soil and suitability for climbing plants.

# BOTTOM DRAINAGE GAP

Allow excess water to drain out, keep soil fresh and protect plants from rot




Image: A visual representation of the bottom drainage gap, showing water flowing out from the planter box, ensuring proper aeration and moisture management for plants.

## MAINTENANCE

- **Cleaning:** Wipe down the aluminum frame and wood-plastic composite boards with a damp cloth as needed. Avoid harsh chemicals that may damage the material.
- **Material Care:** The wood-plastic composite boards are designed to be anti-cracking and anti-fading. Regular cleaning will help maintain their appearance.
- **Stability Check:** Periodically check all fasteners to ensure they remain tight. Re-tighten if necessary.
- **Winter Storage:** While designed for outdoor use, consider moving the planter to a sheltered location or covering it during extreme winter conditions to prolong its lifespan.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit is unstable or tips over easily.	Insufficient weight in planter box; not secured; uneven ground.	Ensure planter box is filled with at least 77 lbs of soil or stones. Place on a level surface. Secure against a wall or fence if possible.
Water accumulation in planter box.	Drainage gap blocked; soil too dense.	Check and clear the bottom draining gap. Use well-draining potting soil.
Parts do not fit during assembly.	Incorrect orientation of parts; fasteners overtightened prematurely.	Review assembly steps and diagrams. Loosen fasteners and re-align parts before tightening.

## SPECIFICATIONS

---

**Model:** 84H-077V00CG

**Brand:** Outsunny

**Color:** Dark Gray

**Material:** Aluminum, Wood-Plastic Composite Board

**Overall Dimensions:** 35.75" L x 15" W x 70.75" H

**Planter Inner Size:** 34.75" L x 13.25" W x 8.75" H

**Trellis Height:** Approximately 60.8" (from top of planter box)

**Item Weight:** 36 lbs

**Weight Capacity (Planter Box):** 165 lbs (75 kg)

**Assembly Required:** Yes



Image: A diagram illustrating the overall dimensions of the Outsunny Raised Garden Bed with Trellis, including length, width, height, and inner planter box measurements.

## WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please contact Outsunny customer service directly. Refer to your purchase documentation or the Outsunny website for contact details.

