

HONITURE V8 Pro

HONITURE V8 Pro Robot Vacuum Cleaner

User Manual

Model: V8 Pro | Brand: HONITURE

1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before using the HONITURE V8 Pro Robot Vacuum Cleaner and retain it for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Do not allow children to play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Only use the original power adapter provided by the manufacturer.
- Do not use the robot in wet environments or near water.
- Remove any loose cables, small objects, or fragile items from the cleaning path before operation to prevent entanglement or damage.
- Do not operate the robot on elevated surfaces without protective barriers.
- Turn off the robot and unplug the charging station before performing any maintenance or cleaning.

2. PACKAGE CONTENTS

Ensure all items are present and in good condition upon unpacking. If any items are missing or damaged,

Was ist in der Box



- | | |
|---------------------------------------|---------------------------|
| 1 V8 Pro Roboterstaubsauger * 1 | 7 Hochleistungsfilter * 1 |
| 2 Ladestation * 1 | 8 Reinigungsbürste * 1 |
| 3 2-in-1-Mülleimer und Wassertank * 1 | 9 Benutzerhandbuch * 1 |
| 4 Seitenbürste* 1 | 10 Kurzanleitung * 1 |
| 5 Hauptbürste* 1 | 11 Wischtuch * 1 |
| 6 Wischtuchhalter * 1 | |

Image: All components included in the HONITURE V8 Pro Robot Vacuum Cleaner package.

1. HONITURE V8 Pro Robot Vacuum Cleaner (1 unit)
2. Charging Station (1 unit)
3. 2-in-1 Dustbin and Water Tank (1 unit)
4. Side Brush (1 unit)

5. Main Brush (1 unit)
6. Mop Cloth Holder (1 unit)
7. High-Performance Filter (1 unit)
8. Cleaning Brush (1 unit)
9. User Manual (1 unit)
10. Quick Start Guide (1 unit)
11. Mop Cloth (1 unit)

3. PRODUCT OVERVIEW

The HONITURE V8 Pro is an advanced robot vacuum cleaner designed for efficient and thorough cleaning of your home. It combines powerful suction with intelligent navigation and versatile cleaning modes.



Image: The HONITURE V8 Pro Robot Vacuum Cleaner and its accessories.

Key Features:

- **Powerful Suction:** Equipped with 5000Pa ultra-strong suction power to effectively remove dust, debris, and pet hair from various floor types.



Image: Illustration of the robot vacuum's powerful 5000Pa suction capability.

- **Intelligent 360° LiDAR Navigation:** Utilizes advanced LiDAR technology for precise mapping, efficient navigation, and systematic cleaning paths.

Intelligente 360°-LiDAR-Navigation

Die Kartierung ist schneller, intelligenter und genauer



Image: The robot vacuum employing 360° LiDAR navigation for accurate room mapping.

- **3-in-1 Functionality:** Sweeps, vacuums, and mops simultaneously, providing comprehensive cleaning in one pass. Features a 2-in-1 dustbin and water tank.

Fegen, Staubsaugen und Wischen 3 in 1

Eine Maschine für die gesamte Reinigung, die gleichzeitig läuft, um die Effizienz zu verbessern


290ML
Wassertank


260ML
Staubbox


3 Stufen
Wasserdurchfluss



Image: The robot vacuum's integrated sweep, vacuum, and mop functions with its combined dustbin and water tank.

4. SETUP

4.1 Charging Station Placement

Place the charging station against a wall in an open, uncluttered area. Ensure there is at least 0.5 meters (1.6 feet) of clear space on both sides and 1.5 meters (4.9 feet) in front of the charging station. Plug the power

adapter into a wall outlet.

4.2 Initial Charging

Place the robot vacuum onto the charging station. Ensure the charging contacts on the robot align with those on the station. The robot will automatically begin charging. For first use, fully charge the robot, which may take several hours.

4.3 App Download and Connection

Download the 'HonySmart' app from your mobile app store (Google Play Store or Apple App Store). Follow the in-app instructions to connect your robot vacuum to your home Wi-Fi network. This will enable advanced features like mapping, scheduling, and remote control.

5. OPERATION

5.1 Starting/Stopping Cleaning

- **Start:** Press the power button on the robot or use the 'Start Cleaning' option in the HonySmart app.
- **Pause:** Press the power button during cleaning to pause.
- **Stop:** Press and hold the power button for a few seconds to stop cleaning and send the robot back to the charging station.

5.2 Cleaning Modes

The HONITURE V8 Pro offers various cleaning modes to suit your needs, configurable via the HonySmart app:

- **Auto Cleaning:** The robot intelligently maps and cleans your entire home in an efficient zigzag pattern.

Effiziente Zickzack-Reinigung

Verbessern Sie die Reinigungseffizienz auf 95 %



Image: The V8 Pro's efficient zigzag cleaning path for improved coverage.

- **Spot Cleaning:** Cleans a specific area more intensely. Place the robot in the center of the dirty area and select spot cleaning.
- **Zone Cleaning:** Define specific areas on the map within the app for the robot to clean.
- **Scheduled Cleaning:** Set specific times for the robot to automatically start cleaning.

5.3 Smart APP and Voice Control

Control your HONITURE V8 Pro conveniently through the HonySmart app or integrate it with voice assistants like Amazon Alexa or Google Assistant.

Intelligente APP und Sprachsteuerung



Funktioniert mit
Alexa



Funktioniert mit
Bluetooth



Funktioniert mit
Google Assistant



Image: The robot vacuum supports control via its smart app and voice commands through Amazon Alexa and Google Assistant.

- **App Features:** View cleaning maps, set no-go zones, adjust suction power and water flow, check battery level, and receive notifications.
- **Voice Commands:** Link your robot to Alexa or Google Assistant for hands-free control (e.g., "Alexa, turn on V8 Pro").

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your HONITURE V8 Pro.

6.1 Emptying the Dustbin

Empty the dustbin after each cleaning cycle or when the 'dustbin full' indicator appears in the app. Open the robot's top cover, remove the 2-in-1 dustbin/water tank, and dispose of the collected debris.

6.2 Cleaning Filters

Tap the filter to remove loose dirt. Rinse the filter under running water. Allow it to air dry completely before reinserting. Replace the filter every 3-6 months depending on usage.

6.3 Cleaning Brushes

- **Main Brush:** Remove the main brush cover and lift out the main brush. Use the provided cleaning tool to remove hair and debris tangled around the brush.
- **Side Brushes:** Periodically check side brushes for wear or damage. Remove any tangled hair or debris. Replace if worn.

6.4 Refilling Water Tank and Cleaning Mop Cloth

For mopping, fill the water tank with clean water. Attach a clean mop cloth to the mop cloth holder. After mopping, remove and wash the mop cloth. Allow it to air dry completely.

6.5 Cleaning Sensors and Charging Contacts

Wipe the cliff sensors, wall sensors, and charging contacts on both the robot and the charging station with a clean, dry cloth to ensure proper function.

7. TROUBLESHOOTING

If you encounter issues with your HONITURE V8 Pro, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot does not charge	Charging contacts are dirty; Power adapter not connected; Robot not properly docked.	Clean charging contacts; Ensure power adapter is plugged in; Re-dock the robot.
Robot gets stuck frequently	Loose cables or small objects on the floor; Robot stuck on high thresholds.	Clear obstacles from cleaning path; Use no-go zones for high thresholds.
Poor cleaning performance	Dustbin full; Brushes tangled; Filter clogged.	Empty dustbin; Clean main and side brushes; Clean or replace filter.
App connection issues	Incorrect Wi-Fi password; Robot too far from router; Router settings.	Verify Wi-Fi password; Move robot closer to router; Consult router manual or app instructions.

If the problem persists, please contact HONITURE customer support for further assistance.

8. SPECIFICATIONS

Brand	HONITURE
Model Number	V8 Pro
Color	Black
Product Dimensions	32.5 x 32.5 x 9.7 cm
Weight	4.97 kg
Voltage	14.4 Volt
Noise Level	50 dB
Battery Type	Lithium-ion
Control Method	Voice, App
Compatible Devices	Amazon Echo

9. WARRANTY AND SUPPORT

The HONITURE V8 Pro Robot Vacuum Cleaner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, warranty claims, or any questions regarding your product, please contact HONITURE customer service through the contact information provided on the official HONITURE website or your purchase platform.

Please retain your proof of purchase for warranty purposes.