

[Manuals.plus](#) /

> [COMHOMA](#) /

> COMHOMA Convertible Futon Sofa Bed (Model B0CT8TL8PP) Instruction Manual

COMHOMA B0CT8TL8PP

COMHOMA Convertible Futon Sofa Bed Instruction Manual

Model: B0CT8TL8PP

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- All foam and upholstered surfaces meet flammability standards.
- Keep the futon away from open flames or high heat sources to prevent fire hazards.
- Supervise children and pets around the futon to avoid entrapment risks, especially during conversion between sofa and bed modes.
- Ensure all legs are securely attached and fully extended when using the futon in any configuration to maintain stability.
- Do not exceed the maximum weight limit of 300 pounds.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact COMHOMA customer support.

- Futon Seat Sections (2)
- Futon Backrest Sections (2)
- Support Legs (6)
- Pillows (2)
- Slipcover (1)
- Assembly Hardware (screws, washers, Allen wrench)

3. ASSEMBLY INSTRUCTIONS

Assembly typically takes less than 30 minutes. It is recommended to have two people for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface

to prevent scratches.

2. **Attach Metal Racks:** Insert the metal support racks into the designated slots within the cushioning of both seat and backrest sections. Ensure they are oriented correctly for proper alignment.
3. **Connect Sections:** Align the two futon sections and secure them together using the provided hardware. Tighten all screws firmly but do not overtighten.
4. **Install Legs:** Screw the six support legs into the pre-drilled holes on the underside of the futon frame. Ensure all legs are tightened securely.
5. **Apply Slipcover:** If desired, place the slipcover over the futon.
6. **Position Pillows:** Place the two included pillows on the futon.

5-GEAR BACKREST ADJUSTMENT



Image: Visual guide for futon assembly, illustrating leg attachment and section connection.

4. OPERATING INSTRUCTIONS

The COMHOMA Convertible Futon Sofa Bed offers multiple configurations for versatile use.

4.1 Adjusting the Backrest

The futon features a 5-gear adjustable backrest, allowing you to select various reclining positions.

1. To adjust, locate the two buttons or levers at the bottom of the iron frame, typically near the backrest hinges.
2. Press these buttons simultaneously and gently push or pull the backrest to your desired angle.
3. Release the buttons once the backrest clicks into one of the five available positions.



Image: Illustration of the 5-gear backrest adjustment, detailing positions from upright to fully flat.

4.2 Converting to a Bed

To convert the futon from a sofa to a bed:

1. Ensure there is sufficient clear space behind the futon for the backrest to lay flat.
2. Adjust the backrest to its fully reclined (flat) position by pressing the adjustment buttons and lowering it completely.
3. If applicable, extend any hidden support legs from the backrest to provide additional stability in bed mode.

FREE SITTING MODE

Enjoy a leisurely afternoon, perfect for sipping tea and relaxing.



COMFORT SLEEPING MODE

Just lie down for a sleep, recharging and staying energized.



Image: Comparison of the futon in sofa configuration (sitting mode) and fully extended bed configuration (sleeping mode).

4.3 Returning to Sofa Mode

To convert the futon from a bed back to a sofa:

1. Lift the backrest from its flat position while pressing the adjustment buttons.
2. Guide the backrest upwards until it locks into an upright or desired reclining position.

5. MAINTENANCE

Proper care will extend the life and appearance of your futon.

5.1 Cleaning

- The futon features a removable and washable slipcover for easy cleaning.
- For general cleaning, use water-based cleaners (Upholstery Cleaning Code 'W'). Test any cleaning solution on an inconspicuous area first.
- Vacuum regularly to remove dust and debris.

- For spills, blot immediately with a clean, dry cloth. Avoid rubbing, which can spread the stain.

FREE REMOVABLE & WASHABLE SOFA COVER

COST SAVING



Pet-Friendly



Hygienic & Healthy



Effortless Care



Image: Features of the removable and washable sofa cover, emphasizing ease of maintenance.

5.2 General Care

- Avoid direct sunlight exposure to prevent fading of the fabric.
- Rotate cushions periodically to ensure even wear.
- Periodically check and tighten all assembly hardware to ensure structural integrity.

6. TROUBLESHOOTING

If you encounter issues with your futon, refer to the following common solutions:

- **Difficulty with Assembly:** Ensure all metal racks and components are correctly aligned before tightening screws. Refer to the assembly diagram. If a part appears to be incorrectly manufactured or missing, contact customer support.
- **Instability/Wobbling:** Verify that all six support legs are securely tightened and fully extended. Ensure the futon is placed on a flat, even surface. If using in bed mode, confirm any additional support legs are deployed.

- **Backrest Not Adjusting:** Check that the adjustment buttons/levers are fully depressed when attempting to change the backrest angle. Ensure no obstructions are preventing movement.
- **Futon Feels Too Firm:** The futon is designed with a medium-firm foam fill. If a softer feel is desired, consider adding a mattress topper (not included).

7. SPECIFICATIONS

Brand	COMHOMA
Model Number	B0CT8TL8PP
Product Dimensions (Sofa)	23.65"D x 68.5"W x 36.3"H
Seat Height	16.1 Inches
Item Weight	48.5 Pounds
Weight Limit	300 Pounds
Material Type	Metal (Frame), Velvet (Upholstery)
Seat Fill Material	Foam (High Resilient Sponge)
Seating Capacity	2.00
Included Mattress Size	Full
Special Feature	Folding, Adjustable Backrest

8. WARRANTY AND SUPPORT

This COMHOMA Convertible Futon Sofa Bed comes with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase or contact COMHOMA customer service.

For any questions, missing parts, or support needs, please contact COMHOMA customer service through the retailer where the product was purchased or visit the official COMHOMA website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CT8TL8PP>

More documents and user manuals: <https://manuals.plus/>