Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GorillaRock A-QS810

GorillaRock 10 L Electric Food Processor Instruction Manual

Model: A-QS810

1. Product Overview

The GorillaRock 10 L Electric Food Processor is a robust appliance designed for efficient food preparation in commercial and home settings. It features a high-speed motor and rotational blades capable of processing a significant amount of ingredients, such as fruits, vegetables, grains, and meat, in a short period.
Key features include:

- **Commercial Use:** 10 L capacity and 1100 W power, suitable for high-volume processing.
- **Food-Grade Materials:** All food-contact parts are made from 304 stainless steel, ensuring safety and durability. Blades are removable for easy cleaning.
- **User-Friendly Operation:** Simple control panel with intuitive buttons.
- **Durable Design:** High-quality construction ensures longevity and easy maintenance.



Figure 1.1: The GorillaRock 10 L Electric Food Processor, showcasing its stainless steel construction and compact design.

2. Safety Instructions

WARNING: Read all safety warnings and instructions before using this appliance. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Keep hands and utensils out of the processing bowl while operating to prevent severe injury to persons or damage to the food processor.
- Never feed food by hand. Always use the lid or a pusher if provided.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been

dropped or damaged in any manner.

- Avoid contact with moving parts. Blades are sharp. Handle with care.
- Do not immerse the motor base in water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Ensure the lid is securely locked in place before operating the food processor.

3. Package Contents

Carefully unpack all components and check for any damage. Retain packaging materials for future transport or storage.

- Main Motor Unit
- 10 L Stainless Steel Processing Bowl
- Tempered Glass Lid
- Rotational Blades (set of 2)
- Wooden Spatula
- Power Cord
- Instruction Manual (this document)




Figure 3.1: Included accessories: a wooden spatula and two sharp processing blades.

4. Product Components and Diagram

Familiarize yourself with the different parts of your GorillaRock Electric Food Processor.



Figure 4.1: Overall dimensions of the food processor: 16.1 inches (D) x 17 inches (W) x 22.8 inches (H).

- **Motor Base:** Houses the powerful 1100W motor and control panel.
- **Processing Bowl:** 10 L capacity stainless steel bowl for ingredients.
- **Lid:** Tempered glass lid with a small opening for steam extraction.
- **Blades:** Removable, sharp stainless steel blades for chopping.
- **Control Panel:** Features OFF, ON, START, and STOP buttons.
- **Handles:** Integrated handles on the motor base for easy transport.



Figure 4.2: Close-up of the control panel, showing the OFF, ON, START, and STOP buttons.



Figure 4.3: The stainless steel processing bowl with its tempered glass lid, featuring a steam opening.



Figure 4.4: The motor shaft, where the blades are attached, located inside the base unit.

5. Setup

1. **Unpack:** Remove all packaging materials and ensure all components listed in Section 3 are present and undamaged.
2. **Clean:** Before first use, wash the processing bowl, lid, and blades with warm, soapy water. Rinse thoroughly and dry completely. Wipe the motor base with a damp cloth.
3. **Position:** Place the motor base on a stable, flat, and dry surface. Ensure there is adequate ventilation around the unit.
4. **Assemble Bowl:** Place the clean processing bowl onto the motor base, aligning it correctly until it sits securely.
5. **Install Blades:** Carefully place the sharp blades onto the motor shaft inside the processing bowl. Ensure they are seated firmly.
6. **Secure Lid:** Place the tempered glass lid onto the processing bowl and secure it. The unit will not operate unless the lid is properly closed and locked.
7. **Connect Power:** Plug the power cord into a grounded 110V electrical outlet.

6. Operating Instructions

Follow these steps for safe and effective operation of your food processor.

1. **Prepare Ingredients:** Cut ingredients into manageable pieces that fit comfortably within the processing bowl. Do not overfill the bowl beyond its 10 L capacity.
2. **Load Ingredients:** Place the prepared ingredients into the processing bowl.
3. **Secure Lid:** Ensure the lid is properly placed and locked onto the processing bowl.
4. **Power On:** Turn the "OFF/ON" switch to the "ON" position.

5. **Start Processing:** Press the "START" button to begin operation. The blades will rotate at high speed.
6. **Monitor:** Observe the processing through the tempered glass lid. Processing times are typically very short (less than 1 minute for most ingredients).
7. **Stop Processing:** Once the desired consistency is achieved, press the red "STOP" button.
8. **Power Off:** Turn the "OFF/ON" switch to the "OFF" position and unplug the appliance from the power outlet.
9. **Remove Ingredients:** Carefully remove the lid, then carefully remove the blades (they are very sharp). Use the provided wooden spatula to scrape out processed food.

Note: *For best results and to prevent motor strain, avoid continuous operation for extended periods. Allow the motor to rest between batches if processing large quantities.*

7. Cleaning and Maintenance

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your food processor.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the lid, blades, and processing bowl from the motor base.
3. **Wash Components:** Wash the processing bowl, lid, and blades by hand using warm, soapy water. Rinse thoroughly. **WARNING: Blades are extremely sharp. Handle with extreme caution.**
4. **Clean Motor Base:** Wipe the exterior of the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
5. **Dry:** Ensure all parts are completely dry before reassembling or storing.
6. **Storage:** Store the food processor in a clean, dry place, out of reach of children.

8. Troubleshooting

If you encounter issues with your food processor, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Lid not properly secured. "OFF/ON" switch in "OFF" position.	Ensure power cord is securely plugged into a working outlet. Check that the lid is correctly placed and locked. Turn the "OFF/ON" switch to "ON".
Motor runs, but blades do not rotate.	Blades not properly installed on the motor shaft. Bowl not correctly seated.	Unplug, then carefully re-install blades, ensuring they are firmly seated. Ensure the processing bowl is correctly aligned and seated on the motor base.
Food is not chopped evenly.	Overfilling the bowl. Ingredients are too large.	Reduce the amount of food in the bowl. Cut ingredients into smaller, more uniform pieces before processing.
Unit vibrates excessively or makes unusual noise.	Uneven load. Appliance not on a stable surface.	Distribute ingredients evenly in the bowl. Ensure the appliance is on a flat, stable surface.

If the problem persists after checking the above, please contact customer support.

9. Specifications

Feature	Detail
Brand	GorillaRock
Model Name	A-QS810
Capacity	10 Liters
Power (Wattage)	1100 Watts
Voltage	110V (Standard for US)
Material	Stainless Steel (Food-contact parts are 304 stainless steel)
Product Dimensions (D x W x H)	16.1" x 17" x 22.8" (409mm x 431.8mm x 579.1mm)
Special Feature	Manual Operation (via buttons)
Recommended Uses	Fruits, vegetables, grains, and meat processing
Product Care Instructions	Hand Wash (for removable parts)
Included Components	Main unit, processing bowl, lid, blades, wooden spatula, power cord
UPC	798506836192
ASIN	B0CT8VRZRG

10. Warranty and Support

GorillaRock is committed to customer satisfaction. This product comes with a commitment to quality and customer support.

- **Quality Guarantee:** The manufacturer offers a quality guarantee for this product.
- **Return Policy:** A flexible return policy is available. Please refer to your purchase documentation or retailer's policy for details.
- **Customer Support:** For any questions, troubleshooting assistance, or concerns, please contact GorillaRock customer support through the retailer where the product was purchased or via the official GorillaRock website.

Your satisfaction is a main priority, and feedback is valued for continuous improvement.

© 2024 GorillaRock. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CT8VRZRG

More documents and user manuals: **https://manuals.plus/**