CORBOBO SK968

CORBOBO SK968 60% Gaming Keyboard User Manual

Model: SK968

1. INTRODUCTION

This manual provides instructions for the CORBOBO SK968 60% Gaming Keyboard. This compact 68-key keyboard is designed for various uses, including gaming, office work, and travel, offering a balance of functionality and portability. It features RGB backlighting and a mechanical-feel membrane design.

Image 1.1: The CORBOBO SK968 60% Gaming Keyboard, showcasing its compact layout and RGB backlighting.

The SK968 is a versatile keyboard suitable for multiple environments:

Image 1.2: Keyboard used in an office environment.

Image 1.3: Keyboard used for PC gaming.

Image 1.4: Keyboard used for business travel.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- CORBOBO SK968 60% Gaming Keyboard
- USB-A to Type-C Cable
- User Manual

3. SPECIFICATIONS

Feature	Description
Model Number	SK968
Keyboard Layout	60% (68 Keys)
Key Type	Membrane, Mechanical-Feel
Connectivity	USB-A to Type-C Wired
Backlighting	RGB (10 effects, 7 colors)
Compatible Devices	PC, Mac, Gaming Console (with USB input)

Dimensions	12.2 x 3.9 x 1.65 inches (approx.)
Weight	1.12 pounds (approx. 303g)
Material	Plastic

4. SETUP

The CORBOBO SK968 keyboard features a plug-and-play design for easy setup.

1. **Connect the USB Cable:** Insert the Type-C end of the provided USB cable into the port on the keyboard.

2. **Connect to Device:** Plug the USB-A end of the cable into an available USB port on your computer (PC, Mac) or gaming console.

3. **Driver Installation:** The keyboard does not require additional drivers. Your operating system will automatically recognize and install the necessary device software.

4. **Ready for Use:** The keyboard is now ready for use. The RGB backlighting will illuminate upon connection.

Image 4.1: Illustration of connecting the USB-A to Type-C cable to the keyboard and a laptop.

5. OPERATING INSTRUCTIONS

The SK968 keyboard utilizes a 60% compact layout. Many functions are accessed via the **Fn** key in combination with other keys.

5.1 RGB Backlight Control

The keyboard features 10 backlight effects and 7 backlight colors. Use the following Fn key combinations to control the lighting:

- **Fn + [\|]:** Switch between 10 different lighting effects.

- **Fn + [↑] / [↓]:** Adjust backlight brightness (4 levels).
- **Fn + [←] / [→]:** Adjust lighting speed (3 levels).
- **Fn + [PrtSc]:** Turn the backlight on or off.
- **Fn + [Ins]:** Switch between 7 lighting colors (for some lighting modes).

Image 5.1: Visual guide for controlling RGB backlight effects, colors, speed, and brightness using Fn key combinations.

5.2 Function Key Combinations

The keyboard's compact design means some standard keys are accessed through Fn combinations. The keycaps are printed with function indicator characters for convenience.

Image 5.2: Diagram illustrating various Fn key combinations for accessing full keyboard functions on the SK968.

Common Fn combinations include:

- **Fn + F1-F12:** Access multimedia functions (e.g., volume control, play/pause). Specific functions are indicated on the keycaps.
- **Fn + Arrow Keys:** Dedicated arrow keys are present, but additional navigation functions might be available via Fn combinations depending on the specific keycap legends.
- **Fn + Other Keys:** Refer to the legends printed on the keycaps for other functions like Home, End, Page Up, Page Down, Delete, etc.

The keyboard supports N-key rollover, ensuring all key presses are registered accurately, even during rapid input.

Image 5.3: Visual representation of the "All Keys No-conflict" feature, indicating simultaneous key presses are registered.

6. MAINTENANCE

Proper maintenance helps extend the lifespan of your keyboard.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. For deeper cleaning, gently remove keycaps (if applicable and designed for removal) and use compressed air to clear debris. Avoid using harsh chemicals or abrasive materials.
- **Spills:** In case of liquid spills, immediately disconnect the keyboard from your device. Turn it upside down to drain liquid and allow it to dry completely before reconnecting. Do not attempt to use the keyboard while wet.

- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your CORBOBO SK968 keyboard, refer to the following common solutions:

Keyboard is not responding:

- Ensure the USB-C cable is securely connected to both the keyboard and your device.
- Try plugging the keyboard into a different USB port on your device.
- Test the keyboard on another computer or device to determine if the issue is with the keyboard or the original device.
- Restart your computer.

Backlight is not working or behaving unexpectedly:

- Press **Fn + [PrtSc]** to toggle the backlight on/off.
- Adjust backlight brightness using **Fn + [↑] / [↓]**.
- Cycle through lighting effects with **Fn + [\|]**.
- If the issue persists, unplug the keyboard and plug it back in.

Keys are not registering or double-typing:

- Ensure the keyboard is clean and free of debris that might obstruct key switches.
- Try reconnecting the keyboard.
- If specific keys are consistently problematic, contact customer support.

8. WARRANTY AND SUPPORT

The CORBOBO SK968 keyboard comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or visit the official CORBOBO website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact CORBOBO customer service through the following channels:

- **Email:** Refer to your product packaging or the official CORBOBO website for contact email.
- **Website:** Visit the CORBOBO Store on Amazon (for general inquiries and product information).

When contacting support, please have your product model (SK968) and purchase information readily available.