

UOGIC F97

Uogic Stylus Pen F97 User Manual

Brand: UOGIC | Model: F97

1. INTRODUCTION

This manual provides detailed instructions for the Uogic Stylus Pen F97. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.

1.1 Package Contents

- 1 x Uogic Stylus Pen (with one tip installed)
- 2 x Replacement Tips
- 1 x USB-C Charging Cable
- 1 x User Manual



Image 1.1: The Uogic Stylus Pen F97, shown with a colorful background.

2. SETUP

2.1 Quick Start

The Uogic Stylus Pen F97 does not require Bluetooth pairing for basic functionality. Follow these steps to begin use:

1. Press and hold the upper button on the stylus for 1 second to power it on.
2. Once the indicator light illuminates, the stylus is ready for use.

QUICK START

No need for Bluetooth, just turn on and use,
record your inspiration anytime



1. Press and hold the upper button for 1 second to start the stylus.
2. When the indicator light is on, it can be used.




Image 2.1: Visual guide for quick start, showing the stylus being turned on and used with a tablet.

2.2 Initial Charging

Before first use, it is recommended to fully charge the stylus. Connect the provided USB-C charging cable to the stylus and a compatible USB power source.

- A full charge takes approximately 40 minutes.
- A 20-minute charge provides approximately 90% battery capacity.
- The stylus offers up to 80 hours of continuous use on a full charge.



Image 2.2: Diagram illustrating the USB-C charging port and battery life indicators for the stylus.

3. OPERATING INSTRUCTIONS

3.1 Smooth Writing and Pressure Sensitivity

The stylus supports 1024 levels of pressure sensitivity, allowing for varied line thickness and shading based on writing pressure. The CNC-crafted, gold-plated nib provides a smooth and precise writing experience.

EASY EDITING

Write and draw naturally, Erase mistakes with eraser and edit easily with right-click button

Right-click Button

About right click: press and hold the button before putting the pen on the tablet

Eraser Button




Image 3.1: Close-up view of the stylus nib, highlighting its replaceable design and the smooth writing capability.

3.2 Eraser and Right-Click Functions

The stylus features two integrated buttons for enhanced functionality:

- The **lower button** functions as an eraser.
- The **upper button** serves as a right-click button. To activate right-click, press and hold this button before touching the pen to the tablet screen.



Image 3.2: Illustration of the stylus buttons, indicating the eraser and right-click functions.

3.3 Palm Rejection

The stylus incorporates palm rejection technology, allowing users to rest their hand naturally on the screen while writing or drawing without unintended input. This feature enhances comfort and precision.

PALM REJECTION

Place your hand naturally on the screen for a comfortable user experience



No Gloves Required



Image 3.3: Demonstrates palm rejection, showing a hand resting on a tablet screen while the stylus is in use, with no gloves required.

3.4 Magnetic Attachment

The stylus features two built-in magnets, allowing it to securely attach to compatible Surface devices for convenient storage and transport. It can typically be stored on the left side of Surface Pro, Surface Go, or Surface Book models.

4. COMPATIBILITY

The Uogic Stylus Pen F97 is compatible with Microsoft Surface devices and other touchscreen devices running Windows 10/11 that support Microsoft Pen Protocol (MPP) 1.5 or 2.0.

4.1 Compatible Microsoft Surface Models

- **Surface Pro:** 3rd Gen and later versions (4th, 5th, 6th, 7th, 7+, 8th, 9th, 10th, X generation)
- **Surface Go:** 1st, 2nd, 3rd Gen
- **Surface Book:** 1st, 2nd, 3rd Gen
- **Surface Studio:** 1st, 2nd, 2+ Gen
- **Surface Laptop:** 1st, 2nd, 3rd, 4th, 5th Gen
- **Surface Laptop Studio**

- **Surface Duo:** 1st, 2nd Gen

4.2 Other Compatible Devices

The stylus is also compatible with various models from HP, ASUS, and Dell that support MPP 1.5/2.0. Please refer to your device's specifications to confirm MPP compatibility.

COMPATIBLE MODELS

Only Windows systems support Bluetooth function

Microsoft

- **Surface Laptop**
Surface Laptop / 2 / 3 / 4 / 5 / Studio / Studio 2
- **Surface Go**
Surface Go / 2 / 3
- **Surface Book**
Surface Book / 2 / 3
- **Surface Studio**
Surface Studio / 2 / 2+
- **Surface Duo**
Surface Duo / 2
- **Surface Pro**
Surface Pro 4 / 5 / 6 / 7+ / 7 / 8 / 9 / X

ASUS

- **ASUS NoteBook**
Q325UA / Q405UA
- **ASUS Transfomer**
3 Pro T303UA / 3 T305CA / Mini T102HA
Mini T103HA / Pro T304UA
- **ASUS Vivobook Flip**
12 R211NA / 14 R211NA / TP203UA / TP401CA
TP401NA / TP410UA / TP510UA / TP510UQ / X580VD
Go 14 Flip Tp14DD
- **ASUS ROG Zephyrus Duo**
15 GX550 / 15GX551 / 16 GX650RX/RS/RW/RM
- **ASUS ROG Flow**
GV301QH/QE/QC / GV301RE/RC/RA
GZ301ZE/ZC/ZA
- **ASUS ZenBook**
UX370UA / UX461UA / UX550VE / UX550VD
UX363JA / UX363EA
- **ASUS ZenBook Flip**
JX560UA / JX560UQ / UX560UX / UX561UA
UX561UD / UX561UN

OTHERS

SONY VAIO ZFlip(VZ13BX0211B) Kobo Sage
Acer Spin 5 Kobo Elipsa
Acer Nitro 5 Spin

Hewlett-Packard

- | | | |
|---------------|-------------------|------------------|
| • ENVY | • PAVILION | • SPECTRE |
| x360 13-agxxx | x360 11-adxxx | x360 13-acxxx |
| x360 13-ayxxx | x360 11-apxxx | x360 13-aexxx |
| x360 13-anxxx | x360 14-baxxx | x360 13-apxxx |
| x360 13-bfxxx | x360 14-cdxxx | x360 14-eaxxx |
| x360 14-esxxx | x360 14-ddxxx | x360 15-blxxx |
| x360 15-anxxx | x360 14-dhxxx | x360 15-chxxx |
| x360 15-bpxxx | x360 14-dyxxx | x360 15-dfxxx |
| x360 15-bqxxx | x360 14-dwxxx | x360 16-flxxx |
| x360 15-cnxxx | x360 14-elxxx | x360 13-akxxx |
| x360 15-cpxxx | x360 15-brxxx | |
| x360 15-dnxxx | x360 15-crxxx | |
| x360 15-dsxxx | x360 15-dqxxx | |
| x360 15-ewxxx | x360 15-erxxx | |
| x360 15-eyxxx | | |
| x360 15-fexxx | | |

Dell, Inc

- **Latitude**
3120 / 3190 / 3390 / 7220
- **Inspiron**
5378 / 5379 / 5400 / 5406 / 5482 / 5485 / 5490
5491 / 5578 / 5579 / 5582 / 5591
7300 / 7306 / 7370 / 7373 / 7378 / 7386 / 7390
7391 / 7405 / 7500 / 7506 / 7570 / 7573 / 7579
7586 / 7590 / 7591 / 7600 /
5400* / 5406* / 7370* / 7570* / 5000**
(Configurations with HD displays do not support active pen.)
5378# / 5379# / 5578# / 5579# / 7378# / 7579#
(# Only models that have the label "support Active Pen" wil support the stylus.)

Image 4.1: A comprehensive list of compatible Microsoft, HP, ASUS, and Dell models for the Uogic Stylus Pen F97.

5. MAINTENANCE

5.1 Charging

To maintain optimal performance, charge the stylus when the battery is low. The stylus automatically enters sleep mode after 10 minutes of inactivity to conserve power.

5.2 Replacing Tips

The stylus nib is replaceable. If the tip becomes worn or damaged, use the provided replacement tips. Gently pull out the old tip and insert a new one until it clicks into place.

6. TROUBLESHOOTING

- **Stylus not responding:** Ensure the stylus is powered on and fully charged. Verify your device is compatible with MPP 1.5/2.0.
- **Inaccurate writing or lag:** Ensure the stylus tip is clean and securely installed. Check for any software updates for your device's operating system or drawing applications.
- **Palm rejection not working:** Confirm your device's settings allow for pen input and palm rejection. Some applications may have specific settings for pen input.
- **Buttons not functioning:** Ensure the stylus is powered on. For right-click, remember to press and hold the upper button before touching the screen.

7. SPECIFICATIONS


Feature	Specification
Model Number	F97
Pressure Sensitivity	1024 Levels
Palm Rejection	Yes
Buttons	Eraser, Right-Click
Charging Port	USB-C
Charging Time	Approx. 40 minutes (full charge)
Battery Life (Continuous Use)	Approx. 80 hours
Auto Sleep	After 10 minutes of inactivity
Material	Aluminum
Item Weight	1.41 ounces
Compatible Devices	Microsoft Surface (MPP 1.5/2.0), Windows 10/11 devices with MPP 1.5/2.0

8. WARRANTY AND SUPPORT

The Uogic Stylus Pen F97 comes with a 12-month worry-free warranty. For any inquiries or support needs, please contact UOGIC customer service. Responses are typically provided within 12 hours.

For further assistance, please refer to the contact information provided with your product packaging or visit the official UOGIC website.

Related Documents - F97



[X1 Pro Stylus User Manual and Specifications](#)

User manual and technical specifications for the X1 Pro Stylus, detailing its features, usage, compatibility, and regulatory compliance.




Uogic Pencil AC10S: User Guide, Features, and Specifications

Comprehensive guide for the Uogic Pencil AC10S, covering operating instructions, LED indicator descriptions, Bluetooth pairing, product parameters, FCC statement, and warranty information.



[Uogic AC10-S Stylus Pen User Manual](#)

Comprehensive user manual for the Uogic AC10-S stylus pen, detailing its functions, setup, compatibility with iPads, power management, warranty information, and important safety precautions.



[Uogic AX10-T Active Capacitive Stylus Pen for iPad - User Manual](#)

User manual for the Uogic AX10-T active capacitive stylus pen. Learn about its product structure, operation, battery charging, light indicators, and compatible iPad models for writing, drawing, and touch control.