

Creative MF0495

Creative Pebble X Plus 2.1 USB-C Computer Speakers User Manual

Model: MF0495

1. INTRODUCTION AND OVERVIEW

The Creative Pebble X Plus 2.1 USB-C Computer Speakers with Subwoofer offer a powerful and immersive audio experience for your PC and Mac. Featuring customizable RGB lighting, Bluetooth 5.3, and versatile USB audio connectivity, this system is designed to elevate your desktop aesthetics and sound quality. With upgraded 2.75-inch drivers and a compact subwoofer, it delivers punchy bass and clear, balanced audio.



Image: The Creative Pebble X Plus 2.1 speaker system, featuring two spherical satellite speakers and a compact cubic subwoofer.

2. WHAT'S IN THE BOX

Upon unboxing your Creative Pebble X Plus system, you will find the following components:

- Creative Pebble X Plus Satellite Speakers (Left and Right)
- Creative Pebble X Plus Subwoofer
- USB-C to USB-C Cable (for data/audio)
- USB-C to USB-C Cable (for power delivery)
- 3.5mm AUX Input Cable
- Quick Start Guide



COMPACT 2.1 BASS POWERHOUSE

Experience deeply immersive, rich, expansive audio with punchy bass with our all-new compact subwoofer



Image: All components of the Creative Pebble X Plus system laid out, including the two satellite speakers, the subwoofer, and the various connection cables.

Your browser does not support the video tag.

Video: Official unboxing and overview of the Creative Pebble X Plus 2.1 USB-C Computer Speakers by Creative Labs, Inc. This video demonstrates the contents of the box and provides a brief look at the product.

3. SETUP

3.1 Initial Setup

1. Place the subwoofer on a flat, stable surface, ideally on the floor or under your desk for optimal bass response.
2. Position the left and right satellite speakers on your desktop, ensuring they are angled towards your listening position for the best audio projection.
3. Connect the satellite speakers to the subwoofer using their integrated cables.
4. Connect the subwoofer to the main speaker unit using the provided RCA cable.

3.2 Connectivity Options

The Creative Pebble X Plus offers multiple ways to connect to your devices:

- **USB Audio:** Connect the USB-C to USB-C cable from your computer's USB-C port to the USB-C data port on the main speaker. This provides digital audio playback.
- **Bluetooth 5.3:** For wireless streaming, activate Bluetooth on your device and pair with "Creative Pebble X Plus".
- **3.5mm AUX Input:** Use the provided 3.5mm AUX cable to connect to any device with a standard audio jack.

MULTI-CONNECTIVITY OPTIONS

Select between wired and wireless modes; supports USB audio playback, *Bluetooth* 5.3 streaming, and analog 3.5 mm AUX input

Also included are headset and microphone ports for quick and easy communication



Image: A diagram illustrating the various connectivity options for the Creative Pebble X Plus, including USB-C, Bluetooth, and 3.5mm AUX input.

3.3 Power Requirements

The speakers are powered via USB-C. For standard performance, they deliver up to 15W RMS power and 30W peak. To achieve amplified sound playback of up to 30W RMS and a 60W peak, connect the USB-C PD cable to a 30W or higher USB Power Delivery (PD) adapter (not included).

FURTHER AUDIO AMPLIFICATION WITH USB PD ADAPTER²

Unleash the speaker's potential for even punchier bass
and increased audio immersion



Up to 30W
RMS power output

**60W
PEAK**

Up to 60W Peak



²Rated at 30W or higher (not included)

Image: A Creative Pebble X Plus speaker shown next to a USB PD adapter, highlighting the option for amplified sound output.

4. OPERATING INSTRUCTIONS

4.1 Controls

All primary controls are located on the front of the right satellite speaker:

- **Volume Knob:** Rotate clockwise to increase volume, counter-clockwise to decrease.
- **Source Button:** Press to cycle between USB, Bluetooth, and AUX input modes.
- **RGB Lighting Button:** Press once to cycle through different RGB lighting presets. Press and hold for 2 seconds to enter brightness control mode, then rotate the volume knob to adjust brightness.



Image: A close-up view of the main satellite speaker's controls, including the volume knob, source selection button, and RGB lighting control button.

4.2 RGB Lighting Customization

The Creative Pebble X Plus features customizable RGB lighting with up to 16.8 million color combinations and six lighting presets:

- Chaser
- Aurora
- Peak Meter
- Glow
- Wave
- Cycle

Adjust brightness by pressing and holding the RGB button and rotating the volume knob.



RADIANT RGB DESIGN

Elevating your desktop aesthetics

Image: A Creative Pebble X Plus speaker displaying its vibrant RGB lighting on a desktop setup.

4.3 Headset and Microphone Ports

The main satellite speaker includes dual communication ports for a headset and microphone, allowing for quick switching between private listening and effortless communication when needed.



Image: A close-up of the side of the Creative Pebble X Plus speaker, showing the dedicated ports for a headset and

microphone.

5. MAINTENANCE

- Keep the speakers and subwoofer clean by wiping them with a soft, dry cloth.
- Avoid using liquid cleaners or abrasive materials, as these can damage the finish or internal components.
- Ensure proper ventilation around the subwoofer to prevent overheating.
- Keep the speakers away from direct sunlight, heat sources, and excessive moisture.

6. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|-------------------------------|---|--|
| No sound output | Incorrect input source selected, loose cable connections, low volume. | Ensure correct input mode (USB, Bluetooth, AUX) is selected. Check all cable connections. Increase volume on speakers and connected device. |
| Bluetooth pairing issues | Speakers not in pairing mode, device too far, interference. | Press the source button to enter Bluetooth pairing mode. Ensure speakers are within 10 meters of your device. Remove any obstacles or sources of interference. |
| RGB lights not working or dim | Brightness set too low, power delivery issue. | Adjust RGB brightness using the control button and volume knob. Ensure a 30W or higher USB PD adapter is used for maximum brightness. |
| Distorted audio | Volume too high, poor audio source quality. | Reduce speaker volume. Check audio source quality and try a different source if possible. |

7. SPECIFICATIONS

- **Model Name:** Creative Pebble X Plus 2.1 USB-C Computer Speakers with Subwoofer and Customizable RGB Lighting, Bluetooth 5.3, USB Audio, Up to 15W RMS Power for PC and Mac
- **Brand:** Creative
- **Model Number:** MF0495
- **Speaker Type:** Satellite (2.1 Channel)
- **Subwoofer Diameter:** 2.75 Inches
- **Woofer Diameter:** 2.75 Inches

- **Speaker Maximum Output Power:** 60 Watts (Peak)
- **RMS Power:** 15W (Standard), 30W (with 30W+ USB PD adapter)
- **Connectivity Technology:** USB-C (Audio & Power Delivery), Bluetooth 5.3, 3.5mm AUX
- **Wireless Communication Technology:** Bluetooth
- **Bluetooth Range:** 10 Meters
- **Control Method:** Button, Knob
- **Color:** Black
- **Product Dimensions:** 7"D x 18.26"W x 7.04"H
- **Item Weight:** 8.04 Pounds
- **Mounting Type:** Tabletop Mount
- **Special Features:** Bass Boost, Hi-Res Audio, USB Port, Customizable RGB Lighting

8. WARRANTY AND SUPPORT

The Creative Pebble X Plus comes with a Limited Warranty provided by Creative Labs. For detailed warranty information, product registration, and technical support, please visit the official Creative Labs website or contact their customer service. Keep your proof of purchase for warranty claims.

For further assistance, refer to the Quick Start Guide included in your package or visit the Creative support page online.