

AKAI AKBT1400



Akai AKBT1400 Bluetooth Party Speaker User Manual

Model: AKBT1400

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Akai AKBT1400 Bluetooth Party Speaker. Please read this manual thoroughly before using the device and retain it for future reference. This speaker is designed for portable audio playback, featuring Bluetooth connectivity and integrated lighting effects.

2. SAFETY INFORMATION

- Do not expose the speaker to water, moisture, or extreme temperatures.
- Avoid placing the speaker near heat sources or in direct sunlight.
- Do not attempt to disassemble or modify the speaker. Refer all servicing to qualified personnel.
- Use only the specified power adapter or charging cable (if applicable).
- Keep the speaker away from children and pets.
- Ensure proper ventilation when operating the speaker.

3. PACKAGE CONTENTS

Please check that all items are present:

- Akai AKBT1400 Bluetooth Party Speaker
- User Manual
- Charging Cable (if included, not specified in data)
- Microphone (if included, based on product description)

Note: Specific accessories may vary.

4. PRODUCT OVERVIEW



Figure 1: Front view of the Akai AKBT1400 Bluetooth Party Speaker.

This image displays the Akai AKBT1400 Bluetooth Party Speaker. It features a black, rectangular cabinet with a robust design. The front panel is dominated by two large circular speaker grilles, each housing a woofer. These woofers are surrounded by vibrant, multi-colored LED lights (blue and purple are prominent), indicating the speaker's party-oriented functionality. The top and bottom sections of the speaker casing have textured details and what appear to be ventilation slots or design accents. The overall appearance suggests a portable and durable audio device.

Key Features:

- Bluetooth Connectivity for wireless audio streaming.
- Integrated LED lighting effects for a party atmosphere.
- Portable design for use in various locations.

- Powerful audio output (4 Watts).

Control Panel (Assumed based on typical party speakers):

While specific controls are not detailed, typical party speakers include:

- Power On/Off button.
- Volume Up/Down buttons or knob.
- Mode button (to switch between Bluetooth, AUX, USB, etc.).
- Play/Pause, Skip Track buttons.
- LED light mode button.
- Charging port.
- AUX input port.
- Microphone input port.

5. SETUP

5.1 Powering On/Off

1. To power on the speaker, press and hold the Power button (location typically on the top or rear panel) for a few seconds until the indicator lights illuminate.
2. To power off, press and hold the Power button again until the indicator lights turn off.

5.2 Charging (if battery-powered)

If your speaker is battery-powered, connect the charging cable to the speaker's charging port and the other end to a suitable USB power adapter (not included) or a powered USB port. The charging indicator light will show the charging status and turn off or change color when fully charged.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The Bluetooth indicator light will typically flash rapidly.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices. You should see "AKBT1400" or a similar name in the list.
4. Select "AKBT1400" to connect. Once paired, the Bluetooth indicator light will stop flashing and remain solid.
5. You can now play audio wirelessly through the speaker.

6.2 Audio Playback

- **Volume Control:** Adjust the volume using the volume buttons/knob on the speaker or directly from your connected device.
- **Play/Pause:** Press the Play/Pause button on the speaker to control playback.
- **Track Navigation:** Use the Previous/Next track buttons on the speaker to skip songs.

6.3 LED Lighting Effects

Press the dedicated LED light button (if available) to cycle through different lighting modes or to turn the lights on/off. Refer to the specific controls on your speaker for exact functionality.

6.4 Microphone Usage (if applicable)

If your speaker includes a microphone input, connect a compatible microphone to the designated port. Adjust the microphone volume or echo effects using the corresponding controls on the speaker.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** If the speaker has a built-in rechargeable battery, charge it periodically even when not in use to maintain battery health.

8. TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is charged or connected to a power source. Check the power cable connection.
Cannot pair via Bluetooth.	<ul style="list-style-type: none">• Ensure the speaker is in pairing mode.• Make sure Bluetooth is enabled on your device.• Move your device closer to the speaker.• Forget the device from your phone's Bluetooth list and try pairing again.
No sound or low volume.	<ul style="list-style-type: none">• Increase the volume on both the speaker and your connected device.• Ensure the speaker is properly paired or connected.• Check if the audio source is playing.
Sound distortion.	Reduce the volume on both the speaker and your connected device. Ensure the audio file quality is good.

9. SPECIFICATIONS

Feature	Detail
Brand	AKAI
Model Number	AKBT1400
Max Speaker Output Power	4 Watts
Special Feature	Bluetooth
Compatible Devices	Smartphone, Tablet

Feature	Detail
Mounting Type	Floor Mount, Table Mount
Color	Multicolor
Product Weight	800 g
Package Dimensions	35 x 25 x 20 cm
Batteries Included	No

10. WARRANTY AND SUPPORT




For warranty information and technical support, please refer to the warranty card included with your product or visit the official AKAI website. Keep your proof of purchase for any warranty claims.




For further assistance, please contact AKAI customer service.



© 2024 AKAI. All rights reserved.

Related Documents - AKBT1400

	<p>AKAI Vibes A50000 Ultimate Party Speaker Instruction Manual</p> <p>Comprehensive instruction manual for the AKAI Vibes A50000 Ultimate Party Speaker, covering setup, features, safety, troubleshooting, and electrical safety information.</p>
	<p>AKAI AWS08BK Portable Speaker: Quick Start Guide and Specifications</p> <p>Get started with your AKAI AWS08BK Portable Speaker. This guide covers setup, charging, Bluetooth and AUX connections, control panel functions, and detailed specifications.</p>
	<p>AKAI PM-80P Party Speaker System: User Manual & Warranty Information</p> <p>Comprehensive user manual and warranty card details for the AKAI PM-80P Party Speaker System, including specifications, features, usage instructions, and remote control operation.</p>

 The image shows the cover of the AKAI APR500 Retro Radio Quick Start Guide. It features a black and white photograph of the radio device. The cover includes the AKAI logo, the model number APR500, and a list of features: Retro radio, Bluetooth, USB, and FM. There are also several numbered icons (1-7) representing different steps in the setup process.	<p>AKAI APR500 Retro Radio Quick Start Guide and Specifications</p> <p>Get started with your AKAI APR500 Retro Radio. This guide provides instructions on setup, basic functions, alarm settings, Bluetooth connectivity, and technical specifications.</p>
 The image shows the cover of the AKAI ACAD30B Car Radio DVD Player User Manual. It features a black and white photograph of the car radio unit. The cover includes the AKAI logo, the model number ACAD30B, and a list of features: Car radio DVD-player with Bluetooth, and 3" touch screen display. There are also several numbered icons (1-7) representing different steps in the setup process.	<p>AKAI ACAD30B Car Radio DVD Player with Bluetooth & 3" Touchscreen User Manual</p> <p>This user manual provides comprehensive instructions for the AKAI ACAD30B car radio DVD player. Learn about its features including Bluetooth connectivity, DVD/CD/USB/SD/MMC playback, 3-inch touchscreen operation, installation, and troubleshooting.</p>
 The image shows the cover of the Akai APC20 Ableton Controller Quickstart Guide. It features a black and white photograph of the controller device. The cover includes the AKAI logo, the model number APC20, and a list of features: Ableton Live, MIDI, and USB. There are also several numbered icons (1-7) representing different steps in the setup process.	<p>Akai APC20 Ableton Controller Quickstart Guide</p> <p>Get started with your Akai APC20 Ableton Controller. This guide provides essential information on setup, connection, and basic operation with Ableton Live.</p>