

[Manuals.plus](#) /

> [VIBOX](#) /

> VIBOX VI-116 PC Gamer Instruction Manual

VIBOX VI-116

VIBOX VI-116 PC Gamer Instruction Manual

Model: VI-116

1. SETUP

This section guides you through the initial setup of your VIBOX VI-116 PC Gamer. Follow these steps carefully to ensure proper functionality.

1.1 Unboxing and Placement

- Carefully remove the PC and all accessories from the packaging. Retain the packaging for future transport or warranty claims.
- Place the PC on a stable, flat surface with adequate ventilation. Ensure there is clear space around the air intake and exhaust vents.
- Remove any protective films or internal packaging materials from the PC case.



Image: The VIBOX VI-116 PC Gamer with its side panel open, showcasing the internal layout, motherboard, CPU cooler, and illuminated cooling fans. This view is useful for understanding internal component placement during initial setup or maintenance.

1.2 Connecting Peripherals

Connect your monitor, keyboard, mouse, and other essential peripherals to the appropriate ports on the rear and front of the PC.

- **Monitor:** Connect your monitor to the graphics card's video output port (e.g., HDMI, DisplayPort, or VGA as specified). Ensure the cable is securely fastened.
- **Keyboard and Mouse:** Plug your keyboard and mouse into the available USB ports.
- **Network:** For wired internet, connect an Ethernet cable to the LAN port. For wireless internet, ensure the Wi-Fi antenna (if provided) is attached or that the internal Wi-Fi is enabled.
- **Audio:** Connect speakers or headphones to the audio output jacks.
- **Power:** Connect the power cable to the PC's power supply unit (PSU) and then to a wall outlet or surge protector.



Image: A detailed view of the top front panel of the VIBOX VI-116 PC Gamer, showing the power button, reset button, USB ports, and audio input/output jacks. These ports are convenient for connecting frequently used peripherals.

1.3 Initial Boot

- Press the power button on the front of the PC.
- The system will boot into Windows 11. Follow the on-screen instructions to complete the initial Windows setup, including language, region, network connection, and user account creation.
- Allow Windows to install any necessary updates after the initial setup is complete.

2. OPERATING

This section provides basic instructions for operating your VIBOX VI-116 PC Gamer.

2.1 Power On/Off

- **Power On:** Press the power button located on the front panel of the PC.
- **Shut Down:** Click the Start button in Windows, then select the Power icon, and choose "Shut down."

- **Restart:** Click the Start button, then select the Power icon, and choose "Restart."
- **Sleep:** Click the Start button, then select the Power icon, and choose "Sleep."

2.2 Connecting to Wi-Fi

- Click the network icon (Wi-Fi or Ethernet) in the system tray on the bottom right of your screen.
- Select your desired Wi-Fi network from the list.
- Enter the network security key (password) if prompted, then click "Connect."

2.3 Using USB and Audio Ports

- USB ports are available on both the front and rear of the PC for connecting devices such as external drives, game controllers, and charging cables.
- The front audio jacks are convenient for connecting headphones and microphones. The rear audio jacks are typically used for permanent speaker setups.

3. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your VIBOX VI-116 PC Gamer.

3.1 Cleaning and Airflow

- **Dust Removal:** Periodically clean dust from the exterior of the PC using a soft, dry cloth. For internal cleaning, power off and unplug the PC. Use compressed air to gently clear dust from fans, heatsinks, and vents.
- **Ventilation:** Ensure that the PC's air intake and exhaust vents are not obstructed. Good airflow is crucial for preventing overheating.



Image: A close-up view of the AMD CPU fan within the VIBOX VI-116 PC Gamer, illustrating the importance of keeping cooling components free from dust for efficient heat dissipation.

3.2 Software Updates

- **Windows Updates:** Regularly check for and install Windows updates to ensure security and performance improvements. Go to Settings > Windows Update.
- **Driver Updates:** Keep your graphics drivers and other component drivers updated. Visit the manufacturer's websites (e.g., AMD for graphics) for the latest versions.

3.3 Data Backup

Regularly back up your important files to an external drive or cloud storage to prevent data loss.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your VIBOX VI-116 PC Gamer.

- **No Power:**

- Ensure the power cable is securely connected to both the PC and the wall outlet.
 - Check if the power switch on the PSU (at the back of the PC) is in the 'On' position.
 - Test the wall outlet with another device to confirm it has power.
- **No Display:**
 - Verify that the monitor is powered on and the video cable is securely connected to both the PC's graphics card and the monitor.
 - Ensure the monitor's input source is set correctly (e.g., HDMI, DisplayPort, VGA).
 - Try connecting the monitor to a different video output port on the PC, if available.
- **Slow Performance:**
 - Check for background applications consuming excessive resources using Task Manager (Ctrl+Shift+Esc).
 - Ensure Windows and drivers are up to date.
 - Run a disk cleanup and defragmentation (for HDD) or TRIM (for SSD) to optimize storage.
 - Scan for malware or viruses.
- **Network Issues:**
 - For Wi-Fi, ensure you are connected to the correct network and have entered the password correctly. Restart your router/modem.
 - For wired connection, check the Ethernet cable and ensure it's properly connected.
 - Run Windows Network Troubleshooter (Settings > Network & Internet > Status > Network troubleshooter).

5. SPECIFICATIONS

Below are the technical specifications for the VIBOX VI-116 PC Gamer.

Feature	Detail
Brand	VIBOX
Model Number	VI-116 (Product Title), 2023 (Specification)
Processor	AMD Ryzen 3200GE (4GHz)
Graphics	Radeon Vega 8
RAM	16 GB (DIMM)
Storage	2 TB HDD
Operating System	Windows 11
Connectivity	Wi-Fi, VGA
Screen Size (Pack)	22 Inches
Item Dimensions (L x W x H)	41 x 21 x 45 cm

6. WARRANTY AND SUPPORT

Your VIBOX VI-116 PC Gamer comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions, including coverage duration and claim procedures.

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact VIBOX customer support through their official website or the retailer where the product was purchased. Have your product model number (VI-116) and proof of purchase ready when contacting support.



© 2023 VIBOX. All rights reserved.