

[manuals.plus](#) /› [Legrand](#) /› [LEGRAND Easykit 365220 7-inch Color Screen Video Intercom System User Manual](#)

Legrand 365220

LEGRAND Easykit 365220 7-inch Color Screen Video Intercom System User Manual

Model: 365220

1. INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your LEGRAND Easykit 365220 WiFi Video Intercom System. This system features a 7-inch color screen and offers remote control capabilities via the Home + Security application, enhancing your home security and convenience. Please read this manual thoroughly before installation and use to ensure proper function and safety.

2. SAFETY INFORMATION

Always adhere to local electrical codes and safety regulations during installation. Disconnect power before performing any wiring or maintenance. This device is designed for indoor use (monitor) and outdoor use (street panel) within specified environmental conditions. Do not expose the monitor to excessive moisture or extreme temperatures. Only use the provided power adapter or a compatible Legrand power supply.

3. PACKAGE CONTENTS

Verify that all components are present in your package:

- LEGRAND Easykit 365220 Indoor Monitor (7-inch color screen)
- Power Adapter (30W plug-in type)
- 1.85m Power Cable
- Mounting Accessories (screws, wall plugs)
- Extension Accessory
- User Manual (this document)

Note: The outdoor street panel is typically sold separately or as part of a complete kit.




Figure 3.1: Front view of the LEGRAND Easykit 365220 indoor monitor. The monitor is white with a black screen and Legrand branding at the bottom center. Control icons are visible on the right side of the screen.



Figure 3.2: The included 30W plug-in power adapter with its cable. This adapter is essential for powering the indoor monitor.

4. PRODUCT FEATURES

- **7-inch Color Screen:** Provides clear video feed from the outdoor panel.
- **Connected Monitor:** Functions as an additional Wi-Fi monitor for multi-point access control within your home.
- **Remote Control with App:** Utilize the free Home + Security application on your smartphone to answer calls, verify visitors, and open doors remotely.
- **Visitor Control:** Communicate with visitors before granting access, enhancing home security.
- **Expandable System:** Supports connection to a second outdoor street panel (sold separately) for properties with multiple entrances.
- **Easy Installation:** Designed for quick and straightforward setup with minimal wiring.
- **Optional Camera Compatibility:** Compatible with Legrand 3 694 01 night vision camera for enhanced security (camera sold separately).

5. SETUP AND INSTALLATION

5.1 Pre-Installation Checklist

- Ensure you have all necessary tools (screwdriver, drill, level).
- Identify a suitable location for the indoor monitor, near a standard 2P+T power outlet.
- Confirm the distance between the monitor and the street panel does not exceed 100 meters.

5.2 Mounting the Indoor Monitor

1. Carefully unpack the monitor and accessories.
2. Position the mounting bracket on the desired wall location and mark the drill holes.
3. Drill holes and insert wall plugs if necessary.
4. Secure the mounting bracket to the wall using the provided screws.
5. Connect the necessary wiring from the outdoor panel (if applicable) to the monitor terminals as per the wiring diagram (refer to the specific wiring diagram provided with your outdoor panel).
6. Mount the monitor onto the bracket, ensuring it clicks securely into place.

5.3 Power Connection

1. Connect the 1.85m power cable to the 30W plug-in adapter.
2. Plug the adapter into a standard 2P+T power outlet.
3. The monitor will power on automatically.




Figure 5.1: Side view of the indoor monitor showing its dimensions (215 mm length, 140 mm height, 22.3 mm depth). This helps in planning the installation space.

5.4 App Configuration (Home + Security)

1. Download the free Legrand Home + Security application from your smartphone's app store.
2. Follow the in-app instructions to create an account or log in.
3. Add your LEGRAND Easykit 365220 system by scanning a QR code or following the guided setup process.
4. Connect the monitor to your home Wi-Fi network through the app.
5. Customize settings such as ringtones, notification preferences, and access control options.

6. OPERATING INSTRUCTIONS

6.1 Basic Monitor Functions

- **Answering Calls:** When a visitor presses the call button on the outdoor panel, the indoor monitor will ring and display the visitor's image. Press the **Answer** button (typically a phone icon) to communicate.
- **Opening Doors/Gates:** During a call or live view, press the **Unlock** button (typically a key icon) to open a connected door or gate.
- **Live View:** Press the **View** button (typically an eye icon) to see a live feed from the outdoor panel at any time.
- **Intercom Function:** If multiple indoor monitors are installed, use the intercom function to communicate between them.



Figure 6.1: Close-up of the control icons on the right side of the monitor. These icons typically include unlock, answer call, live view, and other system functions.

6.2 Remote Operation via Home + Security App

- **Receive Notifications:** Get instant alerts on your smartphone when a visitor presses the call button.
- **Remote Communication:** Answer calls and speak to visitors from anywhere using your smartphone.
- **Remote Access Control:** Open doors or gates remotely through the app.
- **View History:** Access a log of missed calls and visitor events.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the monitor screen and body. Do not use abrasive cleaners or

solvents.

- **Software Updates:** Regularly check the Home + Security app for available firmware updates for your device to ensure optimal performance and security.
- **Power Cycle:** If the monitor experiences issues, try disconnecting the power adapter for 30 seconds and then reconnecting it.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Monitor not powering on	No power, faulty adapter, loose connection.	Check power outlet, ensure adapter is securely plugged in, try a different outlet.
No video from outdoor panel	Wiring issue, outdoor panel not powered, camera fault.	Verify wiring connections between monitor and outdoor panel. Ensure outdoor panel has power.
Cannot connect to Wi-Fi/App	Incorrect Wi-Fi password, weak signal, router issue.	Double-check Wi-Fi password. Move monitor closer to router. Restart router. Follow app's troubleshooting steps.
Door/Gate not unlocking	Wiring to lock faulty, lock mechanism issue, incorrect settings.	Inspect wiring to the electric lock. Test the lock independently. Check app settings for access control.





9. SPECIFICATIONS

- **Model Number:** 365220
- **Manufacturer:** Legrand
- **Product Dimensions (L x W x H):** 21.5 x 2.23 x 14 cm
- **Weight:** 1.04 kg
- **Screen Size:** 7-inch Color Display
- **Connectivity:** Wi-Fi
- **Power Supply:** 30W Plug-in Adapter (included)
- **Max. Distance (Monitor to Street Panel):** 100 meters
- **App Compatibility:** Legrand Home + Security
- **Country of Origin:** China
- **Default Language (Product Interface):** Spanish (may vary by region or be configurable)

10. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or visit the official Legrand website. For technical support, troubleshooting assistance, or to inquire about spare parts, please contact Legrand customer service through their official channels. Keep your proof of purchase for warranty claims.

Related Documents - 365220

	<p><u>Legrand Connected Switch with Dimmer Option - Installation and Wiring Guide</u></p> <p>Detailed guide for installing and wiring the Legrand Valena Life with Netatmo connected switch with dimmer option. Includes pack contents, technical specifications, wiring precautions, safety instructions, and EU Declaration of Conformity.</p>
	<p><u>Legrand Master-Switch Kommen/Gehen: Installation and Battery Replacement Guide</u></p> <p>A guide to installing and replacing the battery in the Legrand Master-Switch Kommen/Gehen wireless smart home device. Includes packaging contents, technical specifications, and EU conformity information.</p>
	<p><u>Legrand Wireless 4 Scenes Control CB0414 - Installation and Usage Guide</u></p> <p>Install, reset, and use the Legrand Wireless 4 Scenes Control (CB0414) with the Home + Control app. Includes safety instructions, technical specifications, and EU declaration of conformity.</p>
	<p><u>Legrand SEANO™: Moderne Schalterserien für Ihr Zuhause</u></p> <p>Entdecken Sie die Legrand SEANO™ Schalterserie – eine wegweisende Kollektion für Design, Smart Home und Nachhaltigkeit. Erfahren Sie mehr über die vielfältigen Designs, einfache Installation und innovative Smart-Home-Lösungen.</p>
	<p><u>Legrand Smarther with Netatmo Connected Thermostat: Smart Home Heating Control</u></p> <p>Explore the Legrand Smarther with Netatmo connected thermostat. This guide details its smart features, remote control via the Home + Control app, voice assistant compatibility, energy saving capabilities, and installation options for optimal home comfort.</p>
	<p><u>Legrand Wireless and Batteryless Home/Away Control Installation Guide</u></p> <p>Guide to installing and configuring the Legrand Wireless and Batteryless Home/Away control system, including pairing, setup, and app integration with Legrand Home + Control.</p>