Lafe CEG015

Lafe CEG015 Electric Kettle User Manual

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using your Lafe CEG015 Electric Kettle and retain them for future reference. Incorrect operation may cause potential hazards.

- Always ensure the kettle is placed on a firm, flat, heat-resistant surface.
- Do not immerse the kettle, power base, cord, or plug in water or any other liquid.
- This appliance is for household use only. Do not use outdoors.
- Keep the appliance out of reach of children and pets. Close supervision is necessary when the appliance is used near children.
- Do not operate the kettle if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.
- Unplug the kettle from the outlet when not in use and before cleaning. Allow it to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not fill the kettle above the 'MAX' level or below the 'MIN' level to prevent boiling dry or water splashing.
- Always ensure the lid is securely closed before operating the kettle.
- Use caution when pouring hot water. Pour slowly and do not over-tilt the kettle.
- The kettle features an automatic shut-off and boil-dry protection system. If the kettle boils dry, it will automatically switch off. Allow it to cool down for 15-20 minutes before refilling with cold water.
- Only use the power base provided with the kettle.

2. PRODUCT OVERVIEW

The Lafe CEG015 Electric Kettle is designed for quick and efficient water boiling, featuring a durable glass body and a powerful heating element.



Image 1: A clear glass electric kettle with a black handle and lid, and a silver base. The kettle is shown with water boiling inside, illuminated by a red LED light ring at the bottom. Measurement markings for MAX 1.7L, 1.0L, and 0.5L MIN are visible on the glass body. The Lafe logo is on the silver base.

Key Features:

• Capacity: 1.7 Liters

• Power: 2200 Watts for rapid boiling

• Material: Durable glass body with plastic and silver accents

• Safety: Equipped with overheat protection and boil-dry safety features

• Design: Transparent body with LED illumination during operation

3. SETUP

1. Unpacking: Carefully remove the kettle and all accessories from the packaging. Dispose of

- packaging materials responsibly.
- 2. **First Use Cleaning:** Before first use, fill the kettle with clean water to the 'MAX' level. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
- 3. **Placement:** Place the power base on a dry, flat, and stable surface, away from the edge of the countertop and out of reach of children. Ensure the power cord is not dangling.
- 4. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet. Ensure the voltage matches the rating label on the bottom of the power base.

4. OPERATING INSTRUCTIONS

- 1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of fresh cold water. Do not fill below the 'MIN' mark (0.5L) or above the 'MAX' mark (1.7L). Overfilling may cause boiling water to splash out.
- 2. Close the Lid: Ensure the lid is securely closed before placing the kettle on its power base.
- 3. Place on Power Base: Position the kettle firmly onto the power base.
- 4. **Switch On:** Press the ON/OFF switch located on the handle or base. The indicator light will illuminate, indicating that the kettle is heating.
- 5. **Boiling Process:** The water will begin to heat. Once the water reaches boiling point, the kettle will automatically switch off, and the indicator light will extinguish.
- 6. **Pouring:** Carefully lift the kettle from the power base and pour the hot water slowly and steadily.
- 7. **Re-boiling:** If you need to re-boil, wait a few seconds for the automatic switch to reset before pressing the ON/OFF switch again.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your kettle.

- **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- Exterior Cleaning: Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals, as these may damage the surface.
- **Interior Cleaning:** The interior of the glass body can be cleaned with a soft brush or sponge. Rinse thoroughly with clean water.
- **Descaling:** Limescale buildup can affect performance. To descale, fill the kettle with a mixture of one part white vinegar and two parts water, or use a commercial descaling solution according to its instructions. Boil the mixture, then let it stand for at least 30 minutes (or longer for heavy buildup). Discard the solution and rinse the kettle thoroughly several times with fresh water. Boil fresh water 2-3 times and discard to remove any residual vinegar taste.
- **Power Base:** Never immerse the power base in water or any other liquid. Wipe it with a dry cloth if necessary.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	No power supply. Kettle not properly seated on base.	Check if the plug is securely in the outlet. Ensure the kettle is correctly placed on the power base.

Problem	Possible Cause	Solution
Kettle switches off before boiling.	Limescale buildup. Boil-dry protection activated.	Descale the kettle. If boil-dry protection activated, allow kettle to cool for 15-20 minutes before refilling.
Water tastes strange after boiling.	First use residues. Limescale buildup.	Perform first use cleaning (boil and discard water several times). Descale the kettle.
Water splashes out during boiling.	Kettle is overfilled.	Do not fill above the 'MAX' level.

If the problem persists after trying these solutions, please contact customer support.

7. SPECIFICATIONS


Feature	Specification
Brand	Lafe
Model Number	CEG015 (LAFCZA46806)
Capacity	1.7 Liters
Power	2200 Watts
Voltage	230 Volts (AC)
Material	Glass, Acrylic (Plastic)
Dimensions (L x W x H)	20.57 x 21.29 x 20.93 cm
Weight	1.29 Kilograms
Special Feature	Overheat Protection

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. Lafe products are designed for reliability and performance.

If you encounter any issues not covered in this manual or require further assistance, please contact Lafe customer support or your product retailer. Please have your model number (CEG015) and purchase details ready when contacting support.

Related Documents



Documents - Lafe - CEG015



[pdf]

Czajnik elektryczny CEG015 Sklep internetowy stylem pl czajnik ceg015 184218 upload files product ||| Czajnik elektryczny CEG015 Indeks: 184218 Producent: Lafe Kod producenta: CEG015 Cena: 115.64 zl Opis Czajnik elektryczny CEG015 Producent: Lafe Wlaciwoci Opis Szklany czajnik Lafe CEG015 niezbdny w Twojej kuchniCzajnik elektryczny to niezbdne wyposaanie kadej nowoczesnej kuchni. Urzdzenie Lafe dzik

lang:pl score:37 filesize: 281.8 K page_count: 3 document date: 2022-08-03



[pdf]

Használati útmutató LAFCZA46806 LaFe CEG015 2200W 1 7L Mikrohálós szűrÅ HáttérvilágÃ-tás Ãveg Fekete Elektromos vÃzforraló Lafe Gravicom Trading Kft 7f7f505efc1653547ad1f73b6593fc87 gravicom hu custom image data srattached |||

MAX 1.7L 1.0L 0.5L MIN PL Czajnik elektryczny Model: **CEG015** EN Electric Kettle Model: **CEG015** CS Elektrick varn konvice Model: **CEG015** SK Elektrick cajnk znacky Model: **CEG015** HU Elektromos vzforral Modell: **CEG015** RU : **CEG015** LT Elektrinis virdulys Modelis: CEG005/CEG005 LV Elektrisk...

lang:pl score:27 filesize: 3.35 M page_count: 44 document date: 2023-11-10