



[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL Recliner Chair User Manual

**vidaXL 348436**

# vidaXL Recliner Chair User Manual

Model: 348436 | Brand: vidaXL

## 1. INTRODUCTION

Thank you for choosing the vidaXL Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and keep it for future reference.



Image 1.1: The vidaXL Recliner Chair in dark grey fabric, designed for comfort and relaxation.

This recliner chair is designed to provide a comfortable and relaxing seating experience with its thick padded seat, backrest, and wide armrests. Its manual recline function allows for adjustment to three different positions, making it suitable for various activities from reading to napping. The robust wood and metal frame ensures stability and durability.

## 2. SAFETY INSTRUCTIONS

**WARNING:** This is a recliner chair with adjustable positions. Always ensure the chair is fully assembled and stable before use. Never exceed the maximum weight capacity. Always follow the assembly instructions carefully to avoid injury. Keep children and pets away from the chair when it is in use or being adjusted.

- Ensure all components are securely fastened during assembly.
- Do not stand on the chair or use it as a step stool.
- Avoid placing the chair near heat sources or direct sunlight to prevent material degradation.
- Keep fingers and limbs clear of moving parts during recline adjustments.
- Regularly check all bolts and connections to ensure they remain tight.

### 3. PRODUCT FEATURES

- **Manual Recline Function:** The chair can be manually adjusted to 3 positions, allowing the backrest and footrest to be set as needed.
- **Comfortable Seating Experience:** The thickly padded seat, backrest, and wide armrests provide a cozy and comfortable seating sensation.
- **Durable Fabric Upholstery:** The fabric cover has a simple and clean appearance, is breathable, and durable.
- **Solid and Stable Frame:** The wood and metal frame ensures a solid structure and high stability, making this TV chair comfortable and long-lasting.
- **Color:** Dark Grey.
- **Material:** Textile fabric.



Image 3.1: Detail of the durable dark grey textile fabric and padded armrest.

## 4. SPECIFICATIONS

Attribute	Value
Brand	vidaXL
Model Number	348436
Color	Dark Grey
Material	Textile fabric (Polyester)
Overall Dimensions (W x D x H)	70 x 93 x 98 cm (27.6" x 36.6" x 38.6")

Reclined Dimensions (W x D x H)	70 x 141 x 81 cm (27.6" x 55.5" x 31.9")
Seat Dimensions (W x D)	49 x 53 cm (19.3" x 20.9")
Seat Height from Ground	45 cm (17.7")
Backrest Length	65 cm (25.6")
Item Weight	21.4 kg (47.18 lbs)
Assembly Required	Yes




Image 4.1: Detailed dimensions of the recliner chair in both upright and reclined positions.

## 5. SETUP AND ASSEMBLY

The vidaXL Recliner Chair requires assembly. It is highly recommended that two people perform the assembly to ensure safety and ease of construction. Please ensure you have sufficient space and all components are present before beginning.

### **Assembly Steps:**

1. Unpack all components and verify against the parts list provided in your packaging.
2. Identify the base frame and attach the legs securely.
3. Connect the backrest to the seat base, ensuring the locking mechanisms (if any) engage properly.
4. Attach the armrests to the main body of the chair.
5. Ensure all bolts and screws are tightened firmly, but do not overtighten.
6. Test the recline mechanism to ensure smooth operation before first use.

If you encounter any difficulties or missing parts, please refer to the troubleshooting section or contact customer support.



Image 5.1: The recliner chair assembled in a typical home environment.

## 6. OPERATING INSTRUCTIONS

The vidaXL Recliner Chair features a manual recline mechanism for easy adjustment to your preferred comfort level.

### Reclining the Chair:

1. To recline, apply gentle pressure to the backrest while pushing back with your body weight.
2. The footrest will simultaneously extend as the backrest reclines.
3. The chair offers 3 distinct reclining positions. Adjust until you find the desired angle.
4. To return to the upright position, lean forward and push the footrest down with your legs until it locks into place.



Image 6.1: Illustration of the recliner chair's adjustable positions, from upright to fully reclined.

## 7. MAINTENANCE

Proper care and maintenance will extend the life of your vidaXL Recliner Chair.

- **Regular Cleaning:** Vacuum the fabric regularly using a soft brush attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric

cleaner following the product instructions and test on an inconspicuous area first. Do not saturate the fabric.

- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position your chair away from direct sun exposure.
- **Check Connections:** Periodically check all bolts and screws to ensure they are tight. Retighten if necessary.
- **Professional Cleaning:** For deep cleaning, consider professional upholstery cleaning services.

## 8. TROUBLESHOOTING

If you experience issues with your recliner chair, please refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Footrest does not lock into place.	Mechanism not fully engaged; assembly issue.	Ensure you are leaning forward and applying sufficient downward pressure to the footrest. Check assembly of the footrest mechanism to ensure all parts are correctly aligned and tightened.
Chair feels unstable or wobbly.	Loose connections or uneven floor.	Check all bolts and screws and tighten them securely. Ensure the chair is on a flat, even surface.
Difficulty reclining or returning upright.	Mechanism obstruction or lack of lubrication.	Check for any obstructions under or around the chair. If the mechanism feels stiff, a small amount of silicone-based lubricant can be applied to moving joints (avoiding fabric).

## 9. WARRANTY AND SUPPORT

Your vidaXL Recliner Chair is covered by a return policy. Please refer to your purchase documentation for specific warranty terms and conditions.

- **Return Policy:** Typically 30 days for refund/replacement. Please check your specific purchase details.
- **Customer Support:** For further assistance, missing parts, or warranty claims, please contact vidaXL customer service through the retailer where you purchased the product or visit the official vidaXL website.
- **Online Resources:** Visit the [vidaXL Store on Amazon](#) for more product information and support.