

Dyson Ball Animal Total Clean (447967-01)

Dyson Ball Animal Total Clean Upright Vacuum

Model: Ball Animal Total Clean (447967-01)

INTRODUCTION

This manual provides essential information for the safe and effective use of your Dyson Ball Animal Total Clean Upright Vacuum. This powerful corded vacuum is engineered for homes with pets, offering strong suction and a self-adjusting cleaner head for optimal performance across all floor types.



dyson ball animal total clean

Dyson's strongest suction with extra tools for a total cleaning solution

Image: The Dyson Ball Animal Total Clean Upright Vacuum being used in a modern living room setting, demonstrating its maneuverability around furniture and pets.

IMPORTANT SAFETY INFORMATION

Before using your Dyson vacuum cleaner, read all instructions and cautionary markings in this manual and on the appliance. When using an electrical appliance, basic precautions should always be followed, including the following:

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only Dyson recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bin and filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.

SETUP AND ASSEMBLY

Your Dyson Ball Animal Total Clean vacuum comes with several components that require simple assembly before first use. Ensure all packaging materials are removed.

Unpacking and Initial Assembly

1. Carefully remove all parts from the packaging.
2. Attach the main body of the vacuum to the cleaner head until it clicks securely into place.
3. Insert the wand into the hose and secure it to the main body.
4. Wrap the power cord around the cord hooks for tidy storage.

Accessory Storage

The vacuum includes a tool bag and integrated storage for some accessories on the machine itself, ensuring they are always within reach.

Attachments and Accessories




Combination tool



Stair tool



Mattress tool



Carbon fiber soft dusting brush



Reach under tool



Tangle-free turbine tool



Multi-angle brush



Tool bag

Image: A visual representation of the eight Dyson-engineered accessories included with the vacuum, neatly arranged for identification.

OPERATING INSTRUCTIONS

Powering On and Off

Plug the power cord into a suitable electrical outlet. Press the red power button located on the main body of the vacuum to turn it on or off.

Self-Adjusting Cleaner Head

The advanced self-adjusting cleaner head automatically adapts to different floor types, from carpets to hard floors, ensuring optimal suction without manual adjustment.



Self-adjusting cleaner head automatically adapts to all floor types

Image: The self-adjusting cleaner head of the Dyson Ball Animal Total Clean vacuum seamlessly moving from a hard floor surface onto a carpeted area.

Using the Wand and Hose

The wand and hose release in one smooth action, allowing you to easily clean high-up areas, under furniture, and other hard-to-reach spots.



Remove dirt and hair from stairs



Tackle hard-to-reach areas



Clean from top to bottom



Pick up fine dust and prevent static

Image: The Dyson Ball Animal Total Clean vacuum's wand and hose attachment being used to effectively clean dirt and hair from carpeted stairs.

Included Accessories and Their Use

- **Tangle-free Turbine Tool:** Designed to remove hair from carpets and upholstery without tangling. Ideal for pet owners.
- **Combination Tool:** A versatile tool for dusting and cleaning crevices.
- **Multi-angle Brush:** Adjusts to various angles for cleaning hard-to-reach surfaces, such as tops of cabinets or ceiling fans.
- **Stair Tool:** Specifically designed for effective cleaning of stairs.
- **Reach Under Tool:** Extends and flexes to clean under low furniture and appliances.
- **Carbon Fiber Soft Dusting Brush:** Gentle on delicate surfaces, designed to pick up fine dust.
- **Mattress Tool:** Removes dust mites and allergens from mattresses and upholstery.



Counter-rotating brush heads remove hair from carpets and upholstery

Image: The Tangle-free Turbine Tool in action, with counter-rotating brush heads effectively removing pet hair from a sofa.

Ball Technology

Dyson Ball technology allows for easy steering and maneuvering around obstacles and furniture with a simple turn of the wrist.



Dyson Ball technology™ designed
for comfortable vacuuming.
Steer smoothly around furniture.

Image: The Dyson Ball Animal Total Clean vacuum smoothly navigating around a sofa and other furniture, highlighting its Ball technology for easy steering.

MAINTENANCE

Hygienic Bin Emptying

To empty the dust bin, simply push the button to release the dirt directly into a trash receptacle. This hygienic design prevents contact with dust and debris.



Hygienically empty bin with a touch of a button. No need to get your hands dirty.

Image: A hand pressing a button to hygienically empty the dust bin of the Dyson Ball Animal Total Clean vacuum into a trash can, showing dust falling out.

Filter Maintenance

The vacuum features whole-machine filtration, trapping particles inside. Regularly check and clean filters as per the instructions in the full user manual to maintain optimal suction and filtration performance.

Brush Bar Cleaning

While the tangle-free turbine tool is designed to prevent hair tangles, it is advisable to periodically check the main cleaner head's brush bar for any accumulated debris or hair and remove it to ensure consistent performance.

Your browser does not support the video tag.

Video: A demonstration on how to clean debris from the Dyson Ball floor brush, ensuring optimal vacuum performance.

TROUBLESHOOTING

If your Dyson Ball Animal Total Clean vacuum is not performing as expected, please refer to the following common issues:

- **No Power:** Check if the power cord is securely plugged into a working outlet. Ensure the power button is pressed.
- **Loss of Suction:** Check the dust bin for fullness and empty if necessary. Inspect the filters and clean

them if they are dirty. Look for blockages in the cleaner head, wand, or hose.

- **Brush Bar Not Rotating:** Ensure the vacuum is in the correct floor mode for brush bar activation.

Check the brush bar for obstructions like tangled hair or debris.

For more detailed troubleshooting or persistent issues, please contact Dyson customer support.

SPECIFICATIONS

Feature	Detail
Brand	Dyson
Model Name	Dyson Ball Animal 2 Total Clean
Item Model Number	447967-01
Power Source	Corded Electric
Suction Power	290 AW
Filter Type	HEPA Filter
Capacity	0.45 Gallons
Recommended Uses	Carpet, Hard Floor, Home
Special Features	Bagless, Self-Adjusting Cleaner Head, Tools for pets
Item Weight	17.42 pounds
Product Dimensions	15.4" L x 15.35" W x 42.13" H

WARRANTY AND SUPPORT

Your Dyson Ball Animal Total Clean Upright Vacuum comes with a **5-year limited warranty**. For warranty claims, technical support, or personalized machine guides, please register your machine on the MyDyson app or contact Dyson customer support.

PRODUCT VIDEOS

Dyson Ball Animal Total Clean Upright Vacuum Review

Your browser does not support the video tag.

Video: A detailed review of the Dyson Ball Animal Total Clean Upright Vacuum, highlighting its features and performance.

Dyson Ball Animal 3 Powerful Suction for Pet Hair

Your browser does not support the video tag.

Video: Demonstrates the powerful suction of the Dyson Ball Animal 3, specifically showcasing its effectiveness on pet hair.

Watch How Much Dyson Picks Up from a Single Room

Your browser does not support the video tag.

Video: A short clip illustrating the impressive amount of dirt and debris the Dyson vacuum can collect from a single room.

