

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AlfaBot](#) /

› [AlfaBot S2 Cordless Electric Mop Instruction Manual](#)

AlfaBot S2

AlfaBot S2 Cordless Electric Mop Instruction Manual

Model: S2 | Brand: AlfaBot

1. PRODUCT OVERVIEW

The AlfaBot S2 Cordless Electric Mop is designed for efficient and effortless floor cleaning across various surfaces. Featuring dual spinning mop heads, an integrated water tank with spray function, and an LED headlight, it simplifies routine cleaning tasks. Its cordless design and adjustable handle provide flexibility and comfort during use.

Key Features:

- **Dual Spin Heads:** Two powerful motors spin up to 200 rotations per minute, effectively removing stubborn stains and dirt. The self-propelling action reduces user effort.
- **Integrated Water Tank:** A 400ml large-capacity water tank allows for wet cleaning with a one-click water spray function.
- **LED Headlight:** Illuminates dark areas, making it easier to clean under furniture and in dimly lit corners.
- **Cordless Operation:** Equipped with a 2600mAh 30W Lithium rechargeable battery, providing up to 60 minutes of runtime on a single charge (4-5 hours charging time), capable of cleaning up to 2500 sq.ft.
- **Adjustable Handle:** The handle length can be adjusted from 37.4 inches to 48.4 inches, accommodating users of different heights. The mop head swivels 180° horizontally and 90° vertically for easy maneuverability.
- **Lightweight Design:** The mop is lightweight and designed to move easily, reducing strain during cleaning.

2. PACKAGE CONTENTS

Please check the box for the following items:

- Mop Head Attachment
- Mop Handle
- Extendable Pipe

- Charger
- Measuring Cup
- Mop Pads (Multiple types for daily, deep, and hair cleaning)
- User Manual (this document)
- Quick Start Guide

Package Contents



Image: All components included in the AlfaBot S2 Electric Mop package.

3. SETUP INSTRUCTIONS

- 1. Assemble the Handle:** Connect the extendable pipe to the mop handle by aligning the buttons and pushing until it clicks into place.
- 2. Connect Power Cord:** Locate the power cord connection point on the handle and securely connect it.
- 3. Attach Mop Head:** Connect the assembled handle to the mop head attachment, ensuring it clicks securely.
- 4. Install Mop Pads:** Select the appropriate mop pads for your cleaning task. The mop pads attach to the bottom of the mop head using hook-and-loop fasteners. Ensure they are centered and firmly pressed onto the spinning discs.
- 5. Fill Water Tank:** Open the water tank cap located on the top of the mop head. Use the provided

measuring cup to fill the 400ml tank with clean water or a suitable floor cleaning solution. Close the cap securely.

Your browser does not support the video tag.

Video: A step-by-step guide on how to assemble the AlfaBot S2 Electric Mop.

4. OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the power button on the handle to turn the mop on or off. The LED headlight will illuminate when the mop is active.
2. **Adjust Handle Length:** Press the adjustment button on the handle to extend or retract the pipe to your desired length.
3. **Use Water Spray:** Press the spray button on the handle to dispense water or cleaning solution onto the floor.
4. **Maneuvering:** Guide the mop across the floor. The dual spinning heads provide a self-propelling action, making it easy to move without significant effort. The flexible handle allows for 180° horizontal and 90° vertical movement to reach under furniture and into tight spaces.
5. **LED Headlight:** The integrated LED headlight helps to reveal dirt and dust in dimly lit areas, ensuring thorough cleaning.

Powerful and Quite Spin Motor

200
r/min

60dB
noise



Image: The AlfaBot S2 mop actively cleaning a floor, highlighting its dual spin heads and illuminating LED headlight.

400ML Big Water Tank

For entire house cleaning



One-click Water Spray

To cleaning all the stains
easily



Image: Close-up of the AlfaBot S2 mop head, illustrating the 400ml water tank and the one-click water spray feature in use.

LED Headlight and Adjustable Angles

Easily reach hard-to-clean corners



Image: The AlfaBot S2 mop cleaning under furniture, showcasing its LED headlight and flexible adjustable angles.

Remove Stains from Different Types Of Floors



Wood floor



Tile floor



Marble floor



Laminate floor



Image: The AlfaBot S2 mop effectively removing stains from different floor types, including wood, tile, marble, and laminate.

Your browser does not support the video tag.

Video: An overview of the AlfaBot S2 Electric Mop's features and cleaning capabilities.

5. MAINTENANCE

- **Cleaning Mop Pads:** After each use, remove the mop pads from the mop head. They are both hand washable and machine washable. Allow them to air dry completely before reattaching or storing.
- **Charging the Battery:** When the battery indicator shows low power, connect the charger to the charging port on the mop and plug it into a power outlet. A full charge takes approximately 4-5 hours.
- **Emptying Water Tank:** After wet cleaning, empty any remaining water or solution from the tank and rinse it with clean water.
- **Storage:** Store the mop in a dry place. The self-standing design allows it to be stored upright without leaning against a wall.

2600mAh Rechargeable Battery for Cordless Use

clean up to 2500 sq.ft area



Image: The AlfaBot S2 mop highlighting its rechargeable battery and the charging connection point.

6. TROUBLESHOOTING

- **Mop Not Turning On:** Ensure the battery is charged. Connect the charger and allow it to charge for at least 30 minutes before attempting to power on again.
- **Spray Function Not Working:** Check if the water tank is filled. Ensure the water tank cap is securely closed. If the issue persists, check for any blockages in the spray nozzle.
- **Mop Pads Not Spinning:** Verify that the mop pads are correctly attached and not obstructed. Ensure the power button is pressed firmly.
- **Reduced Runtime:** Battery runtime may decrease over time with prolonged use. Ensure the mop is fully charged before each use. If runtime significantly decreases, the battery may need replacement.

7. SPECIFICATIONS

Model Number	S2
Brand	AlfaBot
Power Source	Battery Powered (1 Lithium Ion battery included)
Battery Capacity	2600mAh 30W
Runtime	Up to 60 minutes
Charging Time	4-5 hours
Water Tank Volume	400 Milliliters
Spin Speed	Up to 200 rotations/minute
Adjustable Handle Length	37.4" to 48.4"
Item Weight	5.48 pounds (2.49 Kilograms)
Surface Recommendation	Hardwood Floor, Tile Floor, Laminate, Marble, Vinyl
Head Material	Microfiber
Handle Material	Plastic

8. WARRANTY AND SUPPORT

The AlfaBot S2 Cordless Electric Mop comes with a standard manufacturer's warranty. For detailed warranty information, product support, or to purchase replacement parts, please refer to the official AlfaBot website or contact their customer service directly. Contact information can typically be found in the Quick Start Guide or on the product packaging.